

innovators you can count on



Magics Print Metal User Manual

Materialise

materialise.com



Materialise, the Materialise logo, Magics, Streamics and 3-matic are trademarks of Materialise NV in the EU, US and/or other countries.

Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

© 2017 Materialise NV, All rights reserved Rev.04-2017



Table of Contents

Magics	Print	Metal User Manual	. 1
Material	ise l	Jser Manual	. 1
1 Intr	oduc	tion to Build Processors	. 6
2 Thi	s use	r guide	. 7
PART 1			. 8
3 Set	up		. 9
3.1.	Pre	requisites	. 9
3.2.	Inst	alling Materialise Magics software	10
3.3.	Inst	alling Materialise MPM BP	11
3.4.	Lice	nsing	14
4 Bui	ld Pro	ocessor machine management: The Basics	15
4.1.	Acc	ess the Build Processor Manager	15
4.2.	Add	a Local BP Machine	18
4.3.	Add	a Network BP Machine	21
4.4.	Ren	nove a BP Machine	26
4.5.	Con	figure a BP Machine	27
4.5	.1	Materialise Control Platform users	28
4.6.	Acc	ess the BP Machine Properties	30
4.7.	Cha	inge the BP Machine Platform Settings	31
4.8.	Cha	inge the BP System storage location	33
4.9.	Acc	ess the BP Machine Job Queues	34
4.10.	С	onfigure BP Tray Notifications	37
5 Bui	ld Pro	ocessor and Magics	38
5.1.	Cre	ate a Build Processor Scene	38
5.2.	BP	Toolbar	39
5.2	.1	Configure BP Printer	39
5.2	.2	Platform Properties Configuration	40
5.2	.3	Submit a Job (Build)	41
5.3.	The	Build Output	44
6 Usa	age o	f Profile Editor	45
6.1.	Intro	oduction and concepts	45
6.2.	Lau	nching the Profile Editor	46
6.3.	Ger	neral usage of the Profile Editor	48
6.3	.1	Selecting a profile for editing	48
6.3	.2	Editing profile names	49
6.3	.3	Expand and Collapse All	49
6.3	.4	Modifying parameters	49



6.3.	5 Getting information about parameters	50
6.3.	6 Resetting parameters to their default values	51
6.4.	Creating and editing Materials	52
6.5.	Creating and deleting Profiles	53
6.5.	1 Creating Build Strategies by cloning existing Build Strategies	53
6.5.	2 Creating Build Strategies based on factory defaults	54
6.5.	3 Deleting Build Strategies	54
6.6.	Exporting and importing build parameters	55
6.6.	1 Exporting build parameters	55
6.6.	2 Importing build parameters	56
PART 2		59
7 Mac	chine Settings	60
7.1.	Export	60
7.2.	Part Placement Check	61
7.3.	Gas Flow	61
7.4.	Build Envelope	62
8 Ger	neral	63
8.1.	Material Defaults	64
8.2.	Scanning Order	66
9 Slic	e Profile	67
9.1.	Slice Thickness	67
9.2.	Fixing Options	69
9.3.	Optimization Options	71
9.3.	1 Point Reduction	71
9.3.	2 Contour Filter	72
9.4.	Side Note: The Build Processor fixing philosophy	73
10 B	uild Strategy	74
10.1.	Slicing	74
10.2.	Rescaling	76
10.3.	Path Generation	78
10.3	3.1 Part Borders	79
10.3	3.2 In Skin	87
10.3	3.3 Up Skin	96
10.3	3.4 Down Skin	100
10.3	3.5 Solid Supports	103
11 S	canning	105
12 S	canning Order	106
12.1.	Build Order	106



12.1.1	Vector Types Order	106
12.1.2	Build Order Mode	108
12.2.	Sorting Against Gas Flow	109
12.3.	Fill Area Vector Sorting	110
12.3.1	Scan Order	110
12.3.2	Hatch Sorting	110
12.3.3	Hatch Style	111
12.4.	Support Vector Sorting	113
PART 3		114
13 Slice	e Based Operations	115
13.1.	Why	115
13.2.	How	115
14 Free	quently Asked Questions	116
14.1.	How to create a report file	116
14.2.	How to grant a computer read/write access to a network folder	118
14.3.	How to run the BP Service under a different user account	123
14.4.	The Build Processor Manager is not in the Control Panel	124
14.5.	Where can I check if I have a valid Materialise Materialise MPM BP license	e?124
14.6.	Can I see what profiles were applied to my processed job?	125
15 Турі	ical Error Cases	126
15.1.	Error message in queue: 'Unexpected open contours in after slicing'	126
15.2.	Error message in queue: 'Uploading print job to machine'	126
16 Sup	port contacts	127
16.1.	Materialise Offices Worldwide	128



1 Introduction to Build Processors

Materialise works in close collaboration with machine developers to create a customized and integrated solution, which allows you to get the most out of your AM machines and build parts with the highest quality possible. Our Build Processor Software can be considered as an advanced export function that bridges the gap between your digital build files and your AM machine, helping to ensure a smooth and trouble free production.





2 This user guide...

...will give you an overview of all the features and functions of the Materialise MPM Build Processor.

For a clear presentation, it is subdivided into three parts.

PART 1 is arranged as a tutorial. It contains

- Installation of Materialise Magics software & Build Processor
- Licensing the Materialise MPM Build Processor
- BP Machine management and configuration
- Displaying the results of build jobs by accessing the BP Machine Queue
- Handling of the Material Development Module
- Interacting with the Profile Editor

PART 2 is designed as a **dictionary**. Explanations of all features and functions of the parameters in the Profile Editor can be looked-up here. It is structured into the main aspects:

- Rescaling
- Slicing
- Hatching
- Scanning

PART 3 represents a frequently asked question catalog. You will find:

- Frequently Asked Questions
- Typical error cases
- Materialise support contacts
- How to send a crash report to Materialise

Technical Requirement

These boxes appear throughout this guide and describe a technical requirement to ensure that the Materialise MPM Build Processor works correctly. If you are not sure on how to attend to these, please contact your IT department.

Warnings / Notifications

These boxes appear throughout this guide and emphasize various warnings or important notifications. Many of these are linked to some of the more frequently asked questions regarding the workings of the Materialise MPM Build Processor.





Setup and tutorial

PART 1 is structured as a tutorial.

You will be guided through the installation process of the Materialise Magics software and the Build Processor including its licensing.

The BP Machine management will be explained step by step, including adding and removing different machines.

It will be shown how to configure the BP Machine, replacing the machine settings or change the storage location of the configuration data. It will also be explained how to get an overview of all build jobs and their results by accessing the BP Machine queue.

The material development module gets introduced and illustrated.

The handling of the Profile Editor is explained covering the editing of materials, creating build strategies and modifying parameters.

There an explanation of the individual parameters in the Profile Editor will not be given (please see PART 2).



3 Setup

3.1. Prerequisites

Before installing the Materialise MPM Build Processor

- It would be a great help if you contact us in case you experience any unexpected software behavior. For all problems, questions or suggestions regarding the Materialise MPM Build Processor (installation / use of software), please contact your local Materialise office.
- Please follow the installation steps in the given order and verify your installations to ensure that your Materialise MPM Build Processor works correctly. The Materialise MPM Build Processor has been tested and verified on Windows® operating system version 7 and version 10 and requires at least Materialise Magics software version 19. Be sure to check out chapter 3.4 Licensing on page 14 before using.
- We hope you will enjoy the Materialise MPM Build Processor!

In order to install and use the Materialise MPM Build Processor, you need the following:

Minimal System Requirements:

Windows® operating system version 7

Software Installation Packages:

- Materialise Magics software
- Materialise MPM Build Processor (including Build Processor System)

Technical Requirement

Please note that administrative rights are required to install the components.



3.2. Installing Materialise Magics software

- 1. Select and execute the Magics installer.
- 2. First, you need to install Magics. Accept the License Agreement and follow through the wizard.



3. Select your local Materialise office as support center.

Materialise office			Magics
Please choose the nearest support	office for license genera	ation.	
Materialise Belgium HQ Materialise China			
Materialise Germany			
Materialise Japan			
Materialise Malaysia Materialise Likraine			
Materialise United Kingdom			
Materialise USA			

4. In the following dialog windows, choose your preferred installation location or keep the default settings and click next. After the installation completed, click "Finish" to close the setup program.





3.3. Installing Materialise MPM BP

1. To launch the Materialise MPM Build Processor installers, open the *MaterialiseMPMBuildProcessor.exe* (32 bit Version) or *MaterialiseMPMBuildProcessor-x64.exe* (64 bit Version).

The bit version should be the same as the bit version of your Magics installation.

HongnianMPMBuildProcessor.exe

HongnianMPMBuildProcessor-x64.exe

This is a 'bundled installer', meaning that it is responsible for installing all the different necessary components to run the Materialise MPM Build Processor. These include:

- Microsoft® .NET Framework 4.5.2 software (prerequisite check)
- Materialise Local License Server 6
- Build Processor System
- Materialise MPM Build Processor
- 2. Select a language, read and accept the terms in the License Agreement and proceed by clicking the *Install* button (when you select "I accept the terms of the License Agreement", the *Install* button will become active):

ease read the Build	Processor License Agreement		
	END-USER SOFTWARE L	LICENSE AGREEMENT	
	ATTEN	TION	
TO BE READ	CAREFULLY BEFORE RENTING OR	PURCHASING ANY MATERIALISE SOFTWARE	
This license agreen and Materialise for	ent (the "Agreement") is a legal agree ir the software product identified herea documentation	ment between you (either an individual or a legal entit ifter, which includes computer software and electronic ("Software").	y)
Please read the follo Software you agree Agreement. If you d	ving license agreement carefully befor to be bound by the terms and conditio o not accept the terms of this Agreeme	e using the Software. By installing or otherwise using ns of this Agreement and the DirectX End-User Licen: int, you are not authorized to install or use the Softwar	the se re.
DEFINITIONS			
The following terms s	hall have the following meanings:		
'Licenser": MATERIA 'Licensee": Holder of 'Licensed Material": 1 'Software": Compute	LISE the license as specified in the order do fedia containing the software, the soft programs in machine-readable form (i	ccument issued by Materialise. ware itself, and the user documentation. object code)	

3. The following screen will appear, informing you about the components that are already installed on your system and those that will be installed during this installation. In the following dialog hit *Proceed* button:





- indicates that the component is (already) installed on your system.
 When no such icon preceeds the component name, it means that it will be installed upon clicking *Proceed*.
- 4. The components will be installed one by one in the shown order with progress bar indicating its progress:

🛃 Build	d Processor Setup		
~	Microsoft .NET Framework 4.5.2	Installing	
~	Materialise Local License Server 6		
~	Build Processor System		
	Build Processor		
		Cancel	

5. A final screen will appear showing you the overall result of the installation process. Pressing the "Finish" button will close the installation window. The final installation screen provides several options for improved accessibility and getting started in the Build Processor Manager. All options are checked by default. When the checkbox "Launch Build Processor Manager" is active, it will open the Build Processor Manager automatically when closing the window.



Build	Processor Setup	
~	Microsoft .NET Framework 4.5.2	Successfully installed.
1	Materialise Local License Server 6	
4	Build Processor System	
~	Build Processor	
		🛛 Launch Build Processor Manager
		Finish

Technical Requirement

If prompted to reboot your system after installation, please do as such.

6. Before using the Materialise MPM Build Processor, please verify that both components have been correctly installed by checking the Programs and Features list on your system.

Uninstall or change a program

To uninstall a program, select it from the list and then click Uninstall, Change, or Repair.

Organize 🔻			
Name	Publisher	Installed On	Size
Read Street Street and Street Street Street	Intel Companying	3030,004	3,416
Bordett Heragemont/Degine Components	Web Composition	State (89)	204
Collineared Malayaca	Indexes, Inc.	3205,265	70,000
🗰 Markéna di Jeresa a selaji	March 2015 Provide State	38.88.2604	1,000,000
Addition Relinspect 2.2	Additional lines	30.00.000	4-0.000
Enterance to drig to area terms	Market Mark	17 10 (FD)	1000
White is a set in the set	Margarian and	Shell 2004	10,7100
KitheiConnet (2013 (dd))	Weight State	3126,2626	200.000
R Heinighter Logal Lances Second	Weight Street	2011.003	10.000
Respect (SAL), Mark	Market Mark	25-00 (R04)	20.00
Charles at 11114 (49)	Margarian and	1041204	100,000
(Chippe)	the initial sectors.	3547,2454	1.57 (20)
 Mail growt CAUT (e84) 	Weight Street	2011.003	12,000
🚔 Build Processor System	Materialise N.V.	2040.000	10,7540
Standard Build Processor	Materialise N.V.	30-01-2004	74,4,460

3.4. Licensing

Once Materialise Magics software and the Materialise MPM Build Processor have been successfully installed, you will need to license it.

The Materialise MPM Build Processor performs a license check when:

- Preprocessing (slicing) a job
- Uploading a job
- Calling BP functions from within Magics

The system which will perform any of the above functions should therefore have a valid license when doing so.

For information about licensing Materialise software please refer to the Frequently Asked Questions on the Materialise website:

http://software.materialise.com/frequently-asked-questions-materialise-software



4 Build Processor machine management: The Basics

4.1. Access the Build Processor Manager

The Build Processor Manager is the main application for managing and configuring your 3D printers and their settings and profiles.

Therefore, you need to navigate to the Build Processor Manager, which you can find



 by going to your Windows[®] operating system *Control Panel* and clicking on Build Processor Manager

Control F	Panel 🕨 All Control Panel Items 🕨		👻 🍫 Search Contro
Adjust your compute	er's settings		View by:
·	(b) 1010000000000000000000000000000000000	No and	States.
Build Processo	or Manager	🔩 Configuration Manage	e 🛛 📳 Content

by double clicking the tray icon in the right of your taskbar



<u>Note</u>

Depending on your Windows® operating system settings, this icon might not be permanently visible and hidden behind the arrow shown in the screenshot above.



BP Manager Toolbar



This BP Manager Toolbar contains the following control buttons:

🛉 Add a 3D Printer	This button is system	s used to add a ne	ew 3D printer (local or ne	etwork) to your
•	Refresh the	list of installed prir	nters.	
	Change the Manager.	way in which the p	printers are shown in the	Build Processor
	Details	Shows all added	printers in a list.	
		Printers can be s Build Jobs, Desc Model and Netw entry in the men	sorted by <i>Name, Status,</i> cription, Printer Location, rork Location by left click u bar.	<i>Queue Status,</i> <i>Manufacturer,</i> ing the according
	i≡ Contents	Combination of <i>I</i>	Details and Tiles option:	
		Standard Machine Local Standard Machine	— N/A	0 build job(s) waiting 0 local preprocess job(s) waiting 0 remote preprocess job(s) waiting
		An icon and info without sorting o	rmation regarding the pri ption.	inter is shown but
Default alignment of all added printers. Printers are sho as separate big icons including their <i>Name</i> , <i>Printer</i> <i>Location</i> and <i>Status</i> .				
	Opens a me	nu selection:		
	4	Troubleshooter	Generate a report. This assist you in collecting information about the s BP System. No person is collected; you can ve contents of the report b generated Cabinet (.ca	s tool will relevant status of the al information erify the by opening the b) file.
	Standard Build	Processor >	Opens the user manua Materialise MPM Build	l of the Processor
		About	Opens new window con information about the E Processor system vers Copyright of Materialise	ntaining Build ion and e.



9

. Options			-	
General				
Shov	v tray icon			
Start	when Windows starts			
Notificatio	ns			
Level: In	formation 🖌			
Shov	v printer notifications			
Shov	v job notifications			
Storage Location:	C:\ProgramData\Mate	erialise\BuildP	rocessorS	ystem
Size:	800 MB	chanse (build Fi	100055015	ystem
	nge Storage Location	Clean	Storage.	
Cha				
Cha				
Cha Language				
Language Change U	l language	-		
Language Change U	l language	٩	Change	Language
Language Change U	l language	6	Change	Language

Open the Build Processor System options window



4.2. Add a Local BP Machine

1. Open the Build Processor Manager. Click the *Add a 3D Printer* button in order to register a device in the System. When no machines have been installed yet, this button will also be visible in the center window region.

SU Printers			X
🐈 Add a 3D Printer	5	11 v	· 🔺
No 3D Printers installed			
💠 Add a 3D Printer			
0 printer(s)			



2. The following dialog will appear. Choose the machine type of which you want to register a new instance and hit the *Add*-Button:





3. A window will appear, allowing you to define your new printer properties. Please check if the correct version of the Materialise MPM Build Processor is selected in the Build Processor dropdown menu.

Installing 3D Print	er	
Add 3	D Printer	
Manufacturer:	Materialise N.V.	
Model:	Standard Machine	
Network Location:	Local	
Name:	Standard Machine	
Build Processor:	Standard Build Processor	
Description:	Example: Use for small parts only	
Printer Location:	Example: Main production hall	
		Back Add Cancel
· · · · · · · · · · · · · · · · · · ·		

<u>Note</u>

Most of the printer properties can always be changed afterwards, in the Printer Properties window.

The following printer properties can be set:

Name	An appearance name for the printer
Build Processor	Select the appropriate Materialise MPM Build Processor driver version
Description	A description of the printer's main functionality (optional)
Printer Location	A description of the printer's physical location (optional)

Click the Add button to proceed.

4. The *Launch configuration after install* option is enabled by default and will take you to Build Processor Configuration window after pressing the Close button.



Installing 3D Printer		
installing	Standard Machine	
🕅 Install Printer	Printer was successfully added.	
Launch configuration	after installation Close Cancel	

5. You need to select an upload directory, which is the default location for the Materialise MPM Build Processor output for the machine you just registered. This folder should have a distinctive name so that you can easily identify the output later.

Configure Printer	_	×
materialise Configure Printer		
Machine Configuration Profile Editor		
Profiles : 🛛 Allow Remote Clients to Edit Profiles		
Connection mode : No Direct Machine Communication		~
Upload folder : C:\Users\		 ~

6. Once everything is configured, you can see the machine in the Build Processor Manager. If you decide to change the machine's configuration, you can select the machine you want to change and hit the *Configure* button in the Manager panel. For more information see also section 4.5: Configure a BP Machine on page 27.



4.3. Add a Network BP Machine

With the Build Processor System, it is possible to work with network machines. This allows multiple users or workstations to connect to the same Build Processor machine, sharing and syncing its settings and profiles.

3D Printers Workstation #2 ~ Machine 2 on Machine 1 on N/A Sync Sync X 3D Printer Workstation #1 0 - 3 5 Machine 1 Machine 2 _ _ N/A N/A 0 build inbs

Workstation #1 machines added as network machines on Workstation #2:

Adding a network Materialise MPM printer is similar to adding a Materialise MPM local printer. The only difference is the screen where you select your Materialise MPM printer:

1. Open the Build Processor Manager and click the Add a 3D Printer button.





2. Pick Network rom the search location drop-down list.



In the Host entry field, enter the 'Network Location' of system which has the local printer installed. The name of this 'Network Location' can be found in the Printer Properties window (see also section 4.6: Access the BP Machine Properties on page 30) of the network printer. Next to this field you can define the port to be used for communication with the specified 'Network Location' – this is *45118* by default.





4. Press the Tefresh button to search for printers in this network location.

Add 3D Printer		×
Add 3D Printer	_	
Search Location: Network Y Host: Port: 45118		÷. •
	Add	Cancel

5. Select the desired network printer(s) and click the Add button to proceed. Multiple printers can be selected (using CTRL) and added simultaneously.

Add 3D Printer				×	
Add 3D Printer					
Search Location: Network 🛩 Host:	Port:	45118	Ð	-	~
Standard Machine on Materialise N.V. Standard Build Processor					
			Add	Cancel	



6. A window will appear, allowing you to define your new printer properties. Please check if the correct version of the Materialise MPM Build Processor is selected in the Build Processor dropdown menu. Click the *Add* button to proceed.

Installing 3D Print	er	
🐴 Add 3	D Printer	
Manufacturer:	Materialise N.V.	
Model:	Standard Machine	
Network Location:	and the second se	
Name:	Standard Machine on	
Build Processor	Standard Build Processor 👻	
Description:	Example: Use for small parts only	
Printer Location:	Example: Main production hall	
		Back Add Cancel

7. The Launch configuration after install option is enabled by default and will take you to the client terminal window after pressing the *Close* button.

Installing 3D Printer		
installing	Standard Machine on	
 Install Printer Configure Printer 	Printer was successfully added.	
Z Launch configuration	after installation	Close



8. The upload directory is predefined and not editable. Pressing the *left* button will take you to the User Guide. Once everything is configured, press the *OK* button.



9. The selected network printer(s) should now be visible in the Build Processor Manager.



<u>Note</u> Depending on whether the option to 'Allow Remote Clients to Edit Profiles' is enabled on the host machine, remote clients will be able to edit the profiles of the network machine. See also section 4.5: Configure a BP Machine on page 27.



25

4.4. Remove a BP Machine

In order to remove a BP machine, you can

- Select the BP Machine you want to remove and click the "Remove" button in the BP Manager Toolbar
- Right mouse click on the desired BP Machine and select Remove

3D Printers	Tapan .	S	No. of Concession, Name	
💠 Add a 3D Printer 📄 Open Queue 💈	Properties 🔨 Configure	💢 Remove	ર	: • % 🔞
Standard Machine Local N/A 0 build jobs	Show Queue Show Dashboard Configure Remove		-	
1 printer(s)				





4.5. Configure a BP Machine

The Machine Configuration window can be accessed by either

- Selecting the desired BP Machine and clicking the Configure button
- Right mouse click on the desired BP Machine
- and selecting the Configure option



The *Configure Printer* window contains the tab *Machine Configuration* and *Profile Editor*. The *Machine Configuration* tab contains the following options:

Sconfigure Printer		-		×
materialise	Configure Printer			
Machine Configuration	Profile Editor			
Profiles :	Allow Remote Clients to Edit Profiles			
Connection mode :	No Direct Machine Communication			~
Upload folder :	C:\Users\ayablokova\Documents			~
Use Inspector				
Path To Executable :	C:\Program Files\Materialise\Inspector 2.0\Inspector.exe			✓
Help :	0			
Licenses			ок) С	ancel



Allow Remote Clients to Edit Profiles	Depending on whether this option is enabled on the host machine, remote clients will be able to edit the profiles of the network machine. See also section 4.3: Add a Network BP Machine on page 21.
Connection mode : No Direct Machine Communication 💙	Via thus combo box user can choose between two connection modes. Materialise Control Platform users choose for "Use Materialise Control Platform" (for more information see section 4.5.1: Materialise Control Platform users on page 28) other users choose for "No Direct Machine Communication"
Upload folder :	Specify the output location of your processed build jobs. An icon indicates whether this upload folder is at a valid location.
	🗙 = invalid 💙 = valid
	In case of network folders, please pay attention to the 'Technical Requirement' below.
	Opens the user manual for the Materialise MPM Build Processor
Licenses	Open the license manager for the Materialise MPM Build Processor. This manager allows you to view your SystemID and register new licenses.
ОК	Saves user settings and profiles
Cancel	Closes "Configure Printer" window without saving user settings

Technical Requirement

If the chosen 'Upload folder' is located on a different computer, please ensure that the folder permissions include read/write access to your computer. For more information, please refer to section 14.2: How to grant a computer read/write access to a network folder on page 118.

Alternatively, you can run the BP Service under a different user account, as is shown in section 14.3: How to run the BP Service under a different user account on page 123

For details on the Profile Editor tab please refer to section 6: Usage of Profile Editor on page 45.

4.5.1 Materialise Control Platform users

Materialise Control Platform user connection settings become visible when "Use Materialise Control Platform" connection mode is selected. You need to connect with your Materialise Materialise MPM BP to the Materialise Control Platform. For the connection to be successful, you have to:

enter the IP address





- enter your FTP Username and Password
- press "Sync" button

Connection mode :	Use Materialise Control Platform
Server IP Address :	127.00.1
FTP Username :	
FTP Password :	
	Sync
Upload folder :	C:\Users\ayablokova\Documents

As soon as you are connected, BP will retrieve machine configuration settings:

- Build Envelope dimensions
- Scan system structure including scan field IDs, positions and dimensions (for Multi Field Setup)
- Laser Power, Speed and Diameter ranges

Designated fields should appear as read only to the end user.

Machine configuration data is retrieved each time user presses "Sync" button. Time stamp indicates when user has retrieved machine configuration settings last time.

Connection mode :	Use Materialise Control Platform	~
Last Sync :	2/28/2017 3:15 PM	
-		Connection Settings Sync
Upload folder :	C:\Users\ \Documents	··· •

The fields are checked and compared again with a cashed data again automatically every time

- when you open/close the configure printer window
- when you save user profiles

If you've failed to retrieve machine configuration data, you will see a message similar to the one shown in the screen shot below. BP will also indicate the possible reason, why it has failed to retrieve machine configuration data.

Connection mode :	Use Materialise Control Platform	~
Failed to read configuration data :	127.841	
Reason :	Couldn't find Materialise Controller machine configuration data at the FTP server	
Last Sync :	2/28/2017 3:15 PM	
		Connection Settings Sync
Upload folder :	C:\Users\ \Documents	



29



4.6. Access the BP Machine Properties

In order to enter the 3D Printer properties window, either

- Select the desired BP Machine and click the *Properties* button
- Right mouse click on the desired BP Machine and select the *Properties* option



The 3D Printer properties window contains all details of your Materialise MPM BP Machine. The *Name*, *Description* and *Printer Location* field of the BP Machine can be arbitrarily changed.

3D Printer properties	
Name	Standard Machine
Description	
Printer Location:	
Network Location:	Manual and the control (local)
Build Processor:	Standard Build Processor
Build Processor Version:	
Build Processor Provider:	Materialise N.V.
Printer ID:	ali20598-Sec-41da-etec-895c94c999
Model:	Standard Machine
Manufacturer:	Materialise N.V.
	OK Cancel

<u>Note</u>

Do not change the version in the dropdown of 'Build Processor'. A loss of existing profiles and machine might be possible.



4.7. Change the BP Machine Platform Settings

Parameters regarding the support generation module (SG or SG+), platform size and other machine related properties can be defined in Materialise Magics software at the *Machine Properties* in the *Build Preparation* tab. Prior to accessing the Machine Properties a New Scene has to be created. To do so please press the button *New Scene* first, select the desired machine and click on *Machine Properties*.

9	11 12 13 1		*- 🚯	۹ 🔍 🕯	Quick	search (Shift+	Q)	
FILE	TOOLS FIXIN	IG EDIT	SCENE	S & MACH	INES	SUPPORT GE	NERATION	
		3	63		1			
New Scene	Create Scene from Modeler Scene	Add Part to Scene	Move Part To Scene	Duplicate Scene	Unload Scene	Machine Properties	Change Machine	Bui
		Scenes	1				Machin	ies

The settings will be stored in a *Magics Machine Configuration File* ('.mmcf' file format). This file exists for each Materialise MPM machine. When adding a new Materialise MPM machine to the Build Processor Manager a new .mmcf file will be added using default settings.

In case a new machine is added to the Build Processor Manager which should use an already existing set of machine parameters, the existing .mmcf file can be used for this new machine. This can be the case when the platform size is always different from the default size or when the same SG settings should be used for every machine.

For that, open the Build Processor Manager and select the machine with the profiles to be copied. Also select the machine whose configuration file you would like to replace with a new version and open the Printer Properties window for both machines (see section 4.6 Access the BP Machine Properties on page 30).

3D Printer properties	- 0 - X-
Name:	Standard Machine
Description:	
Printer Location:	
Network Location:	SREMLAPHHETZ (local)
Build Processor:	Standard Build Processor
Build Processor Version:	
Build Processor Provider:	Materialise N.V.
Printer ID:	aiQabhili-Sarz-43cki-arlac-fillScS4ci368
Model:	Standard Machine
Manufacturer:	Materialise N.V.
	OK Cancel

The Properties dialog shows the *Printer ID*, which is used to identify the correct machine folder.





Now, using the Printer ID, you can easily identify the correct machine folder. Therefore, navigate to the following directory:

%ProgramData%\Materialise\BuildProcessors\<Machine name>\<Version number>\<Printer ID>



If you have identified the right folder, you can now copy the .mmcf file from the original folder and replace the .mmcf file for the new machine.

Notification

Please make sure that the file you are copying has exactly the same name as the existing file.

Please also make sure that Magics is closed during the copying of the .mmcf file.



4.8. Change the BP System storage location

By default, the Build Processor System stores its configuration data and its temporary data used during job processing in a specific directory located in the Windows® operating system partition. You may choose a different directory if you wish to. To do that, you need to bring up the options dialog first:

— In the Build Processor Manager, click the tool icon:



— In the tray icon context menu, select the entry *Options*:



Either way, you will be shown the Options dialog. In that window, click *Change Storage Location*. A dialog will pop up, offering you the selection of a directory.

Advanced Show hidden jobs	
Storage Location: C:\ProgramData\Mater Size: 7,50 MB Change Storage Location	ialise\BuildProcessorSystem
Language Change UI language	😵 Change Language
	Apply Cancel





4.9. Access the BP Machine Job Queues

You can access the list of jobs associated with a given BP Machine by either

- selecting the BP Machine in the Build Processor Manager and then clicking Open Queue in the tool bar
- right mouse click on the desired BP Machine and selecting the Show Queue option
- double click on the desired BP Machine



The BP Machine queue window will then show up:

Standard Machine					
Properties 🖏 Configure 🗱 Purge Entire Queue			Ð		
Constant And Ard Machine (No description available) Standard LM Machine on Local		Status: N/A		() •	
			Build Jobs		
Name	Status	Progress		Preprocess Start	Time 🔻 Preprocess End Ti
				0 total, 0 running, 1) waiting, 0 failed, 0 finished
			Preprocess Jobs		
Name	:	Status	Progress		Owner
Na	jobs in queue. Use an ex	ternal 3D edit	tor (e.g. Materialise Magics) which su	upports the Build Processor to submit jobs.	

The job queues give an overview of all the jobs processed by the Materialise MPM Build Processor. There are two job queues: 'Preprocess Jobs' and 'Build Jobs'.



Preprocess Jobs

This queue shows information regarding jobs that are in the preprocess phase. You can get more detailed information on processing progress by hovering on the progress bar of the active job:

S Prepro	Ssing print job
	Preprocessing print job
	Slicing part 21 of 50 ("Part(21)") : (14622 / 40002) Progress: 21.67 %

Build Jobs

If the job was sent for '3D Build', the processed files from the 'Preprocess Jobs' queue will be sent to the 'Build Jobs' queue which gives an overview of all jobs that have been sent to the configured upload folder for this BP queue.

In case monitoring is enabled, this queue will also display the building progress for each job.

The columns of the job queues are customizable (through a right mouse click on the column headings) and can display the following information for each job:

Name	The name that was assigned to the job
Status	The status of the job, depending on the job queue:
	Preprocess Jobs: Preprocessing, Finished, Error, Paused
	3D Print Jobs: Waiting, Error, Paused
Progress	This will display either a progress bar or icons which show event start and end times when hovering over them
Owner	Displays the user who sent the job to the queue
Creation Date	This will display the date the file was transferred from the Magics to the AM machine
Preprocess Start Time	Displays the time the preprocess of the build job started
Preprocess End Time	Displays the time the preprocessing of the build job was finished
Output Directory	This will show the output path of the job folder when build setting is set to <i>Preprocess Only</i>





Input File	Shows the file path of the input JobInfo.xml data
Upload Time	Shows the time after the preprocess was finished and the build job was uploaded correctly into the section "Build Jobs"

The right click options for each job are the following:



	Start job	(Re)start the job (after pausing)			
	Pause job	Pause the job's current progress			
	Cancel job	Cancel the job's cu	urrent progress		
8	Remove job	Delete job from the job queue, any relevant data on MCS side will remain intact.			
×	Remove job	and MCS data	Delete job from the job queue including any relevant data on MCS side.		
		Forcibly	If a job hangs in <i>Cancelling</i> or <i>Deleting</i> state after asked to be removed (e.g. job owner is a remote client that is not available), this option removes the job regardless.		
W	Open the project file in Inspector*	Open the Inspector using the 2D MatAMX file (Export of 2D MatAMX must be activated)			
W	Open the job file in Inspector*	Open the Inspector using the job file			
6	Open Upload Folder	Open the folder where the processed job is sent to			


4.10. Configure BP Tray Notifications

Whenever the status of a build job or BP Machine changes, you will be notified via tray callouts as shown below:

The Tray Icon is able to provide BP Machine notifications:



And job notifications:



Clicking on these pop-up message will display the corresponding Build Processor window.

To configure the Tray Icon and its properties, go to the Build Processor System Options which is accessible via the BP Manager Toolbar or via the right-click menu of the Tray Icon itself. See also section 4.8: Change the BP System storage location on page 33 on how to enter the BP Options menu.





5 Build Processor and Magics

This section will guide you through a typical workflow, using Magics and the Materialise MPM Build Processor.

5.1. Create a Build Processor Scene

In Magics, go to the *Build Preparation* toolbar and click *New Scene*. A Change Machine dialog box will appear, where you can choose your Build Processor machine, e.g. *"B.Proc.: Standard Machine",* to load a platform using Materialise MPM Build Processor.

<u>e</u>				~ / ()) Q Q 🗛	8 🕅	
FILE	TOOLS	FIX	TEXTURE	POSITION	BUILD PREPAR	RATION	
New Scene	Create Scer Modeler S	he from Scene	Move Part To Scene Scene	Add Part to Scene	Duplicate Sce Save Scene Unload Scene	e	
	a	hange Mac	hine				23
		Select M Material Support Commen	achine B.I Profile St t	Proc.: Standard Mad	hine		• •
		R Plai Material	tform Parameters	minium			•
					(Ok Ca	ncel Help

In section *Platform Parameters* the material can be selected which should be used for this scene:

Platform Parameters				
Material Aluminium				

The material can also be changed later in *Platform Properties Configuration*.

The platform will now appear in your Magics workspace. You can import, fix and orientate all necessary parts as you normally would, followed by the usual positioning and support generation operations where needed.





5.2. BP Toolbar

Prior to sending a 3D print job from Magics to the Materialise MPM Build Processor, you must configure the job by adjusting *Platform Properties Configuration* to the parts you have placed in your Magics scene.

This features are listed in the toolbar of the active machine scene:



Furthermore the Profile Editor can be accessed via Magics.

👻 ⋟ Platform S	ettings	
Slice Profile	Default	
👻 🍞 🛛 Part Defau	It Settings	
Build Strategy Profile	Default	•

For details on the concepts please refer to section 6.1: Introduction and concepts on page 45.

5.2.1 Configure BP Printer



The Configure Printer window will appear with the possibility to change the Machine Configuration and the machine profiles at the Profile Editor (described in section 6: Usage of Profile Editor on page 45 and the PART 2 in this manual).





Configure Printer		-		×
materialise	Configure Printer			
Machine Configuration	Profile Editor			
Profiles :	Z Allow Remote Clients to Edit Profiles			
Connection mode :	No Direct Machine Communication			
Upload folder :	C:\Users\ayablokova\Documents			~
Use Inspector				
Path To Executable :	C:\Program Files\Materialise\Inspector 2.0\Inspector.exe			~
Help :	0			
Licenses			ок	anc

5.2.2 Platform Properties Configuration



Pressing the button *Platform Properties Configuration* the window *Configure Platform* will appear:

Configure Plat	form	
Configur	re Platform	
✓ Category Sel	ection	
Material	Aluminium	~
👻 ⋟ Platfor	m Settings	
Slice Profile	0.1 mm	•
👻 🍞 🛛 Part De	efault Settings	
Build Strategy Pr	ofile Part thin	•
		OK Cancel

This window allows you to assign settings used by the entire platform.



In section **Category Selection** the **Material** used for this build job can be selected. Depending on this selection the *Slice Profile* and *Build Strategy Profile* related to the selected material will be shown.

A Slice Profile can be selected at Platform Settings. All slice profiles of the selected Material are listed.

Select a Build Strategy used for all parts on the platform (scene) by default. The drop-down list in the section **Part Default Settings** contains all the **Build Strategies** which are

- available for the currently selected Material
- the same or a multiple of the slice thickness according to the selected Slice Profile

A specific profile can be viewed and edited by pressing the 🖉 button next to it.

<u>Note</u>

Any profile editing at this point is saved to the machine profiles file (and not just applied for this current platform).

This edit button will not be available in case you are working on a network machine, where remote profile editing is disabled (see section 4.3: Add a Network BP Machine on page 21).

5.2.3 Submit a Job (Build)



Once you made your settings, you can submit the build job to the Materialise MPM Build Processor using the *Build* button.

You will be shown the following dialog:

👍 3D Print			
🕂 Submit	a Job		
Select 3D printer:	Standard Machine	on Local 👻	
Job type:	3D build		
Job name:	Title	%	
✓ Job settings Queue Settings			
Initially pause	d		
Remove job from queue when finished			
Overwrite exist	ting files in output directory		
Configure 3D Printer)	Configure Job Submit Job	



This window allows you to set some general build settings, specific job settings and eventually submit your build job for further processing.

The dialog consists of three different sections

- General build settings
- Job settings
- Control buttons

General build settings

Select 3D printer:	Shows the selected E when loading the plat	3P Machine (usually the one that was chosen form)
Job type:	3D build	The build will be processed and the generated .job files will be placed in the upload folder of the selected BP Machine as specified in the window for this machine
	Preprocess Only	 Allows you to send the processed job to a custom output directory
Job name:	This name will appear of the subfolder (in the generated build files	r in the BP Machine's queue. It is also the name e specified upload folder) containing all the
	This butto	n allows adding tags to the iob name (such as
	current da	te) which will be resolved upon job generation
ob settings	current da	te) which will be resolved upon job generation
ob settings Initially paused	current da	te) which will be resolved upon job generation The job enters the 'Preprocess Jobs' queue in a paused state. It needs to be manually turned to waiting before it will start
ob settings Initially paused	current da	te) which will be resolved upon job generation The job enters the 'Preprocess Jobs' queue in a paused state. It needs to be manually turned to waiting before it will start The job enters the queue in a waiting state. It will automatically start when the queue is available
ob settings Initially paused	when finished	te) which will be resolved upon job generation The job enters the 'Preprocess Jobs' queue in a paused state. It needs to be manually turned to waiting before it will start The job enters the queue in a waiting state. It will automatically start when the queue is available When the job is finished, it is automatically removed from the queue



Overwrite existing files in output directory	This o Only'	option is only available when 'Preprocessing is selected as a Job type.
	V	Overwrite any previous files if a job with the same name already exists in the specified output directory
		Create a new folder in the specified output directory, regardless of any existing folders.

The visibility of this menu can be toggled by clicking the
rightarrow button. It is hidden by default.

Control buttons

Configure 3D Printer	Opens the Configure Printer window for the selected BP Machine
Configure Job	Open a window that provides an overview of the current job configuration. It is still possible at this point to change these settings if necessary.
	<u>Note</u>
	Any changes made at this point will be taken into account when submitting the job, but will not be saved back to the Magics session.
Submit Job	Submit the job to the BP Machine Queue. A message will appear informing whether the job was successfully sent

You can check the job progress in the corresponding BP Machine Queue (see section 4.9: Access the BP Machine Job Queue on page 34) or stay informed using the BP Manager Tray notifications (see section 4.10: Configure BP Tray Notifications on page 37).



5.3. The Build Output

The generated output files for each machine are uploaded to the predefined *Upload folder* as specified in the machines' Printer Configuration. The job will also appear in the BP Machine queue, where it can be opened using the 'Open Upload Folder' option in the right click context menu of the job entry.

The files generated upon submitting a job are:

Platform.MatAMX	A Materialise AM Exchange file (file ending *.matamx) will be created containing the 3D STL parts of the Magics scene. It can be opened using Materialise Software.
	The option to output this file can be toggled on or off (see section 7.1: Export on page 60).
SliceStacks.MatAMX	A Materialise AM Exchange file (file ending *.matamx) will be created containing the 2D slice data.
	The option to output this file can be toggled on or off (see section 7.1: Export on page 60).
.job file	These files contain the binary data (which includes all geometrical data and vectors to be scanned) for each part. Also it contains all data to guide the building process. This file can be loaded and interpreted by the machine control software.



6 Usage of Profile Editor

6.1. Introduction and concepts

The outcome of a 3D build job generated by the Materialise MPM Build Processor depends on different parameter groups, each of which has a well-defined scope:

- Machine Settings
- Material
- General
- Slice Profile
- Build Strategy

The following diagram illustrates how these types relate to each other:





6.2. Launching the Profile Editor

The Profile Editor is located in the Configure Printer window. It can be opened either via the Build Processor Manager or Magics.

Via Build Processor Manager

Right mouse click on the desired BP Machine and selecting the *Configure* option or
 Select the desired BP Machine and click the *Configure* button



Via Magics



Either way, you will be shown the Build Processor Configure Printer window. Click on the *Profile Editor* tab to access the Profile Editor.





Configure Printer		-	×
materialise	Configure Printer		
Machine Configuration	Profile Editor		
Profiles :	Allow Remote Clients to Edit Profiles		
Connection mode :	No Direct Machine Communication		~
Upload folder :	C:\Users\ayablokova\Documents		 ~
Use Inspector			
Encrypt Job Files			
Help :			
Licenses		Ok	ancel

This will finally bring up the Profile Editor:

Sconfigure Printer	_		×
materialise Configure Printer			
Machine Configuration Profile Editor			
💾 Save 🔁 Import 🕞 Export			
Machine Settings			
Material: Titanium 🗸			
General			
Slice Profile			
Build Strategy			
Licenses	0	K Ca	ncel



6.3. General usage of the Profile Editor

The Profile Editor allows you to define profiles, which describe different aspects of the building process with a defined set of parameters. These profiles can later be accessed from within Magics when sending the build job to the BP Machine.

6.3.1 Selecting a profile for editing

To edit a profile, click onto the corresponding entry in the list located on the left hand side of the editor. The panel on the right hand side will then show an initially collapsed tree structure for the chosen parameter categories.

S Configure Printer				-	o ×	
materialise Configure Printer						
Machine Configuration Profile Editor	_					
🗎 Save 🕑 Import 🕞 Export						
Machine Settings	Gener	al		▷ Exp	and All	•
Material: Titanium 👻	▼ Mate	rial Defaults			•	
General	s	lice Profile	0.05 mm	*	•	
Slice Profile	В	uild Strategy Profile	Pyramid-2	~	•	
Build Strategy	▼ Scan	ning Order			•)
	▼ B	uild Order			•	
		Build Order Mode	Platform	*	•)
	Þ	Vector Types Order		Sort	•	
	▼ S	orting Against Gas Flow			•	
		Enable	2		\$	
		Sorting	Per Platform	~	\$	
		Supports			•	
		Enable Support Vector Sorting	M		e ()
Licenses	-			ОК	Cancel	

The Slice Profile and Build Strategy categories need to be expanded by clicking on the small triangle left to the section name followed by clicking on the profile name before showing the parameters on the right hand side:



Materialise MPM Build Processor User Manual

Sconfigure Printer		- 0	×
materialise Configure Printer			
Machine Configuration Profile Editor			
💾 Save 🕑 Import 🕞 Export	C		
Machine Settings	Name : 0.03 mm	▷ Expand	d All 🔊
Material: 🚺 Titanium 🗸	Slice Thickness 0.06	500 mm	၈ ()
General	 Fixing Options 		•
▼ Slice Profile	Unify Slices 🛛 🛛		গি 🚺
0.03 mm	Gap Fill 🔳		()
0.05 mm	 Optimization Options 		(
Build Strategy	Point Reduction		(
	Contour Filter		\$
Licenses	<u> </u>	ОК	Cancel

6.3.2 Editing profile names

Name :	Build Strategy 1	Ð

In the field *Name*, a name for the Slice Profile / Build Strategy can be defined to identify it in the Profile Editor, for profile import and export and during assigning it to the platform and parts.

6.3.3 Expand and Collapse All

To expand or collapse all nodes press the button Expand All / Collapse All

Expand All
 Expand / Collapse Parameters
Expand all parameters within this profile group.

6.3.4 Modifying parameters

By selecting a parameter category on the right hand side of the Profile Editor, the corresponding parameters to this category will appear. Here you can edit the parameters as needed.





Each parameter is identified by:

- A concise description of the parameter
- An entry field, checkbox or dropdown list (with a validity check where needed)
 - A button, which resets the parameter value to its factory default
- 🤨 Tooltip which provides information on the corresponding parameter upon hovering

6.3.5 Getting information about parameters

Some parameters offer a 'tooltip field' next to their editing components, represented by the symbol ¹:

Name : Default	Expand All
Slice Thickness 0,1000	mm 🔊 🚯
Fixing Options	Slice Thickness
 Optimization Options 	Defines the hight of each layer on a build platform level.
Point Reduction	A

Moving the mouse pointer onto these elements will trigger the display of a tooltip.



50

6.3.6 Resetting parameters to their default values

In case you want to reset parameters to their factory default, click the following button next to the element you want to reset:

<u>Warning</u>

All parameters will be reset to their defaults. This operation can't be undone. Press *Cancel* to undo this operation and default settings will not be saved.





6.4. Creating and editing Materials

The Profile Editor offers buttons to edit the set of materials:

Configure Printer	
Configure Printer	
Machine Configuration Profile Editor	
E Save D Import De Export	
Machine Settings	
Material: Aluminium 👻	
General	
Slice Profile	
Build Strategy	
Licenses	OK Cancel

The materials can be defined in the *Material* field at the left hand side of the Profile Editor.



The following buttons will be shown by hover the mouse above the *Material* field:

- +1Add a new material that contains the factory default profile
- X
 - Delete the current material
- P

0

- Rename the selected material
- 0
 - Set the selected material as default material

Create a copy of the selected material



6.5. Creating and deleting Profiles

In the Materialise MPM Build Processor two profile categories are existing: Slice profiles and Build Strategies. In these categories several profiles can be added which can be used to assign them to parts (via Magics, see section 5: Build Processor on page 38) and define the way in which they must be hatched and consequently scanned by the machine.

To edit a profile, e.g. a Build Strategy profile, click onto the triangle left to the entry *Build Strategy* in the list located on the left side of the editor. The panel will show all existing profiles of the category 'Build Strategy'.

⊳	Slice Profile
Ŧ	Build Strategy
	Part default
	Part thin 0.5
	Part with downskin 0.05
	Support

Clicking on one Build Strategy, e.g. 'Part thin 0.5', will show all parameters related to this profile on the right hand side.

Besides editing the Build Strategies on the right hand side you can also create new Build Strategies.

There are two ways of creating Build Strategy profiles: either clone an existing one or create a new one based on the factory default.

6.5.1 Creating Build Strategies by cloning existing Build Strategies

If you want to base a new profile on an existing one, do as follows:

Move the mouse pointer onto the entry of interest. Two buttons will then be shown. Use the

to create a new Build Strategy:

▼ Build Strategy		 Rescaling
Part with downskin 0.05		Scale
Part default		Scale
Part thin 0.5	+×	Scale
Support	Duplicat	e
	Duplicate	e this profile

+

The *Duplicate* button will add a copy of the selected material. It will contain one build strategy with the same name and the prefix *copy of*, in this case consequently 'copy of Part thin 0.5'.



You can change the automatically created name using the text box in the upper right of the editor window. See also section 6.3.2: Editing profile name on page 49.1.

6.5.2 Creating Build Strategies based on factory defaults

The 'factory default' is an inbuilt template profile that cannot be altered by any user. To create an instance of that profile, move the mouse pointer onto the *Build Strategy* entry and

click onto the 时 button that appears while hovering on the entry:



This will add a new material. It will contain a new Build Strategy called 'copy of Factory Default' containing default values which needs to be adjusted by the user.

Warning

The new Build Strategy contains default values which need to be adjusted by the user. The given values may result into bad build quality or build errors. Please adjust them.

You can change the automatically created name using the text box in the upper right of the editor window. See also section 6.3.2: Editing profile name on page 49.

6.5.3 Deleting Build Strategies

+

X

Build Strategies can be deleted by moving the mouse button onto the corresponding entry and clicking the *solution*.

Ŧ	Build Strategy	
	copy of Factory Default	X
	Part default	Remove
	Part thin 0.5	Remove this profile
	Part with downskin 0.05	

This will delete the current Build Strategy profile.

<u>Warning</u>

This will delete the Build Strategy profiled. Click *Cancel* if you do not want to save these changes and to udo the action.



6.6. Exporting and importing build parameters

The options for exporting and importing Build Processor parameter profiles can be found at the upper part of the Profile Editor. By doing that the entire or a subset of the existing parameters can be stored on an external location and/or transferred to another Materialise MPM Build Processor machine. The file format for the Build Processor parameter profiles is .bpprof (Build Processor Profile).

With the following buttons Build Processor parameter profiles can be exported and imported:

Configure Printer			
Configure Printer			
Machine Configuration Profile Editor			
💾 Save	🕤 Import 🕞 Export		xport

6.6.1 Exporting build parameters

Clicking the Export button will bring up a dialog in which you can specify the items to export:

Export	
Configure export	
Export format	
Build Processor Profiles File	~
Generic parameters Export generic parameters	
Materials:	
Select the categories to export.	
Select all items in this category	
Default	
Aluminium	
Export.	Close

- For each Material you want to export, check the corresponding checkbox.
- If you only want to export a subset of a Material's items, click onto the tool icon subset to Material entry and select the items you wish to export:





Clicking *Export...* will prompt you to specify a name and a location for the export file. Once such a file is created, it can be used for import later on.

6.6.2 Importing build parameters

Clicking the ^{TIMPORT} button will prompt you to select a file to be imported. After that the application will show you a dialog in which you need to clarify the following issues:

- Which elements of the file shall be imported?
- How shall the importer behave in case of naming conflicts?

Import profiles
Select the categories to import
Z Aluminium
General machine settings
•
✓ Advanced
Behavior in case of naming conflicts for categories
 Import and keep both Import and merge Don't import
Behavior in case of naming conflicts for profiles
 Import and keep both Import and replace Don't import
OK Cancel





The section labeled *Select the categories to import* offers you a list with the Materials found in the file.

As it is possible that naming conflicts arise – that is, if Materials. Slice Profiles or Build Strategies in the import file have got the same names like the ones already present in the database – you may define special behavior for that case in the section labeled *Advanced*.

Behavior in case of naming conflicts for Materials (Categories)

Let's assume your current database already holds a Material called *Aluminium* and now you are about to import a file containing a Material with the same name. The outcome of such a situation depends on the setting defined for that case:

Import and keep both:

The item from the import file will be added as a new item to the set of Materials but its name will be suffixed with *(Imported copy)* just so you can tell them apart.

Import and merge:

The Build Strategies contained in the Material to import be added to the set of Build Strategies of the existing Material but their names will be suffixed with (*Imported copy*) just so you can tell them apart.

Don't import:

The entry from the import file will just be ignored.

Behavior in case of naming conflicts for profiles

Similarly, naming conflicts with Build Strategies may arise. In that case, three strategies for resolving are available:

Import and keep both:

The item from the import file will be added as a new item to the 'parent Material' but its name will be suffixed with *(Imported copy)* just so you can tell them apart.

Import and replace:

In this case, the existing Build Strategy will be replaced by the one from the import file.

Don't import:

The entry from the import file will just be ignored.



<u>Warning</u>

As the import function can't be undone it is recommended to save the existing parameters before importing.

This can be done by exporting the parameters into a temporary location.





PART 2 is designed as a library.

The explanations of all features and functions of the parameters in the Profile Editor can be consulted in this section.

As already mentioned in section 6: Usage of Profile Editor on page 45, the Profile Editor is separated into different parameter groups:

- Machine Settings
- General
- Slice Profile
- Build Strategy

This chapter gives a detailed description of the parameters associated to those groups and gives an extensive overview of their purposes.



7 Machine Settings

In the Machine Settings, one can configure Export options and Gas Flow settings.

Click onto the entry *Machine Settings* on the left side (as shown in yellow in the screenshot below):



The Machine Settings are shared between all Material profiles, meaning that the machinespecific settings are applied independently on what Material, Slice Profile and Build Strategy are selected. For instance, one can't set the gas flow angle separately for materials and build strategies as this parameter is tied to a physical machine only.

7.1. Export

The native export format of the Materialise MPM Build Processor is the .job file format which gets exported with every build job.

However additional export files are available which can be enabled or disabled in the export section.

Parameter	Description
Enable 3D MatAMX output	The file <i>Platform.MatAMX</i> will be created containing the Magics scene with the 3D STL parts. It can be combined or not combined with other STL data for creating a new job with the same or different settings.



Enable 2D MatAMX output	The file SliceStacks.MatAMX will be created containing the
	2D slice data of the build job. This data can be imported into
	Magics or Inspector for slice inspection.

7.2. Part Placement Check

Part Placement Check consist of out of bounds and collision check. Both out of bounds and collision check happens upon job preprocessing. Out of bounds check allows to verify if parts and/or supports on the platform exceed Build Envelope bounds. If that is the case preprocessing fails and doesn't allow user to upload the job. While out of bounds check is always activated and hardcoded, collision check can be activated or deactivated by user.

•	Part Placement Check	\searrow

Perform Collision Detection 🛛 💆

Parameter	Description
Perform Collision Detection	If activated parameter allows to verify if any parts in the build envelope are colliding. Collision detection is applied only for parts and not for supports . If Perform Collision Detection checkbox is OFF, collision check will not be carried out which will considerably decrease preprocessing time.

7.3. Gas Flow

If Sorting Against Gas Flow is enabled the gas flow direction determines the scanning order and direction of scan paths (hatch vectors) as well as the scanning order of parts, part regions and supports on the platform. For more information about sorting against gas flow, please, refer to the chapter 12.2 Sorting Against Gas Flow on page 109.

•	Gas Flow			P
	Angle	90.0000	۰	•

Parameter	Description
Angle	The Gas Flow Angle is measured from a line anticlockwise. Angle 0° defines the gas flow direction from right to left.





7.4. Build Envelope

This section is to fill in Build Envelope settings. If BP uses Materialise Control Platform, these settings will be automatically retrieved from FTP server and the whole section will be available as *read-only*.

 Build Envelope 			P
Platform Shape	Rectangle 🗸		२
Position X	0.0000	mm	२
Position Y	0.0000	mm	၈
Position Z	0.0000	mm	P
Size X (Width)	260.0000	mm	n
Size Y (Depth)	260.0000	mm	P
Size Z (Height)	320.0000	mm	२

If these settings are different from those in Build Preparation/Machine Properties in Magics, user will be asked to accept or to decline changes in Magics.

Magics		×
?	Machine parameters were changed. Do you want to apply new parameters to current Job or keep o unbounded from BP)?	urrent parameters (scene will be
		Accept Decline

Reverse changes from the Machine Properties in Magics to the BP are not possible.

Parameter	Description
Platform Shape	With this combo box user can choose among circular and rectangular platform.



Position (X, Y, Z)	Rectangle Image: Circle The X, Y and Z coordinates are used to define position of the Build Envelope (the bottom corner for the rectangular platform or the center point for the circular platform) in WCS.
Size X (Width)	Define here the width of the platform in X direction.
Size Y (Depth)	Define here the depth of the platform in Y direction.
Size Z (Hight)	Define here the height of the platform in Z direction.

8 General

The parameters shown in the *General* will be applied on the entire platform and therefore they are not part specific. In this section user can define settings for:

- Material Defaults
- Scanning Order

Click onto the entry General on the left side (as shown in yellow in the screenshot below):



Configure Printer			- 🗆 ×
materialise Configure Printer			
Machine Configuration Profile Editor			
💾 Save 🔮 Import 🕒 Export			
Machine Settings	General		▼ Collapse All
Material: Titanium 🗸	 Material Defaults 		•
General	Slice Profile	Default-1	•
Slice Profile	Build Strategy Profile	Torus 5 🗸	•
Build Strategy	 Scanning Order 		•
	 Build Order 		•
	Build Order Mode	Region 🗸	
	Vector Types Order	Sort	• U
	 Sorting Against Gas Flow 		\$
	Enable	V	(
	Sorting	Per Platform 🗸	•
	▼ Supports		\$
	Enable Support Vector Sorting	V	ب 🜔

8.1. Material Defaults

In the *Material Defaults* user can set default profiles applied on the platform and part level:

- Slice Profile (applicable on the platform level)
- Build Strategy Profile (applicable on the part level, however, in the current BP only one Build Strategy profile can be selected for all parts on the platform)

Those default profiles are preselected upon opening the *Configure Platform, Configure Job and Configure Parts* dialogs in Magics. The user can select among all the profiles defined in the Profile Editor under *Slice Profile* and *Build Strategy* sections in the *Configure Platform* in Magics:

•	Material Defaults		
	Slice Profile	0.1 mm	~
	Build Strategy Profile	Part thin 0.5	~



Materialise MPM Build Processor User Manual

Configure Job		_		×	
materialise	Configure Job				
 Category Select 	ion				
Material	Titanium		~		
🗸 ⋟ Platform	Settings				
Slice Profile	0.1mm		~		
✓					
Build Strategy Profil	e Thin part		~		

Configure Platfor	m	-		×
materialise	Configure Platform			
← Category Selection	on			
Material	Titanium		~	
🛩 ⋟ Platform S	ettings			
Slice Profile	0.1mm		*	
	(
🛩 🧊 Part Defau	It Settings			
Build Strategy Profile	Thin part		~	
		ОК	Can	icel



65

8.2. Scanning Order

At Scanning Order the build order of regions (closed part contours) and vector types can be defined. The build order determines the order in which the regions and supports are scanned.

•	Sc	anni	ng Order		P	0
	•	Bu	ild Order		P	0
			Build Order Mode	Region	P	0
		⊳	Vector Types Order	Sort	•	
	•	So	rting Against Gas Flow		P	0
			Enable	2	\$	0
		•	Supports		P	
			Enable Support Vector Sorting	2	\$	0

For detailed information please see section 12 Scanning Order on page 106.



9 Slice Profile

In the Slice Profile the Slice Thickness and all other parameters in the section are defined on a platform level (applicable to all parts on the platform), however, the settings related to geometric fixing and optimizing of slice geometries will be applicable for a Slice Thickness defined in the Build Strategy section (Slice Thickness is assigned to each part separately).

Configure Printer			
Configure Printer			
Machine Configuration Profile Editor			
💾 Save Import 🕒 Export			
Machine Settings	Name : 0.1 mm		▼ Collapse All
Material: Aluminium 🖌	Slice Thickness	0,1000	mm 🔊
General	 Fixing Options 		•
▼ Slice Profile	Unify Slices		(
0.03 mm	Gap Fill	V	(
0.05 mm with unify slices	Maximal Gap Size	0,0000	mm 🔊
0.1 mm	 Optimization Options 		P
Build Strategy	 Point Reduction 		P
	Enable	Z	P
	Tolerance	0,0000	mm 🔊
	▼ Contour Filter		•
	Enable	V	(
	Min. Length Outer Contours	0,0000	mm 🔊
	Min. Length Inner Contours	0,0000	mm 🔊

9.1. Slice Thickness

In this field the slice thickness is defined on a platform level.

Slice Thickness	0.0300	mm 🔊 ()
The Part Slice ⁻ and has to be	<u>Note</u> Thickness defined in the Build S equal or multiple of the Slice Th (PST≥ST	trategy can be assigned on a part level nickness defined on the platform level).
Slice thickness in th	pe Slice Profile section should b	e mainly considered as a parameter which

Slice thickness in the Slice Profile section should be mainly considered as a parameter which allows to filter build strategies per slice profile. Build Strategy profiles can be combined with a Slice Profile only in the case they have the same or multiple Part Slice Thickness (PST). In order to combine the Build Strategy profile with a relevant Slice Profile the following condition should be satisfied: **Part Slice Thickness ≥ Slice Thickness**.

For example, user has created two Slice Profiles (SP):





SP with a slice thickness 0.05 mm and SP with a slice thickness of 0.03 mm.

User has also saved 4 Build Strategy profiles:

Box-1 (PST = 0.1), Box-2 (PST = 0.05), Pyramid-1 (ST = 0.06) and Pyramid-2 (ST = 0.03).

At the Configure Platform window of Magics when choosing Slice Profile 0.05 mm the user will see only Box-1 and Box-2 at the Build Strategy drop-down menu. When choosing the 0.03 mm Slice Profile the user will see only Pyramid-1 and Pyramid-2.

Configure Platform - C X					×
materialise	Configure Platform				
← Category Selectio	n				
Material	Titanium			~	
✓ ≫ Platform Se	ttings				
Slice Profile	0.05 mm			•	
✓	t Settings				
Build Strategy Profile	Box-1 Box-1 Box-2			~	
			ок	Car	ncel



9.2. Fixing Options

Part contours are checked for errors after the slicing process and can be repaired using the Fixing Options parameters.

•	Fixing Options		
	Unify Slices		
	Gap Fill	2	
	Maximal Gap Size	0,2000	mm

<u>Note</u> It can happen that settings given in Fixing Options lead to changes in the original geometry of the part.

Parameter	Description
Unify Slices	When the Unify Slices option is enabled, only the outer triangles will be preserved and all inner triangles will be discarded. This operation is performed on a slice-level per part and can be illustrated using the following example:
	For parts with a lot of internal intersections, unify will help you to make clean parts.
	Note
	Enabling this option introduces an additional operation during slicing, causing the process to take longer.
Gap Fill	The Materialise MPM Build Processor contains an open contour stitching algorithm. In the logical workflow, fixing operations will take place in Magics, prior to sending the job to the Build Processor. However, in case for example: the user does not attend to some poorly visible near bad edges, or does not check the part again for errors after performing certain operations; some open contours could still be present.







9.3. Optimization Options

With Optimization Options, the geometry of the part gets simplified for the process.

•	 Optimization Options 				
	•	Point Reduction			
		Enable	2		
		Tolerance	0,0000	mm	
	٠	Contour Filter			
		Enable	2		
		Min. Length Outer Contours	0,0000	mm	
		Min. Length Inner Contours	0,0000	mm	

Note	
Using Optimization Options can lead to changes in the original geome	etry of the part.

9.3.1 Point Reduction

The Point Reduction algorithm is used to reduce the amount of contour (border) vectors. It works by merging successive vectors that lay on one line (close enough within a given Tolerance). When enabled, it will reduce the file size of the resulting slices. Point reduction can also prevent rough surfaces on physical parts in extreme cases where digital part imperfections lead to a very high concentration of vectors (causing the machine software to steer the laser in such a way that there is a longer exposure time in this area of high vector concentration).

The algorithm can be illustrated graphically:





Note how the number of points reduces to produce 'cleaner' contours. The file size of the part slice stack is reduced accordingly.

9.3.2 Contour Filter

The Contour Filter algorithm takes the scanning limits of the 3D printing machine into account. Some features (on the digital model) have a detail which cannot be accurately reproduced due to physical limitations (machine HW, powder particle size ...). The Contour Filter allows the user to specify which of such features should be removed, based on the length defined by each contour.

•	Contour Filter		
	Enable	2	
	Min. Length Outer Contours	0,0000	mm
	Min. Length Inner Contours	0,0000	mm

Parameter	Description	
Minimal Length Closed Outer Contours	Closed outer contours, with a length smaller than this value, will be discarded.	
<i>Minimal Length Closed Inner Contours</i>	Closed inner contours, with a length smaller than this value, will be discarded.	




9.4. Side Note: The Build Processor fixing philosophy

Having open contours in your slices means that there is something wrong with the geometry of your original part, which can be visually checked and fixed in Magics beforehand. In this workflow, the Build Processor is not responsible for applying any geometric changes (for example: closing large gaps in open contours on a slice level, the results of which can be unexpected and would have to be verified slice-per-slice). The guarantee for the user is: a part that is geometrically correct (i.e.: no errors detected in the part analysis), will not have any unexpected results in their slices after processing as no geometric corrections on a slice level are required.

The diagram below illustrates the two different (fixing) workflows to obtain the desired slice result from a 'bad part':

- visually inspect slices slice OK if ix part in Magics SLICE Slice OK Slice OK
- 1. Force fixing on a slice level

2. Fixing on an STL level (in Magics)

Below is a comparison of the different (fixing) workflows:

1. Force fixing on a slice level	2. Fixing on an STL level	3. Advantage of workflow 2
Visual slice-per-slice inspection	No slice checking required	Save time
No 3D visual feedback of entire part after fixing	Fixing on 3D model gives visualization of entire part	Reduce chance for unexpected geometric changes in final part
Limited fixing options / control	Many (auto) fixing options	Improved control over final part quality
Bad results require to go back in the workflow anyway	Bad results are avoided earlier in the workflow	Save time



10 Build Strategy

The Build Strategy contains the description on how a part and supports should be built. This includes part slicing, scanning patterns, fill area hatch sorting styles and provides possibility to assign different laser parameters to each vector block. A Build Strategy can be assigned per part, meaning it can be applied to only one part or multiple parts, and consists of 4 sections:

- Slicing
- Rescaling
- Path Generation
- Scanning

Configure Printer		
Configure Printer		
Machine Configuration Profile Editor		
💾 Save Import 🕞 Export		
Machine Settings	Name : Part thin 0.5	Expand All
Material: Aluminium 💙	Slicing	•
General	Rescaling	•
Slice Profile	Path Generation	•
▼ Build Strategy	Scanning	•
Part default		
Part thin 0.5		
Part with downskin 0.05		
Support		

10.1. Slicing

•	Slicing		
	Part Slice Thickness	0,5000	mm
	Scan supports every	1	layer(s)

Parameter	Description
Part Slice Thickness	The Part Slice Thickness defines the height of each layer, i.e. the distance between two neighboring slices. In comparison with the Slice Thickness in the Slice Profile section which is applied on a platform level, this parameter is applied on a part level (see also chapter 9.1 Slice Thickness on page 67).







10.2. Rescaling

Shrinkage of a cooling part can be partially compensated by applying scaling factors to the part in X-, Y- and Z-direction. The scaling center can be set to the origin of the platform (X = 0, Y = 0, Z = 0) or to the center of a part. It defines relative to what point each part will be scaled.

▼ Rescaling		f
Scale Center	Platform Origin 🔹	\$
Scale X	Platform Origin	•
Scale Y	Center of Part	•
Scale Z	1.5000	•

The example below illustrates this using the factor of 1.5 in each direction. In the case of rescaling relative to **the platform origin** part collision after rescaling is avoided because parts are not only rescaled but also moved according to values defined by a user in X, Y and Z directions. Each coordinate is multiplied by 1.5. The white rectangles are the original parts. The dark purple rectangles visualize the resulting slice stacks after rescaling. However, it still may result in supports collision and/or out of bounds problem.



If rescaling relative to a Center of Part collision may occur if parts on the platform are positioned close to each other. The examples below illustrate this using the unrealistic factor of 2 in each direction.





Effect on Supports

The chosen rescaling profile affects all parts on the platform. All the corresponding supports are rescaled accordingly.



10.3. Path Generation

After the slicing operation is performed various build strategies can be generated to fill in layers with scan vectors (hatches). Different zones in the slices of a part require different scanning and hatching strategies. This is because the solidified slices can interact with the solidified material in different ways. This is dependent on the thermal stresses inside and in between the slices, the desired material properties (for surface and volume of the parts), and the orientation of the parts on the platform. Also the supports and the way how they are oriented and attached to the part are of crucial importance. Due to all these reasons it makes sense to assign own build strategies and scanning parameters to different zones of the part. To make it possible, each layer gets divided into 'Up Skin, 'In Skin', 'Down Skin' areas and 'Solid Supports'.

•	Path Generation	P
	Part Borders	•
	▷ Up Skin	•
	▷ In Skin	•
	Down Skin	•
	Solid Supports	(P)

The 'In Skin' is defined as the area between 'Up Skin' and 'Down Skin' areas. Defining an overlapping area between Down Skin and In Skin is used to ensure solid lamination of In Skin and Up Skin areas helping to avoid occurrence of tiny regions with untreated material.







10.3.1 Part Borders

The Part Border is a contour that surrounds the fill area, e.g. In Skin, Up Skin and/or Down Skin. It defines the outer surface of the part.



Fill Borders are generated to close gaps that are created when a hatch vector and a border converge. It glues together the hatches and the Part Border, and is often printed last, when shrinkage has mostly settled because of heat dissipation.



•	▼ Part Borders				
	Enable Borders	V			
	Beam Compensation	0,0500	mm		
	Number of Borders	1			
	Border Distance	0,1000	mm		
	Enable Fill Border	V			
	Fill Border Offset	0,0500	mm		
	Scan Order	In2Out	~		

Parameter	Description
Enable Borders	Enable or disable Part Border via the checkbox:



	Borders enabled		
Beam Compensation	This value compensates for the melting pool width. It determines an offset between the original slice contour and the outermost border to guarantee the correct build size of the part. Entering a value (e.g. 0.06 mm) will offset the outermost border to the inside of the slice contour as shown in the illustration below.		
	The inside of the side contour as shown in the indistration below.		
Number of Borders	Petermines the amount of borders to be generated		
Number of Bolders	Entering "1" will create one border		
	Entering "1" will create one border.		
	All higher numbers will increase the amount of Following Borders		
Border Distance	Defines distance between the borders. The distance between		
	following and Fill Border is not considered when defining this value.		
	Number of Borders		
	3 2 1 Border Distance Border Distance Beam Compensation		
	©		
Enable Fill Border	Enable or disable the Fill Borders via the checkbox: Fill Borders enabled		
Fill Border Offset	The distance between innermost Border and Fill Border. Consider		
	the Hatch Offset when defining this value.		





Start Point Relocation

Part Borders starting points are randomly distributed from one to the next layer to avoid visible marks on the part surface. If enabled, it is applied to the outermost, following and fill in border.

•	Start Point Relocation		
	Mode	Random	~

Two modes are available:



None: Start Point Relocation disabled



Random: Start Point Relocation enabled

<u>Note</u>

Only existing vectors are considered for the Start Point Relocation, no new vectors are inserted.





Optimization

Optimization will improve the quality of part borders in certain geometrical situations.

	Enable Optimization	
•	Optimization	
	Sharp Edges	
	Blocked Path	

Optimization has to be explicitly enabled to be generated.

<u>Note</u> Due to complex operations enabling this option extends the processing time significantly.

Sharp Edges

This feature helps to avoid uncovered areas at sharp edges during printing caused both by beam compensation issue and cone-shaped laser beam.

•	Optimization			
	•	Sharp Edges		
		Angle Threshold for Corners	0,000	•
		Correction Factor	1,0000]

Parameter	Description
Angle Threshold for Corners	The angle between two vectors is checked. Only angles below this value are considered for offset correction. Angles are defined in degrees.



Materialise MPM Build Processor User Manual

	Angle is larger than threshold angle¶ → No Sharp Corner treatment¶ Border Polygon¶ Threshold Angle¶ Sharp Corner¶ No Sharp Corner¶ No Sharp Corner¶	Angle is below threshold angle¶ → Sharp Corner is generated, Blocked Path can be inserted¶	
Correction Factor	This parameter defines the length of a segment that is additionally scanned in a corner between the original slice contour and the beam compensated Border.		
	In this process the whole co slice contour to the offset co Correction Factor value mu Laser Beam (Correction Fa	orner path (from the original ontour) gets shortened by the Itiplied by the Radius of the ctor*Radius Laser Beam).	









Blocked Paths

 Blocked Path 		•
Trim Blocked Paths	V	•
Trimming Threshold	0,0000	mm 🔊

A Blocked Path is a segment that is created in geometrically thin areas which would not be scanned at all. It helps maintaining the original geometry of the part that could otherwise not be realized because of physical limitations such as the beam diameter.



Blocked Paths enabled

Parameter	Description
Trim Blocked Paths	This feature prevents from generating too much material in geometrically narrow areas of additional Borders. It is applied only when more than one border is defined.
Trimming Threshold	 Defines part regions (thin walls) which are thinner than the given threshold. In these regions blocked path is trimmed. The smaller the threshold value the more Blocked Paths remain. If the Trimming Threshold value is larger than the Border Distance all Blocked Paths are removed. Segments of the outermost border are never trimmed.



85



The beam speed, power and diameter for the Blocked Paths can be set in the Scanning section.





10.3.2 In Skin

To fill inner areas of a layer, parallel scan vectors, called hatches, are generated.

•	In	Skin		
		Hatch Offset	0,0500	mm
		Fill Pattern Type	Stripes 🗸	
	⊳	Stripes Parameters		

Parameter	Description
Hatch Offset	The Hatch Offset defines the distance between the innermost border and the fill pattern.
Fill Pattern Type	In the drop-down menu, the Fill Pattern Type can be selected. Different patterns are possible:





Stripe Pattern

Is applied when selected from the Fill Pattern Type combobox.

Fill Pattern Type	Stripes 🗸	
 Stripes Parameters 		
Hatch Distance	0,0500	mm
Stripe Size	5,0000	mm
Stripe Offset	0,0500	mm
Hatch Sorting	Optimized Sorting 🛛 🗸	
Rotation Start Angle	0,0000	•
Rotation Increment	90,0000	•
Shift Factor	1	

The Stripe Pattern will sub divide the hatching area in stripes, filled with hatch vectors following a selected vector direction.

<u></u>	Slice Contour
	Stripe Partition







	Stripe Offset	3 2 1	
Hatch Sorting	Please see section 12.3	3.2 Hatch Sorting on pa	ge 110.
Rotation Start Angle	Hatch patterns can be r increment. This value d of the pattern starts.	otated each following s efines the initial start ar	lice with a defined ngle from which rotation
Rotation Increment	Defines the increment v consecutive layers.	alue of the rotation and	gle between
	Below, three subsequer works. The initial rotatic only In Skin is enabled)	nt layers demonstrate tl n is 120°, incremented	he way stripes rotation by 75° per layer (when
	120°	195°	270°_
	Layer 1: 120°	Layer 2: 195°	Layer 3: 270°
	If Down Skin is enabled Skin first layer as the se	Rotation Start Angle = cond layer.	195°, considering In
Shift Factor	The Shift Factor will res the original pattern posi being the value entered with the rotation in orde	ult in a shift of the entir tion will be reached afte . The shift factor can be r to perform a Reference	e pattern in y-direction; er <i>n</i> iterations, with <i>n</i> e used in combination ce Point Relocation.





Chess Pattern

In the drop-down menu, the Chess Pattern can be selected.

	Fill Pattern Type	Chess 🗸	
•	Chess Parameters		
	Hatch Distance	0,0500	mm
	Number of Vectors per Field	100	
	Field Offset	0,0500	mm
	Hatch Sorting	Optimized Sorting	
	Rotation Start Angle	0,0000	•
	Rotation Increment	0,0000	•
	Shift Factor	1	

The Chess Pattern will subdivide the complete hatching area in rectangular fields. Two different types called black and white fields are defined. The hatching vectors of those black and white fields are perpendicular to each other. The hatching vectors are always parallel to their field edge.





Parameter	Description
Hatch Distance	This is the distance between two neighboring Hatch Vectors.
Number of Vectors per Field	The field size is defined by the Hatch Distance and the Numbers of Vectors intended to fill in the field. A field starts and ends always with a vector.
Field Offset	This parameter defines to which extent the pattern elements overlap or are distanced from each other. Positive values will result in a gap, negative values will result in an overlap.
Hatch Sorting	Please see section 12.3.2 Hatch Sorting on page 110.
Rotation Start Angle	Hatch patterns can be rotated each following slice with a defined increment. This value defines the initial start angle from which rotation of the pattern starts.









No Pattern

In the drop-down menu, the Hatch Style *No Pattern* can be selected.

	Fill Pattern Type	No Pattern 🗸)
•	No Pattern Parameters		
	Hatch Distance	0,0500	mm
	Hatch Style	Single Fill 🗸)
	Hatch Sorting	ZigZag 🗸)
	Rotation Start Angle	0,0000	۰
	Rotation Increment	0,0000	۰
	Shift Hatches	2	

If No Pattern is activated, there is no subdivision of the hatching area in partitions.

Parameter	Description
Hatch Distance	This is the distance between two neighboring Hatch Vectors of the fill pattern.
	Hatch Distance Slice Contour Border Following Border Hatch Vector
Hatch Style	Please refer to section 12.3.3 Hatch Style on page 111.
Hatch Sorting	Please see section 12.3.2 Hatch Sorting on page 110.
	(Not available with Offset Fill)
Rotation Start Angle	Hatch patterns can be rotated each following slice with a defined increment. This value defines the initial start angle from which rotation of the pattern starts.
	(Not available with Offset Fill)



Rotation Increment This value can be used if the pattern is supposed to be incrementally rotated about a certain angle each layer. the increment value of the rotation angle between cons layers.		osed to be ach layer. It defines veen consecutive	
	Below, three subsequ 120°, incremented by	ient layers can be seen. 75° per layer (when onl	The initial rotation is y In Skin is enabled):
	<u>120°</u>	<u>195°</u>	270°
	Layer 1: 120°	Layer 2: 195°	Layer 3: 270°
	If Down Skin is enable Skin first layer as the	ed Rotation Start Angle second layer.	= 195°, considering In
	(Not available with Of	fset Fill)	
Shift Hatches	Enable or disable shif	iting of hatch vectors via nabled	the checkbox:
	(Not available with Of	tset Fill)	
Order	Please see section 12 (Only available with C	2.3.1 Scan Order on pa <u>c</u> D <i>ffset Fill</i>)	ge 110.





10.3.3 Up Skin

Area on a layer, above which there is no area to be exposed, is termed as Up Skin. If remelting is enabled Up Skin area will be additionally scanned with the In Skin hatching parameters.

•	Up Skin		
	Enable	V	
	Remelting	V	
	Hatch Offset	0,0500	mm
	Split Borders	V	
	Area Tolerance	0,2500	mm
	 Hatching Parameters 		
	Hatch Distance	0,0500	mm
	Hatch Sorting	ZigZag	•

To determine whether there is an Up Skin area present in a slice, the current slice is compared with one slice above. The offset value sets a border offset on the current slice to calculate the area difference between the current slice and the slice above. If the value is positive it indicates that there is an upside surface. Then the next volume area is changed into an In Skin area.



These areas are part of the visible up-facing surface of the 3D model. A different Build Strategy for these areas can be applied for a better surface quality.



Parameter	Description
Enable	Enable or disable the Up Skin hatching via the checkbox: Up Skin hatching enabled
Remelting	Enable or disable the Up Skin Remelting via the checkbox:
	The complete slice (Borders and Fill Area) is first scanned as In Skin area. The Up Skin and Transition Area are rescanned and thus remelted (with the Up Skin Remelting scanning parameters).
	The In Skin areas are scanned with the In Skin build strategy (defined in the In Skin) and the Up Skin areas are scanned with the Up Skin build strategy (defined in the Up Skin).
Hatch Offset	The Hatch Offset defines the distance between the innermost Border and the Up Skin hatching area.
	Hatch Offset
Split Borders	 Border which follows the contour of the same slice is split into Up Skin and In Skin border according to the area it belongs to, creating two different vector types Border which follows the contour of the same slice is subjected to NO split and is defined as In Skin border vector type
Area Tolerance	The Area Tolerance is applied after an Up Skin area is detected.











Enabling Up Skin will increase the processing time.





10.3.4 Down Skin

A Down Skin is a surface area facing down without volume in the previous layer and therefore scanned on powder.

These areas are part of the visible down-facing surface of the 3D model. A different build strategy (especially energy input) for these areas can be used to ensure a better surface quality.

 Down Skin 		
Enable	V	
Hatch Offset	0,0500	mm
Split Borders	V	
Transition Area	0,0000	mm
Area Tolerance	0,2500	mm
Fill Pattern Type	Stripes	~

To determine whether there is a Down Skin area present in a slice, the current slice is compared with the slice below. The offset value that will be set by a user sets a border offset on the current slice to calculate the area difference between the current slice and the slice below. If the value is positive, this indicates that this is a downside surface. Then a previous volume area is changed into a Down Skin area.



<u>Note</u>

Down Skin areas are not detected for the very first layer attaching the substrate plate.

Down Skin areas will be applied to connecting areas between solid supports and part.



The Down Skin hatching has to be explicitly activated in order to be generated.

Parameter	Description
Enable	Enable or disable the Down Skin hatching via the checkbox: Down Skin hatching enabled
	In Skin hatches will be replaced by Down Skin hatches in the Down Skin area.
Hatch Offset	The Hatch Offset defines the distance between the outermost Border and the Down Skin hatching area. 3 2 1
	Hatch Offset
	Border
	Following Border Hatch Vector
Split Borders	Border which follows the contour of the same slice is split into Down Skin and In Skin border according to the area it belongs to, creating two different vector types
	Border which follows the contour of the same slice is subjected to NO split and is defined as In Skin border vector type
Transition Area	A Transition Area should be processed from the Down Skin area into the In Skin, based on an offset value. It ensures a solid lamination of the Down Skin and In Skin area. In these Transition Areas Down Skin hatches are located on top of In Skin hatches.







Please see subsections of 10.3.2 In Skin on page 87 and following for
information on different pattern styles.

<u>Note</u> Enabling Down Skin will increase the processing time.

10.3.5 Solid Supports

Separate vector types are required for supports, to assign dedicated strategies. A difference is made between solid and non-solid supports. Non-solid supports typically have no volume and only consist out of lines. Solid supports have a volume and the slices need to be hatched.

 Solid Supports 		
Enable Hatching	S	
Hatch Offset	0,0500	mm
Hatch Distance	0,0500	mm

Enable HatchingEnable or disable hatching for Solid Supports via the checkbox:Solid Support hatching enabledHatch OffsetThe Hatch Offset defines the distance between the slice contour	Parameter	Description
Hatch Offset The Hatch Offset defines the distance between the slice contour	Enable Hatching	Enable or disable hatching for Solid Supports via the checkbox: Solid Support hatching enabled
and the Solid Support hatching area.	Hatch Offset	The Hatch Offset defines the distance between the slice contour and the Solid Support hatching area.







104

11 Scanning

The Scanning Parameters are added as metadata to the output .job file and can be interpreted by the machine control software to steer the machine and its building process accordingly. They are specified per vector type.

The following laser parameters apply to all available vector type categories, which can be found in the build profile.

- Laser Diameter
- Laser Speed
- Laser Power

All vectors can be modified:

 Border 			\$
Laser Diameter	0.1000	mm	\$
Laser Speed	300.0000	mm/s	\$
Laser Power	100.0000	w	\$

Parameter	Description
Laser Diameter	Determines the diameter of the laser beam for this vector type in mm
Laser Speed	Determines the scanning speed of the laser for this vector type in mm/s
Laser Power	Determines the Laser Power for this vector type in Watt

By clicking on an entry (e.g. In Skin) the vector types will be shown:

•	In Skin	
	⊳	Border
	⊳	Following Borders
	⊳	Fill Border
	⊳	Blocked Path
	⊳	Hatches



12 Scanning Order

The scanning order for parts and their supports, the border and the fill area vectors is defined here. In the Build Order section the general scanning order direction for all parts can be altered regarding their position on the platform and gas flow direction (if sorting against gas flow is enabled). Both sorting of vectors within a part and within the hatch pattern itself is described.

12.1. Build Order

12.1.1 Vector Types Order

The Vector Types Order is a list where user can set the order in which each of the vector types is exposed. To change a vector types order press "Sort" button and change position of vector types in the menu using up-down control buttons.

I Sort items − □ >		×		
	Sort the items by us buttons.	ing the (up/down	
	In Skin Hatching Down Skin Hatching Up Skin Hatching In Skin Following Bo Down Skin Following Bo Up Skin Following Bo In Skin Border Up Skin Border Up Skin Border In Skin Fill Border Down Skin Fill Border Solid Support Hatch Non-solid Support	g order g Borde Border er ning	r	
			(Close

According to this list build processor will expose the layer starting with the 1st vector type in the list, continue with the 2nd vector type and so on.



 Vector Types Order 		Sort	•
	In Skin Hatching		\$
	Down Skin Hatching		\$
	Up Skin Hatching		\$
	In Skin Following Border		\$
	Down Skin Following Border		\$
	Up Skin Following Border		\$
	In Skin Border		\$
	Down Skin Border		\$
	Up Skin Border		\$
	In Skin Fill Border		\$
	Down Skin Fill Border		\$
	Up Skin Fill Border		\$
	Solid Support Hatching		\$
	Non-solid Support		4

On the example shown below for every layer vector types will be printed explicitly in the order shown on the screenshot below. The Vector Types Order list shows all available vector types. In the case the vector type is not present in the layer (e.g. Up Skin and/or Down Skin build strategies, fill border are disabled in the UI; Up Skin and/or Down Skin are not present in the layer), the vector type remains in the list but will not be taken into account.



Here, one should pay attention on solid and non-solid supports which have their own vector types different from those defined for parts. Supports will be printed in the explicit output order defined in the vector type list (in the current example non-solid support is the last in the Vector Types List and, consequently, will be printed the last).



107

12.1.2 Build Order Mode

Slice cut planes create intersection contours with a model of a part. Intersection between one part and a slice cut plane can result in multiple contours referred further in the text as individual **regions**.



Abbreviations:

P – Part

R – Region

SS - Solid Support

NS - Non-solid Support

VT – Vector Type

To assign a printing order to each of the regions, one of two build order modes can be used. A user can choose between **platform** and **region** sorting. Selected build order mode influences the rest of the output order.

Build Order		Ð
Build Order Mode	Region 🗸	\$
Vector Types Order	Platform	•
 Sorting Against Gas Flow 	Region	A

Parameter	Description
Region	When region build order mode is selected vector types are scanned one after another within the same region rather than platform-wide until the whole region is printed.


	most distanced from a gas flow sour further in the direction against the ga Types Order shown on the screensh printed in a sequence illustrated in th	The regions the regions the regions the regions the recease and continues with those positioned as flow. If to take into account the Vector not on the page 106 all vector types are he corresponding table below.	
	Build Order Mode	Region	
	Gas Flow Angle	90°	
	Build Order of Regions	P2-R → P1-R1 → P3-R → SS → NS	
	Build Order of Vector Types	$\begin{array}{l} P2-R-VT_1 \rightarrow P2-R-VT_2 \rightarrow P2-R-VT_3 \rightarrow \\ P2-R-VT_4 \rightarrow P1-R1-VT_{14} \rightarrow \rightarrow P1- \\ R1-VT_{14} \rightarrow P3-R-VT_{14} \rightarrow P4-R-VT_{14} \\ \rightarrow P1-R2-VT_{14} \rightarrow P5-R-VT_{14} \rightarrow SS- \\ VT_5 \rightarrow NS-VT_6 \end{array}$	
	P1-R1 and P1-R2 regions belong to one right after another.	o the same part but will not be printed	
Platform	When platform build order mode is active, all same vector types are scanned one after another and each in a corresponding region. The order of regions is the same as in the region build order mode. If to take into account the Vector Types Order shown on the screenshot on the page 106 all vector types are printed in a sequence illustrated in the corresponding table below.		
	all vector types are printed in a sec table below.	quence illustrated in the corresponding	
	all vector types are printed in a sec table below. Build Order Mode	Platform	
	all vector types are printed in a sec table below. Build Order Mode Gas Flow Angle	Platform 90°	
	all vector types are printed in a sec table below. Build Order Mode Gas Flow Angle Build Order of Regions	Platform 90° P2-R \rightarrow P1-R1 \rightarrow P3-R \rightarrow P4-R \rightarrow P1- R2 \rightarrow P5-R \rightarrow SS \rightarrow NS	
	all vector types are printed in a sec table below. Build Order Mode Gas Flow Angle Build Order of Regions Build Order of Vector Types	Platform 90° P2-R \rightarrow P1-R1 \rightarrow P3-R \rightarrow P4-R \rightarrow P1- R2 \rightarrow P5-R \rightarrow SS \rightarrow NS P2-R-VT ₁ \rightarrow P1-R1-VT ₁ \rightarrow P3-R-VT ₁ \rightarrow P4-R-VT ₁ \rightarrow P1-R2-VT ₁ \rightarrow P5-R- VT ₁ \rightarrow SS-VT ₅ \rightarrow NS-VT ₆	

12.2. Sorting Against Gas Flow

There is always an inert gas (nitrogen or argon) flowing over the platform in a defined direction. This gas flow is primarily used to maintain the required inert atmosphere during processing to minimize the oxidation of the metal powder. However, it also serves a secondary function by removing any process by-products such as vaporized powder (condensate) and sputtered powder particles from the path of the laser, which may affect the laser beam properties and cause powder bed unevenness.





Consequently, direction of the inert gas flow across the build platform together with sorting against gas flow can significantly influence the quality and reproducibility of components across the build area. Direction of the gas flow can be defined in Configure Printer/Machine Properties/Gas Flow.

▼ Gas Flow			•
Angle	90.0000	•	n

12.3. Fill Area Vector Sorting

After defining the sorting methods for the platform, the Fill Area Vector Sorting describes the build order of hatches within an area.

12.3.1 Scan Order

Defines the order of the Offset Fill hatch vectors or borders. The user can select:

In2OutOut2In

Out to In	In to Out	3	2	1
	•			

12.3.2 Hatch Sorting

There are three different hatch sorting styles available. The sorting of the scanned vectors of the fill area is defined here. In the drop-down menu the user can select:

 ZigZig <i>(in No Pattern only)</i>
· · · · · · · · · · · · · · · · · · ·
- -

— ZigZag





Optimized Sorting

Optimized Sorting combines functionality of both ZigZag and jumps optimization. To minimize the number of jumps the Optimized Sorting will group the vectors in blocks following the shape of the slice. The figure below shows the difference between 2 sorting mechanisms: ZigZag on the left, Optimized Sorting on the right.



12.3.3 Hatch Style

There are three different Hatch Styles available when *No Pattern* Fill Pattern Type is selected:

Single Fill







Offset Fill







12.4. Support Vector Sorting

The parameters in this section are applied on non-solid (wall) supports only.

•	Supports		\$
	Enable Support Vector Sorting	V	\$

Parameter	Description
Enable Support Vector Sorting	Enable or disable Support Vector Sorting via the checkbox: Support Vector Sorting
	If activated, gas flow direction is taken into account following the same logic of hatch vectors sorting against gas flow even if the Gas Flow is deactivated (see also chapter 12.2 Sorting Against Gas Flow on the page 109).
	If deactivated, Support Vectors are printed in a random order and a number of jumps is minimized.





PART 3

Frequently Asked Questions

PART 3 represents a question catalog.

The frequently asked question section explains the solving of common issues like 'How to grant a computer read/write access to a network folder'.

Also typical error cases like 'Unexpected open contours in ... after slicing' or 'Uploading print job to machine' are demonstrated.

It includes a list of Materialise offices worldwide including their contacts and explains how to create a report file for the support.



13 Slice Based Operations

13.1. Why

Applying textures or structures to a model can easily result in very large STL files which become difficult to manipulate, store and transfer. Materialise has developed a technique to skip the intermediate STL file stage by generating the desired geometry directly into the slices using the Materialise Materialise MPM Build Processor.

13.2. How

Materialise 3-matic^{STL} **software** models containing metadata about textures (texture bitmap, location and size of texture, white and black offsets) or structures (area, graphs, thickness of graphs) can be loaded into Materialise Magics software and placed on the build platform. The Materialise Materialise MPM Build Processor will then automatically apply the textures or structures directly into the generated slices.

<u>Materialise Magics software</u> offers a module to generate Slice Based Structures straight from within Materialise Magics software.



For more information on how to access slice based operations please visit <u>http://software.materialise.com/making-complex-designs-printable</u>



14 Frequently Asked Questions

14.1. How to create a report file

In case of unknown errors the technical support of Materialise needs more detailed information of what has happened with the Build Processor or Build Processor System.

This information can be provided by the Build Processor System by creating a report file collecting data which might be useful to detect the error.









2. Click on 'Build Processor Manager'.



3. Click on the 'Help' button in the top right corner and click on 'Troubleshooter'.



4. Press 'Generate Report' to collect all data.







5. Save report.cab to a temporary folder.

J V I Computer V DATA (e.) V Temp 2			• • Search Te	mp 2	
Organize 🔻 New folder					
Name	Date modified	Туре	Size		
🛜 Libraries					
Documents	No items match	h your search.			
📄 Keno					
👌 Music 📃					
Pictures					
M Videos					
. Conneter					
A OS (C)					
kheitmann (\\hrs					
🗣 Network 👻					
File name: Report.cab					
Save as type: All Files (*.*)					

Notification

No personal data will be collected. The collected data are mainly log files of the Build Processor, information on the system environment, parameter files...

Before sending the report file to Materialise it is advised to open the report.cab to check the collected data. Make sure no data are enclosed which might be in conflict to the security policies of your company.

6. In order to send the report file successfully to Materialise the file <u>must</u> be zipped <u>and</u> password protected in order to pass the Materialise firewall.

This step is temporary as Materialise is working on a more easy solution of sending the report file.

7. Send the zipped file together with the password and a good error description to the technical support of Materialise.

14.2. How to grant a computer read/write access to a network folder

The BP uploads the jobs under the *local system account* by default, meaning that you must give read/write access for the upload folder to the computer from which you are sending the job, in case the target folder is a network folder. The screenshots below illustrates how a computer can be given access to a folder (in Windows® operating system version 7):

1. Right click on the folder and select *Properties*. Go to the tab *Sharing* and then click on *Advanced Sharing*



1 testfolder Properties
General Sharing TimeStamps Security Previous Versions Customize
Network File and Folder Sharing
testfolder Not Shared
Network Path: Not Shared
Share
Advanced Sharing Set custom permissions, create multiple shares, and set other advanced sharing options.
OK Cancel Apply





2. Check the option Share this folder and click on Permissions

Advanced Sharing
Share this folder
Settings
Share
testfolder
Add Remove
Limit the number of simultaneous users to: 20
Comments:
Permissions Caching
OK Cancel Apply

3. Click on Add

Permissions for testfolder		×
Share Permissions		
Group or user names:		
& Everyone		
	Add	Remove
Permissions	Allow	Deny
Full Control Change Read		
Learn about access control and per	missions	
ОК	Cancel	Apply





4. Click on Object Types

Select Users, Computers, Service Accounts, or Groups	? ×
Select this object type:	
Users, Groups, or Built-in security principals	Object Types
From this location:	
The state was a second as a second second	Locations
Enter the object names to select (<u>examples</u>):	
	Check Names
Advanced OK	Cancel

5. Check Computers and press OK

Object Types	? ×
Select the types of objects you want to find.	
Object types:	
V 🖳 Built-in security principals	
Service Accounts	
Computers Computers	
Groups	
V Sers	
OK	Cancel

6. Enter the (network) name of the computer which will submit jobs to this folder and press *OK*

Select Users, Computers, Service Accounts, or Groups	? ×
Select this object type: Users Computers, Groups, or Built-in security principals	Object Types
From this location:	
matone.materialise	Locations
Enter the object names to select (examples): *name of the computer which will be submitting jobs to this folder*	Check Names
Advanced OK	Cancel

7. Select the Computer you have just added and grant it Full Control of this folder. Proceed by pressing *OK* (followed by *OK* and *Close* to exit the other two windows)





📜 Pe	ermissions for test	folder		×
Sha	are Permissions			
G	roup or user names:	:		
5	Reveryone			
		1915 BAR 1993		
	\square			
			Add	Remove
P	ermissions for		Allow	Deny
	ermissions for Full Control		Allow	Deny
P	Full Control Change	X	Allow	Deny
P	ermissions for Full Control Change Read	×	Allow V V	Deny
P	ermissions for Full Control Change Read	×	Allow V V	Deny
P	ermissions for Full Control Change Read	× 	Allow V V	Deny
P	ermissions for Full Control Change Read	× 	Allow V V	Deny
	ermissions for Full Control Change Read	control and perm	Allow	Deny



14.3. How to run the BP Service under a different user account

You can let the BP Service run under a different user account, which means jobs will be uploaded under that user's credentials. The BP will then be able to upload jobs to the folders which this user has access to. The screenshots below show how you can run the BP Service under a different account:

1. Go to the Windows® operating system Task Manager (*CONTROL+SHIFT+ESC*) and click on the *Services…* button in the Services tab.

🚇 Windows Task Manager			_ 0	X	
File Options View Help					
Applications Processes Services Performance	Networking	Users			
Name	PID Des	scription			
- The Bard of Parents	2000 B			=	
- and a metropy of phases of		in the Paper State	100.000		
- manufacture					
		and the second second			
- application					
disast and disast statistics and		CONTRACTOR OF			
and the second second		Section and an	_		
- Andrew Street St Street Street Stre		the second second second			
- Andrewson (the state			
- All All All All All All All All All Al	1.00	a name i serand			
100.010		ay an subset			
1997	100		and the second		
in market	100	Angel and Andrew			
Colores -	100				
In the second second second	100 100	and the state of t	1.000	-	
< III			•		
			<u>S</u> ervices		
Assess DT O'RAge DR	Contract Bar	many SER			44

2. Locate and right click the *Materialise Build Processor System* entry and go to *Properties*

Services		- 5 11-11-11- ## 11 4 admin		
File Action View Help				
♦ ♦ 🔲 🗎 🤇	🗟 🛛 🖬 🕨 🔲 🖬 🕨			
Services (Loca	Services (Local)			
	Materialise Build Processor	Name	Description 🔺	
	System	🧠 IPsec Policy Agent	Internet Pro.	
	Stop the service	StmRm for Distributed Transaction Coordinator	Coordinates	
		Sink-Layer Topology Discovery Mapper	Creates a N.	
	Restart the service	🔍 Materialise Build Processor System	Start ise .	
		Materialise Floating License Server 6.0	Stop ise .	
	Description: Materialise Build Processor	Materialise Local License Server 6.0 Media Center Extender Service	Pause ise .	
Materialise Build System.			Resume Aed.	
	System.	Microsoft .NET Framework NGEN v2.0.50727_X64	Restart ft	
		Microsoft .NET Framework NGEN v2.0.50727_X86	ft	
	Microsoft .NET Framework NGEN v4.0.30319_X64	All Tasks / ft		
		Microsoft .NET Framework NGEN v4.0.30319_X86	Refresh ft 🔻	
<	Extended Standard		Properties	
Opens the properti	ies dialog box for the current se	lection.	Help	



3. In the tab *Log On*, select the *This account* button and *Browse* to the user account under which you wish to run the BP Service. Enter and confirm the corresponding password.

Materialise Build Processor	System Properties (Local Computer)	×
General Log On Recover	y Dependencies	
Log on as:		
Local System account		
Allow service to inte	eract with desktop	
This account	Browse	
Password:	•••••	
Confirm password:	•••••	
Help me configure user ac	count log on options.	
	OK Cancel App	ly

4. Exit by pressing *OK*. You will get a warning that you must restart the service, which can be done by right clicking the *Materialise Build Processor System*.

14.4. The Build Processor Manager is not in the Control Panel

This indicates that the Build Processor System has not been installed correctly. Please verify that the BP Manager is installed correctly, as described in section 3.3: Installing Materialise MPM BP on page 11. If this is not the case, try running the installer file again to reinstall.

14.5. Where can I check if I have a valid Materialise Materialise MPM BP license?

The Materialise Materialise MPM BP license is (currently) not visible in the license manager when it is launched from Magics. Please refer to section 3.4: Licensing on page 14 for more information.



14.6. Can I see what profiles were applied to my processed job? Yes, you can reopen the 'MatAMX input platform' (in Magics version 19 or higher).



15 Typical Error Cases

15.1. Error message in queue: 'Unexpected open contours in ... after slicing'

This error message means that the indicated part contains open contours which are not automatically stitched by the Gap Fill in the selected slicing profile. Such errors indicate that there are errors present in the original digital model. It is highly recommended to fix these in Magics, where you have a large set of dedicated fixing functions and visual feedback available. Alternatively, you can increase the Maximum Gap Size value to force stitch together all open contours. Please note that this can lead to unexpected output results.

15.2. Error message in queue: 'Uploading print job to machine'

Below the failed job entry, a more specific warning will be visible:

- 'The system cannot find the path specified' This indicates that no valid upload folder has been configured for the printer. Please refer to section 4.5: Configure a BP Machine on page 27 for more information on how to specify the printer upload folder.
 - 'Access denied' This indicates that your computer does not have modify/read/write access to the chosen folder.



126

16 Support contacts

We want you to have a smooth user experience when working with Materialise Build Processor. If you do encounter any error, please always try to save your work and restart your system first. Should the problem persist, you may contact Materialise Support. The technical support will be able to help you with technical problems you have when working with Materialise Build Processor.

If you have a valid **Materialise software maintenance contract** you can contact your local helpdesk via:

Worldwide	software.support@materialise.be
Korea	software.support@materialise.co.kr
USA	software.support@materialise.com
Germany	software.support@materialise.de
UK	software.support@materialise.co.uk
Japan	support@materialise.co.jp
Asia-Pacific	software.support@materialise.com.my
China	software.support@materialise.com.cn

Please include a report in your support request.





16.1. Materialise Offices Worldwide

Europe (Headquarter)

Technologielaan 15 3001 Leuven Phone +32 16 39 66 11 software@materialise.be

Great Britain

AMP Technology Centre Advanced Manufacturing Park

Brunel Way, Catcliffe

Sheffield, S60 5WG

Phone +44 1142 541 248

software@materialise-rp.co.uk

France

Zone Industrielle 41, Avenue de la Déportation 26100 Romans-sur-Isère Phone +33 4 75 05 00 22 <u>software@materialise.fr</u>

China

Room 1803A , BaoAn Mansion No. 800 Dongfang Road, Pudong Shanghai, PRC 200122 Phone + 8621 58312406 software@materialise.com.cn

Asia/Pacific

Unit 906&907, Block A, Phileo Damansara 2 No 15 Jln. 16/11 46350 Petaling Jaya Selangor Phone +603 7665 2988 software@materialise.com.my

USA & Canada

3009 Miller Road Ann Arbor, MI 48103 Phone +1 734 662 5057 software@materialise.com

Germany

Friedrichshafener Str. 3 D- 82205 Gilching Phone +49 8105 77859 33

Mary-Somerville Str.3 D- 28359 Bremen Phone +49 421 944074 30 software@materialise.de

Ukraine

UI. Raisy Okipnoi 8a 02002 Kiev Phone +380 44 594 56 10 info@materialise.kiev.ua

Japan

Yokohama Portside Bldg. 2F Sakae-cho 8-1 Kanagawa-ku, Yokohama Phone +81 45 440 4591 software@materialise.co.jp

India

Office No. 622, Siddharth Towers Near Sangam Press, Kothrud Pune – 411 029 Maharashtra, India software@materialise.com.my



128