

innovators you can count on



Magics Print Metal

Rev. 001

materialise.com



Table of contents

Table of	f contents 2
1 Ins	tallation5
2 Lice	ensing7
2.1	Working with a Local License7
2.2	Working with a Floating License7
3 Ma	nual & Other Documentation
4 Sup	oport Request
5 Vei	rsions
6 Qu	ick Access Bar9
6.1	Load Project9
6.2	Load Project9
6.3	Save Project9
6.4	Save Project as10
6.5	Import Part10
6.6	Save Selected Part(s) As10
6.7	Unload Part10
6.8	Undo10
6.9	Redo10
6.10	Select10
6.11	Zoom10
6.12	Unzoom11
6.13	Settings11
6.14	Quick Search11
7 File	Operations11
7.1	Info11
7.2	New Project12
7.3	Load12
7.4	Save As16
7.5	Machines
7.6	Options19
7.7	Exit19
8 Bas	sic Flow19
8.1	Setup19
8.2	Fix20





8	3.3	Enhance	20
8	8.4	Edit	20
8	8.5	Position	21
8	8.6	Z Compensation	32
8	8.7	Build Check	32
8	8.8	Supports	39
9	Fixi	ng	40
g).1	Errors explained	40
ç	.2	AutoFix	42
g	.3	Manual	43
g	.4	Enhance	43
10	E	dit	45
1	0.1	Rescale	45
1	0.2	Hollow part	45
1	0.3	Perforator	47
1	0.4	Cut or Punch	49
1	0.5	Extrude (PRO feature)	50
1	0.6	Label	52
1	0.7	Prop Generation	55
1	0.8	Structures (Additional Module)	57
11	S	cenes and Machines	62
1	1.1	Scenes	62
1	1.2	Machine	69
12	S	Support Generation	74
1	2.1	Introduction	75
1	2.2	Support Generation ribbon	75
1	2.3	Support Parameters – Machine properties	78
1	2.4	Support module	113
13	١	/iew & Analyze	130
1	3.1	Views	130
1	3.2	Elements	132
1	3.3	Measure	133
1	3.4	Build checks	133
1	3.5	Dialogs	133
14	С	Options & Help	134
1	4.1	Settings	134
1	4.2	Licenses	142
1	4.3	Help	144





14.4 About	
14.5 Logging	
15 Toolbars	
15.1 Mark Toolbar	
16 The Toolpages	
16.1 General	
16.2 View Pages	
16.3 Part Pages	
16.4 Measurements pages	
16.5 Fixing Pages	
17 Recommended System Requirements	
17.1 Hardware	
17.2 Operating Systems	
18 Contact Info	



1 Installation

Your Machine Manufacturer is responsible for supplying you with an installer for the Materialise Magics Print Metal Software.

This is a 'bundled installer', meaning that it will install all the necessary components to run the product. These include:

- Microsoft® .NET Framework 4.5
- Materialise Local License Server 6.0
- Build Processor System 2.0
- Standard Metal Build Processor 1.0 or similar OEM rebranded Metal Build processor
- Magics Print Metal data prep environment

How to install:

Notifications

We recommend that you close all other applications before installing Magics Print Metal

Technical Requirement

Please note that administrative rights are required to install the software.

- 1. Double click the product installer:
- NagicsPrintMetalSetup64bit21.3.
- 2. Select the language you want to use and click OK to proceed:



3. Select the folder where you want to install Magics Print. Via the browse button you can specify a new directory.





After reading the license agreements:

- Software beta tester non-disclosure agreement
- Materialise EULA
- Microsoft DirectX EULA

Select the "I agree with..." checkbox and click on the *Install* button.

Technical Requirement

If prompted to reboot your system after installation, please do so.

4. The software is now successfully installed. Click **Associate Files** to select the file types you wish to open with the Magics Print Metal software







Select the file types you want to open with the Magics Print software. It is advised to keep the standard settings. You can always change the associated files whenever needed via the Settings > File I/O > File associations menu

2 Licensing

For instructions on how to (re)activate your Materialise software licenses, please consult:

http://software.materialise.com/frequently-asked-questions-materialise-software

Once the Materialise Magics software and the Build Processor have been successfully installed, you will need to license it.

You can either license your software locally or use a floating license server to supply a license for you. This section will quickly describe these two different models of licensing.

2.1 Working with a Local License

Local Licensing is the traditional system with the license stored locally on each computer (see figure below). The software can only be used on the computer for which the license is issued. However, more than one session of Materialise Magics software & Build Processor can be opened on a single computer.



2.2 Working with a Floating License

The licenses for Floating Licensing are stored on a central computer somewhere on the company network (Server PC). This computer has the Materialise Floating License Server installed to manage all the licenses available on the network.

When a session of Materialise Magics software and Build Processor is started on a computer, the software will contact the Floating License Server via the network. When there is a license available, the Floating License Server will assign a license to Materialise Magics software & Build Processor allowing it to open.



However, if all licenses are in use, Materialise Magics software & Build Processor will not open. The user must wait until elsewhere on the network an open session closes, thus making a license available.

You can install Materialise Magics software & Build Processor on every PC connected to the company network, but the number of open sessions is limited by the number of floating licenses available.





3 Manual & Other Documentation

When clicking the "Manual" button in Magics Print Metal, you will be redirected to a webpage managed by your machine manufacturer. Here you can find this manual and optionally additional documents.



4 Support Request

Magics Print Metal allows you to send a support request by email to the customer support team of your machine manufacturer. This can be done by filling out the request form and by selecting the type of additional information you want to add to the request.

Support Request	
Select Office *	
First Name *	
Last Name *	
Company *	
E-mail Address *	
Phone number	
Details: *	A
	~
* required fields	
Additional information	
License overview	
Installation history	
Preferences	
🔲 GUI profile	
C Screen picture	
	Submit Close

To make sure that our customer support team has enough information regarding the problem, additional information can be included. You can select to add this information to your support request, which will give the customer support team more information about your Magics Print Metal configuration. By sharing this information it is more likely that your support case will be solved more swiftly.





5 Versions

Magics Print Metal for ... can be offered in 3 versions:

- Base
- Standard
- Pro

All versions can import

Magics project files (*.magics) STL files (*.stl) Materialise AM Exchange files (*.MatAMX) Stl Zip Files (*.mgx) Connect Project File (*.mproject) Connect Part File (*.mpart)

All versions can only export to specific machines of your machine's manufacturer.

In all versions, parts can be saved as .mpart and projects as .mproject.

High-level feature overview: (all higher versions contain all features from the lower version)

Base: Import, manual placement, cutting, manual support placement (cones & trees), measurements, out of bounds, collision detection, export

Standard: + Fixing, Editing tools (hollow, perforate, label), automatic placement, automatic support (points, lines, blocks, cones, trees), wall thickness analysis.

Pro: Extrude, Thickness for non-solid supports

Additionally, a **Structures module** is available.

6 Quick Access Bar



6.1 Load Project

Create a new Magics Print project. (CTRL+N)

6.2 Load Project

Load an existing project. (CTRL+O)

6.3 Save Project

Save the current project. (CTRL+SHIFT+S)





6.4 Save Project as

Relation. Save the current project and select the desired name, file format and location.

6.5 Import Part

Import an existing 3D model into the current scene.

6.6 Save Selected Part(s) As

Save the selected part(s) and select the desired name, file format and location. (CTRL+S)

6.7 Unload Part

This command removes the selected parts. If the user has selected several parts, these parts are removed at once. The Unload function does not affect any platform settings. The user is prompted to save the parts that will be unloaded if they are changed. (CTRL+U)

6.8 Undo

With this command you can undo the previous action. All actions that change the STL file will be noted in a list, the Log Window (Menubar/View/Log Window). In case of a computercrash when Magics Print Metal is open, you will be able to recover the work you did before (auto-recovery). (CTRL+Z)

The undo and auto-recovery functions are default ON. If you would like to change this, go to Settings (Settings > General > Undo and Recovery)

6.9 Redo

The actions that were undone by the undo operations can be redone by redo. (CTRL+Y)

6.10 Select

Select part(s) (F2)

6.11 Zoom

To zoom in on a region, this region has to be defined by means of a box (drag from the left upper corner to the right bottom corner). When the mouse button was pressed, but no rectangle was drawn, a zoom in of 25% will be applied. Zooming in and out can also be done using the mouse scroll.



10



6.12 Unzoom

 \mathbb{R} The zoom factor will be set so that all the active parts are displayed.

6.13 Settings

Change Magics Print settings

6.14 Quick Search

<u>Duick search (Shift+Q)</u> Search a functionality within Magics Print Metal. Start entering the name of a functionality, and all relevant functionalities are instantly shown. Click on the desired functionality to directly activate. (SHIFT+Q)

7 File Operations

7.1 Info

Info New Project Laad Save As Machines Dytions Exit Class C	
---	--

In this section you can find more information on the Magics Print Metal software:

- Manual: hyperlink to Reference manual on the Magics Print Metal software
- Support Request: contact info to request support.
- About Magics: info about your currently installed Magics Print for Metal.

The features of this section are also available via the Options & Help ribbon.





7.2 New Project

Info	
New Project	Information
Load	
Save As	
Machines	Wanua

The "New Project" command removes all parts from the current project and generates an empty project. The user is prompted to save the project before the current platform is closed.

🔳 Unic	bad	×
?	Save changes to Untitled?	
	\square Never ask this again	
Ye	s No Cancel	

7.3 Load

Via this section you can load a project or import a part into an open project. Your recently opened or saved files can be accessed directly in this section.

7.3.1 Load project

The Load Project command starts the standard dialog box to open files.

👱 Load				×	
← → × ↑ 🔩 > Thi	$\leftarrow \rightarrow \checkmark \uparrow $ $\textcircled{b} > $ This PC $> $ OSDisk (C:) $\checkmark \bigcirc$ Search OSDisk (C:) $\checkmark \bigcirc$				
Organize 👻 New folder	r			?	
🗸 🧢 This PC 🔷	Name	Date mod			
> 📙 Desktop	📕 Intel	7/11/2016			
> 📔 Documents	PerfLogs	10/07/201			
> 🔖 Downloads	📜 Program Files	26/01/201			
> 🔥 Music	📜 Program Files (x86)	26/01/201			
> 🕞 Pictures	Users	8/11/2016	Colorto filo to considera		
> 🖪 Videos	Windows	24/01/201	select a file to preview.		
> 🔩 OSDisk (C:)					
> 🜙 DATA (D:)					
> 🧹 My Passport (F:)					
> 🥪 Johan Troukens (
> 🛫 China-HQ(SAM) 🗸	<	>			
File nam	e:	~	Magics project files (*.magics)) ~	
	Project Loading	g: Standard ~	Open Cancel		

The following types of files can be loaded:





Magics Project files	(*.magics)
Materialise AM Exchange files	(*.MatAMX)
3MF files	(*3mf)
3-matic project files	(*.mxp)
STL files	(*.stl)
STL Zip files	(*.mgx)
Magics Connect Project file	(*.mproject)
Magics Connect Part file	(*.mpart)

The memory state of the loaded project can be defined, the following states can be chosen:

Standard	This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles)
Compact	The STL resides in the memory as read-only, therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level.
On Disk	The STL is saved on disk and unloaded from the memory. The STL will stay in the project but the user can't perform any actions on it.
As Saved	The Project will be loaded as previously saved.

The default memory state for the loaded project can be defined in

Settings -> File I/O -> Import -> STL.

7.3.2 Import Part

Notification

All formats can be imported by dragging and dropping the files in Magics Print Metal

This command loads a part on the current platform from a selected location. To load several parts at the same time, the CTRL or Shift buttons can be used. In this case, the preview can't be used.



e modified Ty 1/2017 23:59 St 1/2017 23:59 M 1/2017 23:59 St	ype TL Document	Size	1 0
e modified Ty 1/2017 23:59 ST 1/2017 23:59 M 1/2017 23:59 ST	ype TL Document	Size	ſ
1/2017 23:59 ST 1/2017 23:59 N 1/2017 23:59 ST	TL Document	10 KB	
V2017 23:59 N	Antonia Bara Manata		
/2017 23-59 51	laterialise ivlagic	19.610 KB	
7201725.55	TL Document	19 KB	
/2017 23:59 5	TL Document	19 KB	
/2017 23:59 5	TL Document	777 KB	
/2017 23:59 5	TL Document	489 KB	
/2017 23:59 5	TL Document	4 KB	
/2017 23:59 5	TL Document	577 KB	
/2017 23:59 N	laterialise MGX D	129 KB	
/2017 23:59 S	TL Document	1.137 KB	
/2017 23:59 N	laterialise Magic	212 KB	
/2017 23:59 5	TL Document	248 KB	
/2017 23:59 ST	TL Document	637 KB	
/2017 23:59 ST	TL Document	3.816 KB	
/2017 23:59 ST	TL Document	165 KB	
ofix during import			
4	4/2017 23:39 S	ofix during import	All available parts (*.magic

As Is	The original STL-position is maintained
Default Position	The part is placed at the default position. This default position is defined in the Machine Properties and represents the minimal X, Y and Z of a part. (default position: Xmin = 10mm; Ymin=10mm; Zmin = 10mm)
Aside Of Others	Parts are loaded one after the other while the original Y-position is maintained. If a line is full, a new line is started.
Automatic Placement	The part(s) will be added using automatic placement. The parts that already are loaded will not be moved. This can be done later by selecting all the parts and using Automatic Placement of the Tools menu. Changing the settings for automatic placement can be done in the Nesting settings (see Error! Reference source not found., page Error! Bookmark not defined.).



14



Autofix during	When enabled, Magics will diagnose your files during import and attempt to fix
import	the part if needed.

The memory state of the loaded part can be defined, the following states can be chosen:

Standard	This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles)
Compact	The STL resides in the memory as read-only, therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level.
On Disk	The STL is saved on disk and unloaded from the memory. The STL will stay in the project but the user can't perform any actions on it.

The default memory state for the loaded part can be defined in

Settings -> File I/O -> Import -> STL.

When trying to load a part that is too large in standard mode, a dialog box asking to rescale the part will pop up.

Import Pa	rt Warning				23
Part 'bottom_Rescaled(968.973).stl' is oversized. The dimensions of the part exceed the dimensions of the workspace. Magics needs to rescale the part with a Rescale factor to ensure the part will fit in to the workspace.					
Do you	u wish to rescale by	a factor of	10,000 %?		
	Original bounding	box	Rescaled boundin	ig box	
	28999,000	mm	2899,900 mm		
	57704,000	mm	5770,400	mm	
	110268,000	mm	11026,800	mm	
Image: Add rescale factor to part's name Image: Apply to next oversized parts Rescale Don't Import Cancel					

Rescale factor	Magics proposes a factor to use to rescale the part so it will fit within the workspace.
Original bounding box	Represent the current size of the parts bounding box





Rescaled bounding box	Represents the parts bounding box after the rescale take place
Add rescale factor to part's name	The used rescale factor will be added to the part name
Apply to next oversized parts	The same rescale factor will be used for other upcoming oversized parts
Rescale	The actual rescale is performed
Don't import	The part isn't rescaled and will not be imported

7.3.3 Recent Files

This list shows the most recent files you used in Magics Print.

7.4 Save As

Via this section you can save your opened project, select part(s) or scene.

Info	
New Project Load	Export
Save As Machines	Save Project
Options Exit	Save Project As
	Save Selected Part(s) As
	Save Scene

7.4.1 Save Project

When you have prepared a project in Magics Print Metal, you can save it to disk in order to load it again later on. In order to save the project, the following types can be chosen:

Magics Connect Project files (*.mproject)

7.4.2 Save Project As



16



Save Project As allows you to save the project with another name, it contains the same functionality as Save Project.

7.4.3 Save Selected Part(s) As

With this command, the active (selected) files are saved. The destination of the saved parts can be changed when using this option. Each part is saved in a separate file.

💐 Save Part(s) As	×
\leftarrow \rightarrow \checkmark \uparrow \blacksquare « Users > Default > Desktop \checkmark \circlearrowright	Search Desktop
Organize • New folder	!≡ ▼ (?
✓	Date modified Type
Desktop 🖈 No items match	your search.
📔 Documents 🖈	
📜 Downloads 🖈	
🔚 Pictures 🖈	
01_Materialise_N	>
•	-
File name: Bas Reliefs_Male-2_Scaled_triangle_reduction.mat	Part ~
Save as type: Materialise part files (*.matPart)	~
Hide Folders One by one	Save Cancel

Following formats can be used to save your parts

Name	Extension
Connect part files	*.mPart

7.4.4 Save scene

Save the active scene.





7.5 Machines



7.5.1 Change MachineSee Change Machine, page 74

7.5.2 Machine Properties See Machine Properties, page 69

7.5.3 Build Processor Manager

See Build processor, page 1874



18





7.6 Options

Info	
New Project	Ontions
Load	Options
Save As	Ö Cattinge
Machines	settings
Options	
Exit	*

7.6.1 SettingsSee Settings, page 134

7.6.2 Licenses See Licenses, page 142

7.7 Exit Closes Magics.

8 Basic Flow



- 8.1 Setup
- 8.1.1 Load Project
- 🌠 Load an existing project. (CTRL+O)

8.1.2 New Scene







With this function, you create a new Platform Scene in the main window. The platform size will depend on the machine you select.

Change Machine	
	B.Proc.: Standard LM Machine 🔹
	Metal
	Standard LM Machine 👻
	none
Platform Pa	arameters
	Default
	Ok Cancel Help

The new scene will appear on the right of the present Platform Scenes.

If you create more than one platform for the same machine, the platform name will be the machine name extended with a number, e.g. 'Machine ABC (2)'. You can organize machines via drag and drop.

8.1.3 Import part

5 Import an existing 3D model into the current scene.

8.2 Fix

8.2.1 Autofix

See AutoFix, page 42.

8.3 Enhance

8.3.1 Triangle Reduction

See Triangle reduction, page 43

8.4 Edit

8.4.1 Rescale







See Rescale, page 45

8.4.2 Hollow part

See Hollow part, page 45

8.4.3 Perforator

See Perforator, page 47

8.4.4 Cut or Punch

See Cut or Punch, page 49

8.4.5 Label

See Label, page 52

8.5 Position

8.5.1 Duplicate

This command duplicates the selected parts. The new parts automatically get the name of the original part with a counter at the end, like this: "PartName_1"

💘 Dupli	cate Part(s) (Virtual C	Opies)			×
Tota	al Number of Cop Show Preview	ies 2	÷		
-	Array placement				
	Number of Copie	es Spacing			
x	2 ‡	1,000	* *	mm	
Y	1 ‡	1,000	÷	mm	
z	1 +	1,000	÷	mm	
		Remem	ber Value		
				Ok	Close





Total Number of Copies	Here you have to indicate the total number of parts (the original part included) you would like to have in the end.
Show Preview	When enabled, a preview will be shown
Number of Copies	Number of copies (original included) you would like to have in the indicated directions (X, Y, Z)
Spacing & Remember Value checkbox	The distance between 2 parts. Check " <i>Remember Value</i> " if you want this value to be remembered.

8.5.2 Automatic Placement

This command will nest the loaded parts on the building platform. Please note that for nesting the parts in 3D, the Sinter module is required. There are two options:

- Geometry based nesting
- Bounding box based nesting

Please recall, that while importing multiple parts you can also use the automatic placement algorithm to immediately position your parts on the platform.

Automatic placement is also possible when the platform isn't big enough to load all the specified parts on the platform. A dialog box will appear indicating no solution is found, but a search is performed to find a solution outside platform borders. So even if the parts don't fit the platform, they are spread out to have a better overview.

😤 Automatic Placement		×
Part Interval 5,000 ‡ mm		
Parts to Nest	Range by Z beight	
Nest All Parts	Start with min Z	
Selected parts	Start with max Z	
Z-height & support	O Bartinining	
Move parts to default Z-heig (Trees, manual supports an	ght nd STL supports will be removed)	
 Keep supports (Z-height of 	parts will not change)	
Enable Multi-Platform Placeme	ent	
Geometry Bounding Box Placement Solution First Possible Solution Minimal Surface Area Minimal X-Dimension Minimal Y-Dimension Platform Center	[BETA] Geometry 2.5	
	Ok Clos	e





Part Interval	The minimum distance between two parts.				
Platform Margin	The minimum distance between (the bounding box of) a part and the edge of the platform				
Parts to Nest	Nest All Parts	Nests all the parts or only the selected parts.			
	Selected Parts				
Z-height & support	Move parts to	Moves the parts to the default z-height, but will remove the			
	default Z-height	support			
	Keep supports	Keeps the parts on the same z-height and maintains the			
		support			
Enable Multi-	If this option is checked and the nested parts don't fit on the current Platform, Magics Print will create as many as needed new Platforms to nest all (or the selected) Parts.				
Platform Nester					

8.5.2.1 Geometry

A nesting based on bounding box can cause a waste of capacity in case of parts, which are having a big bounding box but a small projected area. Magics Print will nest the parts using the actual form of the parts and so increase the efficiency of the nesting.

Geometry Bounding Box Geometr	y 2.5
Placement Solution First Possible Solution Minimal Surface Area Minimal X-Dimension Ninimal Y-Dimension Platform Center Custom Part Placement Part Placement Translate and Rotate Parts Only Translate Parts	
Placement solution	
First possible solution	With this option, Magics offers the first placement it finds for which all parts are nested on the platform.
Minimal surface area	The total surface area of all the loaded parts is minimized.





	Minimal X-	The delta-X of the total surface area of the loaded parts is minimized
	dimension	The delta-X of the total sufface area of the loaded parts is minimized.
	Minimal Y- dimension	The delta-Y of the total surface area of the loaded parts is minimized.
	Platform center	Parts are nested around the center of the platform. A circular shape is created.
	Custom Part Placement	With this option, you can add a grayscale image to assign priority or penalty zones for Autoplacement.
Part	olacement	
	Translate and Rotate parts	Rotate will give Magics Print the liberty to rotate the parts by 90°. This will result is more efficient and faster nesting.
	Only Translate	The parts will not be rotated, strictly translated.
	Automatic Placement	This indicates the progress of the parts being placed on the building platform



	Progress [42%]		
	Automatic Placement	42%	
	Time elapsed: 1 seconds		
		Cancel	
	If the automatic nesting isn'	t able to nest all parts following	message is
	shown:		
	Magics	23	
	All parts can't be placed on the platform on multiple platforms?	n. Would you like to place parts	
		Yes No	
	YES: New platforms will be	created with parts on it	
	NO: The parts that didn't fit	can be found beside the platform	n
Cancel	This cancels the calculation	 (S.	

8.5.2.2 Bounding Box

Magics Print Metal will nest the parts, representing the parts by their bounding boxes. This will result in a fast nesting, however the full surface of your machine will not be used due to the rough representation of the parts.







Notifications

Performing an automatic placement without a scene (platform) loaded will give you fewer possibilities than shown above.

8.5.3 Translate

Translate

The translate operation allows to move a part or a group of selected parts to another position. Move the selected part(s) interactively or by inputting values.

Tra	nslate P	art(s)					
	Decili				Delet		la tian
	Result	ing coo	raina	tes	Relat	uve trans	ation
х	7,499		*	mm o	1X D,00	0	-, mm
Y	5,001		÷	mm o	IY 0,00	0	‡ mm
z	10,00	0	+	mm o	lz 0,00	0	‡ mm
] Enab	le snap	ping		Size	1,000	¢ mm
] Trans	slate al	ong li	ne			
	Make	CODY			Shov	w preview	,
	🔻 Tra	nslatior	n origi	in			
	Define	origin f	or se	lected	parts:		
	Min	Middle	Max	User			
	x 🖲	0	0	Ο	0,000		‡ mm
	Y 🖲	0	0	Ο	0,000		‡ mm
	z 🔍	0	0	0	0,000		‡ mm
Indicate Point							
To default position To default Z							
Apply Ok Close							

Resulting coordinates	Use the resulting coordinates fields if you want to move a part to a specific location.
Relative translation	Use the relative translation fields if you want to move the part a specific distance away from the current position.
Enable snapping	Enable if you want to translate with specified intervals. (For example: only move per 1 mm.) You can use the snapping option both for interactive translation and with coordinate fields.
Size	The snapping value used.





Translate along line	After enabling, select a line (part/triangle edge) along which you want to translate. This function can only be used when translating interactively.
Make Copy	Enable if you want to make a copy on the desired place and keep the original part on its place.
Show preview	When enabled, a preview will appear to show the result of the inputted values.
Define origin for selected parts	Define the translation origin of the part to select which point of the part should be moved (to which point in space) by selecting minimum, middle, maximum or user defined. The gizmo will move to visualize your choice. With "Indicate point", you can easily select a translation origin.
To default position	Click to move the origin of the translation to the default position (see Default part position, page 7071).
To default Z	Click to move the part to the default Z-height. X and Y will remain unchanged.
Apply	Apply the changes. The dialog box won't close, so you can easily perform the translation in multiple steps.
ОК	Apply the changes. The dialog will be closed automatically.

To move interactively, click on an axis of the translation gizmo and drag to move the part along that axis. It is also possible to click on a plane of the gizmo to move the part within that plane.



Notifications

By default, if only one part is selected, the translation gizmo will appear in the minimum point of the bounding box of the part. If multiple parts are selected, the gizmo will appear in the minimum point of the bounding box of all selected parts. All the parts will then be translated together, without changing the distances between the parts. The position of where the gizmo appears depends on what you select in "Define origin for selected parts"



27



8.5.4 Rotate

Rotate the selected part(s) interactively or by inputting values.

Rotate

Y Rotate	×
Rotation Angles $ \begin{array}{c c} $	
□ Enable Snapping Size: 45,00 ‡ °	_
□ Rotate Around Line □ Keep Original Z Position	
Make Copy Show Preview	_
▼ Rotation Center	_
Center of Selection	
Individual Part Center	
○ Custom Rotation Center	
X 65,001 ‡ mm Indicate Point	
Y 35,001 🛟 mm Default Center	
Z 15,000 🗘 mm	
Apply Ok Close	

Rotation Angles	Fill in the desired rotation angles in the X, Y and Z fields. The positive rotation sense is counter clockwise (CCK).
Enable snapping	Enable if you want to rotate with specified intervals. (For example: rotate per 45°) You can use the snapping option both for interactive rotation and with angle fields.
Size	The snapping value used.
Rotate around line	After enabling, select a line (part/triangle edge) around which you want to rotate. You can then rotate interactively or by inputting a value.





	Rotation Angle
Keep original Z position	When enabled, the part's minimal Z-position will stay the same while rotating.
Make copy	Magics will create a copy on the desired place and keep the original part on his place.
Show preview	When enabled, a preview will appear to show the result of the inputted values.
Rotation Center	There are 3 options available: <u>Center of selection</u> : If multiple parts are selected, they will all rotate around the center of the selection, moving their position. <u>Individual part center</u> : Each part will rotate around its own center, so their position won't change, only the orientation. <u>Custom rotation center</u> : You can define a point around which the selected part(s) should rotate. With "Indicate point", you can easily select a rotation center. "Default center" resets the values to the center of the selection.
Apply	Apply the changes. The dialog box won't close, so you can easily perform the rotation in multiple steps.
ОК	Apply the changes. The dialog will be closed automatically.



To rotate interactively, click on an axis of the rotation gizmo and drag to rotate the part along that axis. To rotate perpendicularly to the screen, use the outer (blue) circle. To rotate in an unrestricted way, click in between the axes of the rotation gizmo and drag.

8.5.5 Bottom/Top Plane



This command allows easy orientation of the part by indicating a plane as the bottom/top plane. This plane will be automatically oriented parallel to the platform. The bottom/top plane window looks like this:





🔮 Bottom/Top Plane		\times
Plane Bottom Plane Upper Plane Indicate Plane Hold CTRL to select su Advanced	rfaces on differen	t parts
Apply	Ok	Close

8.5.5.1 Advanced

Indicate Plane	The user selects one triangle and a whole plane (according to the plane selectio parameters) will be indicated by the default green marking color. The selected plan will be placed parallel to the platform (// XY-plane). E.g. Bottom plane selection i the following figure.				

Plane Selection Para	ameters	
Surface Tolerance	10,000	‡ mm
Angle Deviation	10,000	÷ o
Positioning		
None		
○ Keep Original Z Position		
○ Translate to Def	ault Positio	on
O Translate to Def	ault Z Posi	ition





Plane Selection Pa	rameters
Surface	Indicates the maximum deviation in mm or inches that a related triangle may
Tolerance	have to be part of the same plane that contains the selected triangle
Angle Deviation	Indicates the maximum angle in degrees between the normals of a related triangle and the selected triangle, in order to be part of the same plane.
Positioning	
None	No translation is done.
Keep Original Z Position	The part first will be rotated and next will be translated in such a way that the original minimum Z position remains the same.
Translate to Default Position	The part first will be rotated and next will be translated to the default part position.
Translate to Default Z position	The part will be translated to the default Z position.

Notifications

The indicate place function is only performed when the part is loaded in standard mode. If the part is loaded in compact mode, the indicate plane function is going to act like indicate triangle.

Use CTRL+click left mouse button so select multiple parts. Click a part a second time to deselect.

8.5.6 Pick and Place Parts



This command allows the user to translate and rotate (around the axis perpendicular to the platform) selected parts on a platform by mouse movements. You can select the part by first clicking on the icon and then clicking on the part. The pick and place Pick and Place Parts tags will appear. There are nine tags on a selected part in the pick and place mode:

One translation tag: the filled green or white circle located in the center of the part.



Eight rotation tags: the hollow green or white tags located on the corners of the bounding box. This command allows easy positioning and nesting of the parts on the building platform. With the collision detection-feature, the user can check if the parts aren't positioned inside each other.





If the cursor is positioned above the translation tag, the cursor will change to the translation cursor ($^{(1)}$). To translate the part, push the left mouse button. If several parts are selected, they will all move in the same direction over the same distance.

8.6 Z Compensation



Z compensation will allow you to modify your part(s) in the Z direction in such a way that it will compensate for overcuring

Z Compensate

Z-Compensation Part(s)		×
Z Compensation 0,1250	mm I	
Advanced Options	OK Cancel Help	

8.7 Build Check

8.7.1 Wall thickness analysis



The wall thickness analysis helps you to detect small details, thin and/or thick walls. This can be very helpful, because you can predict where problems can pop up during building.

8.7.1.1 Principle

Magics determines the local wall thickness for each triangle separately. If requested, Magics divides bigger triangles in smaller ones according to the refine triangles parameters entered. This way, a more detailed figure of the wall thickness can be calculated.

Wall thickness analysis X			
Show result as $\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \$			
Minimum thickness 0,500 mm			
Maximum thickness 1,500 mm			
Refine triangles			
Advanced			
OK Cancel Help			





8.7.1.2 *Gradient coloring*

The triangles are colored corresponding their wall thickness. In the Legend you can see which wall thickness corresponds to which color.

Show result as Gra Minimum thickness 0,5 Maximum thickness 1,5 I Refine triangles	idient coloring V i00 mm i00 mm		
Minimum thickness This parameter defines the minimum wall thickness needed. Every triangle with a local wall thickness smaller than the entered value, will receive the begin color.			
Maximum thickness	The maximum thickness is the wall thickness for which you no longer expect to have problems. Local thickness bigger than the maximum thickness do not need special attention and will have the end color. Triangles with local thickness situated between the minimum and the maximum thickness will have a color gradually changing from the begin color (minimum) to the end color (maximum wall thickness) over the color spectrum. The minimum and maximum wall thickness also forms the borders of the Wall Thickness Color Legend.		
Refine triangles	If checked, the triangles that met the criteria are retriangulated. The analysis is based on the newly created triangles.		
Is based on the newly created triangles.			







Triangles that met the criteria can be colored after the analysis.

In the legend you can see which wall thicknesses correspond to which color.

Color range can be customized from the customization settings.

8.7.1.3 Marking

(
Show result as	Marking		\sim	
Thinner than	0,500 mi	m		
O Thicker than	10,000 mi	m		
OBetween	0,500 &	10,000	mm	
Outside	0,500 &	10,000	mm	
Refine triangles				
L				
Detect triangles of walls Choose				
Thinner than Search v				
Thicker than			Search	
Between			Search	
Outside			Search	
Refine triangle	S		If check	
Petect triangle Detect triangle Thinner than Thicker than Between Outside Refine triangle	s of walls		Choo or O Sear Sear Sear Sear If cho The	

After the analysis of the part(s) a list is shown with areas that match the WTA conditions.

Every group of triangles is indicated as a bad area. The list gives a clear overview of all problem areas on the part(s). By clicking on the magnifying glass, the view will zoom to that specific bad area.





ID 1 2 3 4 5 6		* * * *	* III
1 2 3 4 5 6		* * * * *	=
2 3 4 5 6		* * * *	=
3 4 5 6		××××	
4 5 6		× ×	
5	2	×	
6	- O		
-		×	
/	,	×	
8	P	×	
9	P	×	
10	P	×	
11	P	×	
12	P	×	
13	2	×	
14	P	×	
15	P	×	-
	9 10 11 12 13 14 15	9)9)9 10)9 11)9 12)9 13)9 14)9 15)9	9 10 2 x 11 2 x 13 2 x 14 2 x 15 2 x

×	Visible/ Invisible	Hide/ unhide bad areas
ed	Part	Part name is displayed
	ID	Every bad area is indicated with a unique ID to easily identify regions
	Zoom	Zoom to indicated area
	Delete	Remove the indicated area from the list
	Reanalyze selected parts	The list is updated by performing a new wall thickness analysis
•	Isolate highlighted parts	Only the selected part in the part list is isolated. To have a good overview all other parts on the platform are invisible.
	Autozoom	Zooms automatically to the bad area that is highlighted

8.7.1.4 Advanced

Advanced	
Wall angle	45,000 °
Refine triangles parameters	
Iterations	3
Max edge size	2,000 mm

Wall angle Defining a wall angle makes it possible to exclude certain areas/ surfaces from the analysis. (More information below)		
Refine triangles parameters (More information below)		
Iterations The value entered as the number of iterations places an upper limit on the number of iterations		
s		





Max edge size	A triangle will only be split up in a smaller triangle if one dimension of
	that triangle is bigger than the maximum edge size. This parameter thus
	decides the accuracy with which you are going to visualize (and
	measure) the thickness distribution.

8.7.1.4.1 Wall angle

During the analysis of the part, certain areas of the part can be excluded from the calculations.

The following 2D drawing illustrates the case where you have a wall with two rectangular angles.



From a triangle point-of-view the local wall thickness approaches zero when coming closer to the edge of the part. The real thickness though remains the same throughout the whole wall. Therefore we can exclude the area around these edges from the thickness calculations.

The wall angle is the parameter that avoids that the above areas are taken into account. When the wall angle is for instance set to 60 degrees, thickness calculations will only be done for edges whose angle is smaller than 60 degrees. These edges will be interpreted as functional edges of the part and not just 'wall borders'.

On the figure below you can see a sample of a file where the triangles have an angle of 45 degrees between each other.






Set Wall Angle value less than the angle between triangles (in this case it is less than 45 deg.), these triangles won't be detected by WTA tool.

Set Wall Angle value higher than the angle between triangles (in this case higher than 45 deg.), these triangles will be detected by WTA tool.

Wall Angle = 50°	Wall angle = 70°
Critical gap angle = 180-(2*50)= 80°	Critical gap angle = 180-(2*70)= 40°
60.00°	E0.00°
60° < 80°: the local thickness reduction is not taken into account	60°>40°: the local thickness reduction is taken into account

8.7.1.4.2 Refine triangles parameters

Now let us take a look at the following part.



At the bottom of the rectangular gap, there is a significant thickness reduction. Therefore we expect that on the bottom plane, close to the gap, a region will show up to indicate this smaller thickness.

However, there is a small problem ... the bottom plane will probably exist out of two big triangles. During the analysis the complete plane will become indicated. 'Refining the triangles of the bottom plane solves this problem. The two big triangles are spitted up in smaller triangles, and the thickness variation can now be visualized more accurately.

Three parameters define this remeshing process.







8.7.2 Out of Bounds



The out of bounds function will color parts which are placed outside of the platform bounds. Any placement tool can be used without losing the color indications.



Notification

Round platforms are currently not supported.

8.7.3 Collision Detection



If several parts are loaded on the platform, Magics Print can detect if there is a collision. Collision can be detected between intersecting triangles or with an indicated clearance between different parts. The involved triangles are marked in the Marked Triangles Color (default green). A message-box appears to tell you if there are colliding triangles or not.



Collision Detection	×
Analysis With Clearance 1,000 All Parts Selected Parts Analyze No-Build-Zones	mm
Identification Hide Parts with no Conflict Color Triangles	
ОК	Cancel Help

Analysis				
With clearance	Define the spacing allowed between parts. If they are located within a distance smaller than this value, they will be identified as colliding parts.			
All parts	Collision is detected between all loaded parts on the platform scene.			
Selected parts	Collision is only detected between selected parts			
Analyze No- Build-Zones	Collision is detected between the part(s) and active 'No-Build-Zones'			
Identification				
Hide parts with no conflict	Make parts where no collision is detected invisible after the analysis			
Color triangle	Color triangles where collision is detected			

8.8 Supports

8.8.1 Generate Support



Select a part on the platform and click this button to automatically generate support structures and enter Support Generation mode.

Materialise nv | Technologielaan 15 | 3001 Leuven | Belgium | info@materialise.com | materialise.com innovators you can count on





8.8.2 Generate Support of Selected



Generate support for selected parts without entering the support generation mode. To generate the supports, Magics Print Metal will utilize the support parameters which are found within the actual platform

9 Fixing

9.1 Errors explained

Some examples of common problems



9.1.1 Inverted Normals

In the STL format, a normal indicates the outside of a triangle. When the normal points to the wrong direction (the inside), the triangle needs to be inverted to have a watertight STL. This triangle is then called a flipped triangle.

9.1.2 Bad edges

To have a correct STL file, all edges of each triangle should be connected properly to a neighbor. If an edge is not connected properly, the edge is called a bad edge and is indicated with a yellow line. A group of connected bad edges will make a bad contour. The STL file will be sliced in a subsequent step. To process the slicefiles correctly, every slice needs to be closed. This is why Bad edges need to be fixed.





9.1.3 Bad contours

A group of bad edges connected to each other form a bad contour. E.g. the hole below has 1 bad contour that consists of 5 bad edges.

9.1.3.1 Near bad edges

Near bad edges are bad edges that are near other bad edges. These are mainly caused by 2 surfaces that are not well connected. You can recognize them as long yellow lines on the part. You can fix them easily by stitching. Stitching is an automatic operation that will unite two neighboring triangles which both have a bad contour right next to each other.



9.1.3.2 Planar hole

A hole consists of missing triangles. Use fill hole to fill it up. Magics is only able to recognize planar holes, which are recognized by the open contour which lies more or less in one plane. Holes caused by more irregular contours will not be recognized by Magics and be shown as a bad contour.





9.1.4 Intersecting triangles

Intersecting triangles are triangles cutting each other. It can happen sometimes that the STL surface has intersections. Depending of the application of the STL file, it's advised to remove the intersections. You can remove them with the Unify function on the Triangles Page.





9.1.5 Overlapping Triangles

An STL-file sometimes has overlapping triangles. These triangles can be removed with the tools in the double surfaces page. 2 triangles are considered as overlapping as:

- The distance between them is smaller than the given tolerance. (E.g. 0,1 mm or 0,005 inch)
- The angle between the normal of the triangles is smaller than the given angle. (E.g. 5°)

Take into account that some "false alerts" may occur. When the triangles comply with the parameters, they will be marked as overlapping triangles, even when they are part of the geometry.

9.1.6 Shells

A shell is a collection of triangles connected to each other. Normally a part has only one shell because every triangle of the part is (indirectly) connected to every other triangle. Parts with:

1 shell	2 shells	2 shells
Every triangle is connected to each other.	The cylinder is not connected properly to the part. The overlap between the two shells can cause build failure. This can be solved with a Unify.	The part is hollow. The inner shell is not connected with the outer shell. This is normal with hollow parts.

9.1.7 Noise shells

Some shells have no geometrical meaning and are considered as noise (waste) that we can throw away. However, it is recommended to look at these shells first before removing them. Even a shell of a few triangles can be important.

9.2 AutoFix

AutoFix

The autofix option will execute a predefined list of repair actions. Some actions are conditional, this means that the action will only be performed when Magics Print Metal is sure that the result will be ok.



42



Manual 9.3

9.3.1 Fill Hole mode



Click to activate. You can now click on holes to fill them.



9.3.2 Create Triangle

Click to activate. You can now manually create a triangle.



Create Bridge

Click to activate. You can now manually create bridges.

9.3.4 **Delete Triangle**



Click to activate. You can now click on triangles to delete them..

9.4 Enhance

9.4.1 Triangle reduction



Magics Print allows you to reduce the number of triangles in an STL file. This makes it easier to manipulate the file.

Reduction







Smallest Detail	If 2 triangles are replaced by one triangle, there may be a little deviation in position. The tolerance indicates the maximum deviation allowed between the original surface and the new one.
Max Angle	The Max Angle value defines two limits: When two triangles have an angle value bigger than Max Angle, they may not be reduced. The edge between them may not be eliminated; otherwise too much geometrical information would be lost. When the program meets such an edge, the reduction will keep the edge but reduce the number of points on it. When there is no critical edge, this Max Angle value determines the maximum angle that can be created during the reduction. This means where there is an edge present, there will remain one. Where there is no edge, no edge will be added.
Number of Iterations	Magics can perform the operation in different iterations to improve the reduction of triangles. It is better to increase the number of iterations than performing the triangle reduction twice (to maintain the smallest detail).
Keep Textures Intact	Textures on the part stay intact. Some triangles may not be filtered out due to texture that is kept.
Keep Colors Intact	Colors on the part stay intact. Some triangles may not be filtered out due to color that is kept.

Notifications

It is advised not to use the reducer on very noisy objects. If the tolerance and angle values are too big, essential part information may get lost.





10Edit

10.1 Rescale



A part can be rescaled with different factors in the three main directions or set to a certain size in the three main directions

10.1.1 Factor

😪 Rescale Part(s)							×
Factor X 1,00000 Y 1,00000 Z 1,00000	* * *	Resulting size 24,638 18,778 30,736	, mm mm mm	Difference 0,000 0,000 0,000 0,000 0,000 0	mm mm	Original size 24,638 18,778 30,736	4 ¥ 4 ¥	mm mm mm
🗌 Make Copy				Show Previ	ew			
Match meas	urem	ent						
Rescale Fac	tor Li	brary						
Rescale Cer	iter							
					Арр	ly	Clo	5e

The factor is a multiplying value for the dimensions in that direction. When the factor is 1, no rescaling is done, when the factor is 2, the size is doubled. A factor bigger than 1 will enlarge the part, a factor smaller than 1 will shrink the part.

Factor		Resulting s	size		Difference			Original siz	ze	
X 1,00000	÷	24,638	* *	mm	0,000	÷	mm	24,638	* *	m
Y 1,00000	÷	18,778	* *	mm	0,000	÷	mm	18,778	* *	m
Z 1,00000	¢	30,736	÷	mm	0,000	÷	mm	30,736	÷	m
Match mea	asuren	nent								
Make Copy					Show F	Previe	w			
Rescale Fa	actor L	ibrary								
Rescale C	enter									

10.1.2 Resulting Size

The resulting size column has a dual function. First of all it is showing the actual dimensions of the selected part but it also allows to set the dimensions of the part in the 3 main directions in absolute values

10.1.3 Checkbox Options

Uniform Rescale	The rescale factor is identical in all directions
Show Preview	Checking this box will show a preview of the rescale
Make copy	Make a copy of the original part before resizing or rescaling

10.2 Hollow part



The result of the hollow part operation is one STL file with two shells: the original shell and a new one that gives the part a thickness. The new shell is build from triangles whose size is determined by the parameter smallest detail. You can select several parts and make them hollow in one operation.



45





Wall Thickness	This value displays the distance over which the triangles of the original shell get an offset in order to generate a hollow part.
Detail Size	This value displays the level of detail that will remain in the new shell. Standard, this value should be the same as the smallest detail of the part. The smaller this value, the more triangles will be included in the new shell and the more detail can thus be incorporated. <i>Remark:</i> If the smallest detail is chosen too high, it is possible that the internal wall intersects with the external wall.
Туре	Here you determine if you want to create a new shell at the interior or at the exterior of the existing shell
Memory requirements	While you set the parameters, Magics Print Metal makes an estimation of the quantity of free RAM that will be needed during the calculation and of the number of triangles that will be created. You'll need to enter new values in the Wall Thickness and Smallest Detail fields to see a new estimation of the amount of RAM and new triangles. The amount of triangles can later on be reduced with the Triangle Reduction function.





10.3 Perforator



With this command you can make perforations trough your parts. The perforation is defined by a flattened cone that will be subtracted from the part, thus creating a perforation. This is especially useful if you work with hollow parts.

Perforator



Add			12
Remo	/e		
Hold Shift to Remove mod	enter e		
Perforation siz	e	•	
Radius outer	circle (r2)	1,000	mm
Radius inr	er circle (r1)	0,500	mm
○ Angle (a)		3	•
Use Notch			∧ ^b
Width (b)	0,500	mm	\vec{k}
Height (c)	0,500	mm (^a	VY
Angle (a)	0	•	
Keep Subt	racted Parts wanted Intersecti	ons	

Add	When clicking 'add' the perforation is being drawn when you click on the part. The hole is not immediately being subtracted.To have a better look where the cone will be placed a blue preview is shown.The "Add" mode is enabled by default when opening the Perforator function.					
Remove	Unwanted perforations can be deleted when pressing this button. While in the "Add" mode, it is possible to hold down Shift to activate the "Remove" mode.					
Perforation size						
	Radius outer wall (r2)	Here you determine the radius of the outer circle of the perforation.				
	Radius inner wall (r1)	Here you can determine the radius of the inner circle of the perforation.				
	Angle	Here you can determine the angle of the perforation				
Use notch	You can choose to add a small notch. The notch is defined by the parameters Angle, Width and Height.					
	Width					
	Height					





	Angle	Width Angle Height			
Keep subtracted parts	When checked are unloaded a	d, the subtracted part(s) are kept. If not checked subtracted part(s) automatically.			
Subtract	The perforatio	n takes place.			
Detect Unwanted Intersections	Collisions will	Collisions will be detected when a cone is added. Default on. (See remark)			



Notifications

When you want to make a perforation, Magics Print might detect that an <u>unwanted</u> <u>intersection</u> will take place.







10.4 Cut or Punch

With this command you can cut parts. Magics Print Metal only provides a basic section cut

Cut or Punch			×
Section			
Type of section cut:		Basic	~
Cut Visible Sectio	ns		
Cut Visible Triang	les		
O Cut Selected Con	tours		
Clearance	0,200 n	ım	
Clearance Direction	Inside	\sim	
Indicate Contour	Rese	ŧt	

10.4.1.1 Cut Visible Sections

If you define some sections, you can make a cut along all these sections. For more information about how to define sections, please see <u>Sections</u>.

In the figure below, an X, Y and Z section are defined. If you select 'Cut Visible Sections' this is what happens:





Total Clearance	If you would like to have a little cutting line, you can add a cle both sides.	e gap between the two parts that result from the earance. This either to the inside, outside or on
	Inside	Clearance inside
	Outside	Clearance outside
	Both sides	Clearance/2





10.4.1.2 *Cut Visible Triangles*

If you have defined a section (<u>Sections</u>), you can clip and flip to visualize only the part behind or before the section. With the Cut Visible Triangles function, you can cut out the visible part. It is possible to make different combinations of sections, with each their own clip or flip.

In the figure below, three sections are defined, and a clip is applied on each of them so only the part before the section is made visible. By selecting cut visible triangles, the visible part becomes a separate part.



10.4.1.3 *Cut Selected Contours*

If you have defined a section, and you only would like to cut away some parts at one side of it, you can do so with the cut selected contours function. Select the contour (the intersection line between the part and the section) you would like to cut with the Indicate Contour button and press the Apply button.

In the figure below a Z section is made. The contour on the right is selected, so only the right 'leg' will be separated from the main part.



If you have indicated a section, and you would like to erase the indication, you can use the Reset button.

10.5 Extrude (PRO feature)



This command allows you to extrude triangles in a certain direction. Before the extrusion, you first have to mark the triangles you'd like to extrude. All marked triangles are moved in the same direction, over a defined distance.



50



Extrude	—
Offset 0,000 Connection Move Points Add Triangles Automatic	m
Modify Extrude Direction	
	Apply Close

Offset	The user must specify the extrude offset. Each triangle will undergo an offset in the defined direction over a distance defined by this value. The area of the surface formed by the triangles that are extruded will stay the same after extrusion.	
Connection	MoveThe triangles adjacent to the selected triangles will be redrawn. They are stretched like shown in the figure below. The common points are moved. The area of the surface formed by the triangles that an extruded will stay the same after extrusion. The slope of the adjacent triangles will change a bit.	
	Add Triangles	The triangles adjacent to the triangles that are extruded stay the same. The common points of the selected and adjacent triangles remain on their position. The gap between the latter and the triangles that have undergone an offset is filled with new triangles. This is shown in the figure below.
	Automatic	The program will make the choice between Move Points or Add Triangles.

Original part





Add triangles







1.3.1.1. Modify Extrude Direction



Vector	You can give in direction coordinates in the X, Y and Z field.
Indicate Line	You can click the Indicate Line button and afterwards click on a line. The extrude offset will be in the direction of the line.
Indicate Triangle	You can click the Indicate Triangle button and afterwards click on a triangle. The extrude offset will be the direction of the normal of the triangle.

10.6 Label



This feature allows you to put text on a part. First you need to indicate the area where you want the label to be applied. There are 2 options for the label: rectangular or circular.

Label





Indicate the area on the part where I	abel will be applied
Rectangular label	O Circular label

The rectangular label area needs to be defined by clicking on the part and drawing a rectangle. In the picture point 1 is the starting point of the rectangle, point 2 is the end point. This rectangular area can then be used as label area. Make sure the label area completely fits on the part. A warning message will be shown when the label doesn't fit on the part.



The circular label area needs to be defined by defining 3 points to define the main circular shape. The fourth point will define the size of the label area. The fifth and sixth click will determine the start and end point of the label area.







Label	\times	
Test		
lext		
Indicate the area on the	part where label will be applied	
Rectangular label	O Circular label	
Laber content		
Part Name	Times New Roma - B I U No color -	
Remember current 1		
	ext	
☐ Auto-partname		
✓ Fit text to label boun	daries	
Font size 12,0	pt 4,234 🗘 mm	
Height 1,000 ‡	mm Raised Engraved	
Advanced		
Auvanceu		
Delete	Apply STL Save planning Close	
pel content	Specify in this box the text which should be used as label content.	
rt name	Pushing this button will automatically add the current part name to the labe	
	content.	
nt .	Specify the font type for the label.	
d	Select if the font should be Bold.	
IC dorlino	Select if the font should be Italic.	
	Select II the font should be Underlined.	
member current	The last entered value will be remembered the next time the labeling	
t	functionality is used.	
to-part name	Not available in Magics Print Metal	
nt Size	Specify the dimension of the label text.	
text to label	Overrules the size specification and will use the maximal possible size of the	
undaries	text in the label planning area.	
ight	Specify the height of the label (in or outside).	
ised/Engraved	Specify if the label needs to be raised (outside) or engraved (inside).	

Advanced options

▼ Advanced	
Flip	
Mirror	
Label through	
Automatically update preview	
As separate STL	





Flip	The label content will be flipped before being applied.
Mirror	The label content will be mirrored before being applied.
Label through	Use this option to label multiple parts at once with the same label. Make sure the parts are aligned perpendicular to the view
Automatically	The content of the label content textbox will be automatically updated in the label
update preview	planning area.
As separate STL	The label will be generated as a separate part.

Delete	Apply STL	Save planning	Close
Delete	Lise this button to de	alata proviously dat	fined label plar

Delete	Use this button to delete previously defined label planning areas.
Apply STL	Pressing this button will generate the label and modify the STL.
Save planning	Pressing this button will keep the label planned, but not yet generate it as STL. It can still be modified in a later stage.
Close	Press this button to close the dialog.

10.7 Prop Generation



To avoid distortion on your part during building you can create 'props' to make sure that the shape of the part is kept.

Prop Generation

Prop Generation	
Add	b a
Prop Shape	
Square	
Strong-Section Width (a)	5,000 mm
End-Section Width (b)	2,000 mm
End-Section Length(c)	5,000 mm
Advanced	
	Apply Close Help

Add	When clicking add, the prop can be drawn on the part, but it's not yet created. To have a better look where the
	prop will be placed a preview is shown (Advanced)





Remove	Unwanted props can be deleted when pressing this button					
Prop Shape	Circle/ Square					
	The shape of prop of this cross s between a circle or a square.	ection can be changed				
Strong- section width (a)	The width of the circle/ square connector	a				
End- section width (b)	The width of the connection (in between the strong section and the part)	b				
End- section length (c)	The length of the connection between the strong section and the part.					

1.3.1.2. Advanced



Perform Boolean Unite	The part and prop(s) are united into one file and all surfaces are trimmed to make one shell of both parts.
Show Preview	While adding the props a preview is created of how the prop will be placed on the part

<u>*Remark*</u>: After creating the prop, it will be merged together with the part.





10.8 Structures (Additional Module)

The wizard consists out of 3 pages:

- Define outer Shell
- Choose Structure
- Add Drain Holes

1.3.2. Define outer shell

Create Structures						×
1 Define Outer Shell	🔘 No Outer Shell					
1. Denne odder onen	Outer Shell					
2. Choose Structure	Thickness	2,000	mm			
3. Add Drain Holes	Detail Size	2,000	mm			
	Direction					
	Inside			~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~		
	Outside					
	For this operation	on you will need	~3.1 MB o	fmemory		
	Reduce Tria	ngles of Core				
	Tolerance	0,050] mm		
	Angle	5,000] •		
	Number of Itera	ations 3]		
			0	50%	100	
	Smoothen C	ore				
		< Back		Next >	Cancel	Help



57



No outer shell	The part will be fully replaced by a lattice and will not					
	have an outer shell					
Outer shell	The part will receive a shell					
Thickness	This value displays the distance over which the triangles of the original shell get an offset in order to generate a hollow part.					
Detail Size	This value displays the level of detail that will remain in the new shell. Standard, this value should be the same as the smallest detail of the part. The smaller this value, the more triangles will be included in the new shell and the more detail can thus be incorporated. <i>Remark:</i> If the smallest detail is chosen too high, it is possible that the internal wall intersects with the external wall.					
Direction	Here you determine if you want to create a new shell at the interior or at the exterior of the existing shell.					
Memory requirements	While you set the parameters, Magics makes an estimation of the quantity of free RAM that will be needed during the calculation and of the number of triangles that will be created. You'll need to enter new values in the Wall Thickness and Smallest Detail fields to see a new estimation of the amount of RAM and new triangles. The amount of triangles can later on be reduced with the Triangle Reduction function. The memory requirements depend greatly on the value set for Smallest Detail.					
Reduce triangles c	f Because the hollow function creates a lot of triangles,					
Core	you have the possibility to reduce these at once.					
	Tolerance <u>Triangle Reduction</u>					
	Angle					
	Number of Iterations					
Smoothen Core	By checking this option a smoothing will be					
	performed on the created core.					





1.3.3. Choose Structure

Create Structures				—
 Define Outer Shell Choose Structure Add Drain Holes 	Choose Structure body diagonals with Cross Cross-1 Cross-2 Cross-3 Cross-3 Cross-X Cross-X_reenforce diamond 30 percent diamond 30 percent	th nodes r	Structure Preview	
	Add Structure Dimension X Y 10 Z 10 Advanced Options 2 Advanced Options 2 Advanced Options 3 Advanced Options 3 <th>Delete</th> <th>mm mm Mm Add Current Struct Start position X 0,000 mm Y 0,000 mm Z 0,000 mm</th> <th>ture to Library Angled Growth X 0,000 ° Y 0,000 ° Z 0,000 ° s, but may deform small</th>	Delete	mm mm Mm Add Current Struct Start position X 0,000 mm Y 0,000 mm Z 0,000 mm	ture to Library Angled Growth X 0,000 ° Y 0,000 ° Z 0,000 ° s, but may deform small
		< Back	Next >	Cancel Help

Choose Structure	This shows a library with unit structures that can be used for lattice generation.					
	Add Add structures to the library					
	Delete	Delete structures from the library				
	Structure Preview	A preview of the unit structure is shown				
Structure Dimensions	Here you can specify the length in X, Y and Z of the unit structure					
	Keep Aspect Ratio	When this is checked the Y and Z length will be rescaled uniformly with the X length				
	Invert Structure	Instead of converting the part by the lattice, the lattice will be subtracted from the part				
	Sample Data to Process	The amount of memory necessary to create specified lattice				







Advanced Options	Spacing	A spacing will be given between the bounding boxes of the unit structure
	Spacing	
	dX 0,000 mm	
	dY 0,000 mm	
	dZ 0,000 mm	
	Start position	The start position of structure can be defined
	Start position	
	dX 0,000 mm	
	dY 0,000 mm	
	dZ 0,000 mn	
	Angled Growth	The whole lattice will be generated under specified angle
	Angled Growth	7 MAT HUR MUS AND AND THE SAID
	X 0,000 °	
	Y 0,000 °	
	Z 0,000 °	
.3.4. Add Dr	ain Holes	





Create Structures		×
1. Define Outer Shell 2. Choose Structure 3. Add Drain Holes	Add Remove	
	Perforation size Radius Quter Circle 1.0000 mm	
	Radius inner circle (r1) 0,5000 mm	
	© Angle 3 °	
	Use Notch Width (b) 0,500 Height (c) 0,500 Angle (a) 0	
	Keep Subtracted Parts Detect Unwanted Intersections Advanced Options	
	Image: Wight of the state	
	< Back Finish Cancel Hel	p

Add		When clicking add the perforation is being constructed but not yet subtracted.				
Remove		Unwanted perforation can be deleted when pressing this button.				
Perfo	ration size	Define the size of the perforation				
	Radius outer circle (r2)	Here you determine the radius of the outer circle of the perforation.				
	Radius inner circle (r1)	Here you can determine the radius of the inner circle of the perforation.				
Angle		Here you can determine the angle of the perforation				
Use n	otch	Define the size of the notch				
	Width (b)					
	Height (c)					





	Angle (a)	Width Angle Height						
Keep	subtracted parts	When checke not checked s automatically.	d, the subtracted part(s) are kept. If ubtracted part(s) are unloaded					
			000					
	With subtracti	ons	Without subtractions					
Detect interse	unwanted ections	Collisions will be detected when a cone is added. Default on. (See remark)						
Advan	ced options	1						
	Show preview	When checke	d a preview of the perforation is shown					
	Total clearance	Define an offs sides of the in This way you parts that resu	et towards the inner, outer or both tersecting line between the parts. introduce a little gap between the ult from the perforation.					
	Inside	Clearance inside						
	Outside	Clearance outside						
	Both sides	•	Clearance/2					

11 Scenes and Machines

11.1 Scenes







With Scenes, platforms can be created to prepare your build. It gives you a workspace where you can orientate and position your parts in the same way as they should be built by the machine. A lot of parameters can be stored in such a scene. Your Magics Print software will come with the optimized parameters for the machine you have purchased. You can also work on different platforms in parallel. The active scene is the one showed on the screen. You can switch between different scenes by clicking on the name of the platform in the main window (see picture below).

FILE	TOOLS FIXIN	IG EDIT	SCENES	& MACHINE	es su	PPORT GENER	ATION	YLM-120	VIEW	& ANALYZE	OPTIONS & HELP
	\$	\$	67	V	1						
New Scene	Create Scene from Modeler Scene	Add Part to Scene	Move Part To Scene	Duplicate Scene	Unload Scene	Machine Properties	Change Machine	Build P Mar	rocessor nager		
		Scene	5				Machin	nes			
	😵 Modeler Scene	B.Proc.:	Standard LM	Machine (1)	📱 В	.Proc.: Standa	rd LM Machi	ine (2)			

In Scenes, platforms are handled. The available platforms will correspond to the machine portfolio of your machine manufacturer. If a new scene is generated, you can see that a second tab "modeler scene" is opened. The modeler scene can be recognized by its different background color and a lack of platform. Every part that is imported into Magics Print, will be visible in the modeler scene.

To orientate a part on the platform Indicate top or bottom view can be used. There is also a collision detection tool (see Collision Detection) to see if the parts are well positioned on the platform. The automatic placement tool (see Automatic Placement) makes it possible to easily and economically position different parts on the platform.

11.1.1 Scenes: Virtual Copies

This section will explain what virtual copies are and how you have to handle them.

The goal of using virtual copies is to save memory. If you need e.g. 100 copies of a part, there will be a big difference in memory usage if you have to load (and save) 100 parts or only 1 part.

11.1.2 A Part and his Virtual Copies

The real parts are collected in the modeler scene. The modeler scene acts as the database of loaded parts. From this database you can create virtual copies on platforms. This virtual copy contains a reference to the real part and a translation matrix. To make it possible and user friendly to work with virtual copies, the structure of parts and copies is as shown in the picture below.

Example

The picture below shows an example of the principle of real parts and their virtual copies. This example will be used in the next sections to illustrate the behavior of parts and virtual copies.







In this example:

The modeler scene contains 2 real parts, i.e. part A and part B. Platform 1 contains 1 virtual copy of part A and 1 of part B. Platform 2 contains 2 virtual copies of part B.

The arrows on the picture below, indicate that *"Copy of Part B"* is based on the real *"Part B"* from the modeler scene.

11.1.3 Edit a Virtual Copy

If you edit a real part (in the modeler scene), all virtual copies of that part, present in the current Magics session, will be edited in the same way.

Example

Suppose you select and edit one of the virtual copies of part B on platform 2.Magics will ask if you want to apply the changes only on the selected copy or on all virtual copies of part B present on platform 2. If you apply the changes only on the selected copy, this is the result:







A new part is created in the part database. The edited copy will refer to a new real part. If you apply the changes on all virtual copies of that mother part, this is the result:



All the virtual copies of the same mother part, present on that platform, will refer to a new database part.

11.1.4 Naming of virtual copies

Virtual copies inherit the name of the mother part when it is created. Within the platform scene however, virtual copies can be assigned with a unique/ different name.



65



Example



Notification

Editing virtual copies is only possible for virtual copies of the same mother part and present on the current platform! This is for safety reasons. If you want to edit all virtual copies of the same mother part, present on all the platforms, you should edit the part in the Modeler Scene.

Names of virtual copies change when the name of the mother part (in the Modeler Scene) is changed, even if virtual copies are already renamed. The part status however stays the same.

11.1.5 Advised ways of working

Method 1: Working in platform scenes

When you open Magics Print Metal, the modeler scene will be present. Create a new Platform Scene, then load or create a part. In the background this part will be loaded in the Modeler Scene (part database) and immediately a Virtual Copy of that part is created on the platform. You can edit and prepare this part in the Platform Scene. Each operation you do on the copy in the Platform Scene will automatically be performed on the real part in the Modeler Scene.

11.1.5.1 Multiple Copies

If you want to build more than one copy of a part on that Platform, you can duplicate the part (see Duplicate). Most advised is to create the copies after you finished the preparation of the files. Otherwise, Magics Print will ask for each operation if you want to apply it on all copies or only on the selected ones. (If you select all copies, of course, the message won't be prompted).



66



11.1.5.2 Hide Modeler Scene

Because you can perform each operation on Virtual Copies, it can be less confusing when you hide the Modeler Scene. To hide the Modeler Scene, type "Modeler Scene" into the 'Quick search' bar and click on 'Modeler Scene'. To make the Modeler Scene reappear, repeat the previously mentioned process.

Method 2: Prepare files in the Modeler Scene and assign them to a Platform Scene.

You can also work in the opposite way. This means that you load all parts in the Modeler Scene, you prepare the files in the Modeler Scene and afterwards you assign the parts (read: create Virtual Copies) to the Platforms.

The disadvantage of this method is that you cannot perform machine dependent operations, e.g. translate to default position, in the Modeler Scene.

The advantage of this way of working is, when you need to edit a part that need to be built on different platforms, you only have to edit it once.

Of course, you can use a combination of these two methods, depending on what you want to do in Magics Print. Combining these two methods will give you the most added value, i.e. preparing your builds in a very fast and flexible way!

11.1.5.3 Scenes: Platform Operations



11.1.5.3.1 New Scene

With this function, you create a new Platform Scene in the main window. You have to choose the machine of which you want to create a Platform Scene. It's also possible to select a specific support profile directly from this window. If you create more than one platform for the same machine, the platform name will be the machine name extended with a number, e.g. '[Machine name] (2)'. You can organize machines via drag and drop.

11.1.5.3.2 Create Scene from Modeler Scene



Choose the machine for which you want to create a Platform. Then, for each of the parts present in the Modeler Scene, a Virtual Copy will be created on the current platform.





11.1.5.3.3 Add Part to Scene



This operation opens a window showing all the parts loaded in the Modeler Scene. Here you can select from which of these parts you want to assign a virtual copy to the active Platform Scene. If the parts you selected don't fit inside the platform, a message will appear indicating a solution will be found but outside platform borders.

Add	Part to Scene		×
V	Part Name bg sultan griffes x3 ob		
		OK Cancel Hel)

11.1.5.3.4 Move part to Scene

This function lets you easily move selected parts from the modeler scene to any of the loaded platform scenes. A platform machine dropdown list is shown with all available scenes.

11.1.5.3.5 Duplicate Scene

This operation creates a Platform Scene, identical to the active Platform Scene. The Platform name will be the machine name extended with a number, e.g. '[Machine name] (2)'. If the platform contains parts, the parts will also be copied to the new atform

platform.

11.1.5.3.6 Unload Scene

With this operation you can unload the active Platform Scene. If there are virtual copies present on the current Platform Scene, Magics will pop up following dialog box:

Magics	×
?	Save changes to Untitled?
	Yes No Cancel

Yes	Magics proposes to save all parts in a project file before unloading the scene. After saving all parts/ copies are unloaded.
No	The scene is unloaded without saving any parts/ copiers





11.2 Machine

11.2.1 Machine Properties



This function will open the Machine Properties dialog of the active Platform. The machine properties contain all the information related to the chosen machine type.

10.2.1.1 Machine Information Properties

Machine Properties : StandardImage Build Processor X					
Machine information Machine information Machine information Compensation Support parameters Save changes in:	Machine information Machine name Material name Comment	Standard]mage Build Processor			
Active platform scene 🗸 All platform scenes al	ike Machine librar	y	OK Cancel	Apply Help	

Machine Name	Each machine type has a name. If you are building with different parameters, it is best to have a machine type for each set of parameters (e.g. layer thickness).
Material name	The material of the selected machine.
Comment	Comment on the selected machine.

11.2.1.2 *Platform properties*

Machine Properties : StandardImage Build Properties : StandardI	rocessor	×
Machine information Machine information Default part position Automatic Placement Fields No-Build Zones Silce visualization Z Compensation Support parameters	Pladorm	
Save changes in:	e Machine library	OK Cancel Apply Help





11.2.1.2.1 Default part position

Machine Properties : StandardImage Build Processor						
Machine information Default part position						
 Platform Default part position 	Minimum x	10	mm			
Automatic Placement	Minimum y	10	mm			
Fields No-Build Zones	Minimum z	10	mm			
Slice visualization						
Z Compensation	Z Compensation					
Support parameters						
Dimensions The minimum X, Y and Z value of the part on the platform.						

11.2.1.2.2 Automatic placement

III Machine Properties : StandardImage Build Processor						
Machine information Platform Default part position Automatic Placement Fields No-Build Zones Slice visualization Z Compensation Support parameters	Automatic Placement Bounding Box Geometry Based Part Interval Platform Margin Placement First Possible Solution Minimal Surface Area Minimal X-Dimension Platform Center	Enable Multi-Platform Nester				

Allows the automatic placement on multiple platforms.			
Automatic Placement Bounding Box Geometry Base Part Interval Platform Margin Placement Solution First Possible Minimal Surfa Minimal X-Dim Minimal Y-Dim Platform Cen	ed 10 mm 10 mm Solution ce Area lension lension ter		
Part interval	The interval between parts		
Platform Margin	The margin of the platform		
	Allows the automat		





Geometry Based	Automatic Placement	The placement solution that will be applied: First Possible Solution Minimal Surface Area Minimal X-Dimension Minimal Y-Dimension Platform Center		
	Part Interval	5 mm		
	Platform Margin	5 mm		
	Placement Solution First Possible Minimal Surfa Minimal X-Dim Minimal Y-Dim Platform Cen Custom Part I Part Placement Part Placement Only Translate and Only Translate	Solution ce Area ension ension ter Placement I Rotate Parts e		
	Part interval	The interval between parts		
	Platform Margin Placement Solution	The margin of the platform The placement solution that will be applied:		
		First Possible Solution Minimal Surface Area Minimal X-Dimension Minimal Y-Dimension Platform Center Custom Part Placement How the parts are placed: Translate and rotate Parts Only Translate		
	Part Placement			





Custom Part	Oustom Part Placement			
Placement	Part Placement			
	Translate and Rotate Parts			
	🔘 Only Translate			
	Load Image Export Platform Image			
	Note: Any loaded image will be converted to gray			
	and scaled to the platform			
	Image weep't leaded			
	illiage wash (loadeu			
	Lighter: low priority Darker: high priority			
	Accuracy: 50			
	Show the image on the plaform			
	Load an image that can be shown on the platform. The darker			
	areas indicate higher priority, while the lighter areas indicate			
	lower priority.			
	Export the Platform image to get an image with the correct			
	platform dimensions, that you can immediately edit.			
	Lower accuracy will be laster, but the image used for the			
	give a more detailed image, but might be clower			
	give a more detailed image, but might be slower.			

11.2.1.2.3 Fields

Fields							
Voverlap 1	X Position	0,000	mm	Width	0,000	mm	
Overlap 2	X - Position	0,000	mm	Width (0,000	mm	

11.2.1.2.4 No Build Zones

The No Build Zones page allows you to define cylindrical, rectangular and STL shapes on the platform that indicate no-build zones.






With following controls you can manage the no build zones:



Add a shape to the platform as no build zone



Remove a shape from the platform as no build zone



Add a STL to the platform as no build zone



Copy the no build zones from another machine

11.2.2 Z Compensation





Machine information	Z Compensation			
 Platform Slice visualization Z Compensation Support parameters 	Default Value 0,1250 Advanced Options	mm		
	Triangle Based	0.0010		
	E Feature minimai z-t	nickness 0,0010	mm	
	O Point Based			
	Remove Self-Inters	ections		
	Add Z-Compensation v	alue to part name		
	Use Angle based Corre	ection factor		
	0° 1,0000	x 0.125 = 0.125	mm	
	15° 0,7400	x 0.125 = 0.0924999	mm	
	30° 0,5000	x 0.125 = 0.0625	mm	
	45° 0,2930	x 0.125 = 0.0366249	nm	
	60° 0,1340	x 0.125 = 0.0167500	nm	
	75° 0,0340	x 0.125 = 0.0042500	mm	
	90° 0,0000	x 0.125 = 0	mm	
	Filter sharp triangles			
Sava shangaa in				
oave changes m.				
Active platform scene 🗸 All platform s	cenes alike Machine library		ОК	Cancel Apply Help

11.2.3 Change Machine



If you want to change the machine of the active Platform Scene, you can do this with this operation. The Select Machine dialog will pop up and you can choose another machine and another support profile for this machine.

Change Machine

11.2.4 Build Processor Manager

3D Printers								
🕂 Add a 3D Printer	Open <u>Q</u> ueue	Properties	🔦 Configure	>	Ð	÷. •	S 🕐	
	Standard LM Local N/A 0 build jobs	Machine					•	•
5 printer(s)								

The Build Processor Manager gives the user an overview of all the machines that are compatible with the user's version of Magics Print.

12 Support Generation

Support generation is important in Metal 3D printing. Generating support structures quickly and easily is crucial in Rapid Prototyping. Final part quality depends on verifying and adapting the





supports you've generated. Magics Print offers several support types and combinations of these different support structures on one surface.



12.1 Introduction

Magics Print for Metal is equipped with a module for support generation. The support generator allows you to generate supports for a whole platform and then edit the support on each surface individually. This support generation work routine allows you to easily adapt supports, also after the part has been replaced on the building platform.

Support is only needed on certain surfaces. The selection is based upon the selection parameters from the Machine Properties (1: Support generation parameters). Magics Print Metal selects these surfaces when entering the support generation module (2: Automatic support generation). Once you've arrived in the support generator module, Magics Print allows you to adapt the support to your needs (3: Modifying surfaces, support types and parameters). The support generation parameters are crucial during the initial automatic support generation but can be modified for each individual support. In the first place you can adapt the construction parameters, which are interactively defined in the Machine Setup. This interactive change applies only to the active support. The active support is the one that is visible on your screen or when you made them all visible, it is the one with a different color (the bad edges color; default yellow). Secondly you can remove parts of the support in 3D or remove and if necessary redraw portions of the support in the 2D-edit window. At last you can save or export the support you've made.

Schematically a support is generated in the following steps:

- Definition of the selection and the construction parameters in the Machine Setup;
- Automatic support generation;
- Modification of the support types and construction parameters;
- 2D and 3D editing of the supports;
- Saving and exporting the supports.

12.2 Support Generation ribbon

12.2.1 Generate support





Generate Support

Easily create support structures on your part. Simply chose your platform, place your parts and generate your support one by one or multiple copies at the same time.



12.2.2 Generate support of selected



Generate support for selected parts without accessing the support generation module. To generate the supports, Magics Print will utilize the support parameters which are found within the actual platform.

12.2.3 Manual support



Let Magics Print Metal subdivided your part into the different surfaces that need support. Within the support generation module you can manually create the needed support structures for the already existing surfaces.

12.2.4 Supported area preview



Before generating your support within the support generation module, you can in advance visualize the areas that would need support. Based on the surface angle, Supported the supported areas are indicated with color codes. Additionally it is possible to Area Preview highlight the down facing edges. When checking the 'Show support preview' checkbox, a provisional display of the support is visualized. At the same time of the visualization you can change the surface angle or re-position your part based on the analysis of the surfaces and edges.





Supported area preview		×
Surface Angle	30,000	Colors
 ✓ Highlight downfacing edges ✓ Show support preview 		Mark Highlighted
Surface Angle currently store	ed in active Machine Pr	roperties 30.000°
		Close

Surface Angle	Adjust the surface angle and see immediately on your part how the surfaces that need support change.
Colors	Change the colors to visualize the areas which need support Supported Area preview End color range Begin color range
Mark highlighted	Marks the highlighted areas.







12.2.5 Unload support

Unload generated supports of parts that are selected.



12.3 Support Parameters – Machine properties

12.3.1 Support parameters profile

Magics Print Metal offers the possibility to manage different support parameters profiles for the same machine. This represents something useful when working with different kind of parts, different materials or different part size which might request different supports and parameters.

Machine information	Support parameters	
Platform	Current selected profile:	
Z Compensation	Etandard I M Machina	
Support parameters		
General		
Point		
Line		
Line*		
Block		
Cones		
Cones*		
Tree*		
Save changes in:		
Active platform scene 🖉 All platform scenes alike 🗌 Mac	ine library OK Cancel Apply Help	

Create new profile	Create a new support profile for the selected machine.
Copy profile	Use an existing profile to create a new profile by copying. After copying the profile you can make the needed modifications. Make sure to save your modifications to the 'Machine library'.
Load profile	Load an already existing profile into your instance of Magics Print. Profiles generated on other systems can also be loaded.
Rename profile	Add a new name for the profile







Delete profile	Remove a profile from the list when it is no longer used
X	

12.3.2 General

Useful feature for those who want to mark specific areas for support and do not want to wait too long for auto-generating of support surfaces which are not needed. Disable "Automatically Generate support surfaces at Manual support" to not calculate and generate these support surfaces in your support list.



12.3.2.1 Support Format

Defines how supports are handled when exiting the support module

Support Format	
Solid supports:	
Keep as stl on exit	filename *_ex.ext •
Merge with part on exit	
Non-solid supports:	
Keep as stl on exit	filename *.ext
Merge with part on exit	
Thickness 0,000] mm
Apply stitch	
Apply triangle reduction	
Apply unify (will be done before merging the solid	d supports)





12.3.2.2 Surface Selection

Surface angle					
Selection angle	30	•			
This angle determines support generation.	which surfaces	will be selected for			
If the angle is below th above this value the s self-supporting and su	nis value, supp urface is consic pports are not	orts are generated; lered to be required.	70° 45° 31	0° 15°	

Selection Angle	The Selection Angle defines which triangles are selected for support
	generation and which are not. It is defined as the angle between the horizontal
	plane and the surface. Surfaces whose angle to the horizontal plane is bigger
	than the selection angle are supposed to be self-supporting. This angle can be
	changed individually for each supported surface in the Support Generation
	Module (see Modifying Surfaces, Support, Types and Parameters).





Surface filter



Surface filter	Noise in the STL file can give rise to a huge amount of surfaces. The Surface Filter will filter out all surfaces which are smaller than this parameter, and which are supported by at least one other triangle. These surfaces will not be visible in the interactive support generator.
Unconditional surface filter	The unconditional surface filter will filter out all surfaces smaller than this parameter, also those that are not supported by other triangles.
Sharp edge filter	Magics Print will support sharp down facing edges or points in the STL-file, in cases where there is no complete down facing surface available like for example in the following figures:
	The surface area of a sharp edge support is 0. Consequently these sharp edges will be found at the end of the surface list in the Support Generation Module. This functionality is very sensitive to STL noise. STL noise can create a lot of situations in which sharp edge supports are placed. The Sharp Edge Filter will minimize the effect of STL noise and avoid unnecessary supports. The value of the Sharp Edge Filter determines the height of the details for which sharp edge supports will be generated. If this





	value is 0, all sharp edges will be supported. Typically you can set this parameter at the same value as the slice distance.
	SLODET SLOT
Maximum height	Surfaces higher than the maximum height will not be supported.
Auto merge surfaces	Surfaces with small sharp triangles can be automerged.

12.3.2.3 Type Selection

Support types			
Indicate the type of s None None Non-solid Point Point* Ine	upports that can be used for support generation.		
Support types	The user can define which types	of support are generated automa	atically.
_	·		
Point supports Define the maximum place a point suppor	size of a support surface where Magics will t.		



Point supports provide more stable support for small surfaces, while other support types may be too small or potentially unstable during the build process.

mm²







Point supports	A Point Support will typically be selected for very small surfaces, where a Block Support would be too small and unstable.	
	Maximum Area	A Point Support will be selected if the surface is smaller
		than the 'Max Area' defined on this page.

Line supports		
Define the maximum surfac support.	e size that car	n be supported with a line
Minimum thinness	50	(= Contour ² / Surface)
The thinness of the sur shape of the surface is Use this parameter to ir generation.	face area indi ; long small pa nfluence block	cates how narrow the rts have a high thinness. or line support
Maximum width	12	mm
A line support will be ge less than or equal to th value, Magics will gener this feature. Otherwise generated, for example Example of a thinness calcu	enerated wher is value. If the rate a more ef a different ty a a block supp lation:	n the width of an area is e width is greater this ffective support type for /pe of support will be ort.
1.000		
		11.000
Contour = 2 x 1mm + 2 x 1 Surface area = 11mm x 1m Thinness = contour ² / surfa	.1mm = 24mm m = 11mm ² ace = 24 ² /11	= 52.4







ľ	Minimum thinness	The thinness of the surface area must at least be equal to this value. The thinness indicates how narrow the shape of the surface is. It is calculated as the ratio of the square contour length and the area of the surface. With this parameter the user can influence the number of automatically generated line supports.
ſ	Maximum width	In order to receive a line support automatically, the average width of the surface area may not exceed this value.



Line*	Line* supports are a sp	becial kind of line supports. They support down facing edges.
supports	They do not support a	surface (the surface is 0 mm ² and contains 0 triangles).
	Point threshold	When the edge is shorter than the given length, a point
		support will be set.
	No support threshold	This filter will not put supports when the edge is shorter
		than the given length.

12.3.3 Common

12.3.3.1 XY offset







XY offset This offset defines how far the support must be from the border of the part.

12.3.3.2 Z offsets



Z offsets	All the supports can have a certain offset into the part in order to ensure a better contact between part and support.	
	Upper Z Offset	You can specify an offset in the supported surface.
	Lower Z Offset	You can specify an offset in the supporting surface.

12.3.3.3 No support offset





No support offset



No support offset	A (more or less) vertical wall gives support to another surface. For this reason, there is no support needed if there is only a very small overhang.		
	No Support Offset	You can define the distance up till where the vertical wall is supporting.	
	Minimum Height Supporting Wall	You can define the minimum height of the wall to be a supporting wall.	

12.3.3.4 Vertical wall offset

Vertical wall offset			
Vertical Wall Offset (a)	0	mm	
This feature ensures that supports d vertical wall. A small gap allows the s removed.	on't get place upport to be e	d on a easily	
			-





Vertical wall offset	In case a support is generated beside a vertical wall, the parameter Vertical Wall Offset makes sure a distance is kept between the vertical wall and the support. This avoids support being attached to the vertical wall and hence, unnecessary difficulties and marks on the part when removing the support.

12.3.3.5 Lowest line

Lowest line		
Draw Lowest Line Minimum Length When lowest line is cheor created so that this lowe connecting the lowest p	4 mm ked, an extra line of support is est line (the imaginary line oints of the surface) is supported.	h
Lowest Line	When placing a support under a curved surface, it can happen that the lowest line (= the imaginary line connecting the lowest points of the surface) is not supported correctly. This can cause problems when building the part with some RP-techniques. When lowest	

		inter (internitienginen) inte	
	connecting the lowest p	points of the surface) is not	
	supported correctly. Th	is can cause problems when	
	building the part with some RP-techniques. When lowest line is checked, an extra line of support will be placed so that this lowest line is correctly supported.		
	Due to the surface triangulation it can be that some		
	'noise' lowest lines pop up. In that case you can better		
	use the Local Minima.		
	Minimum Length	Lowest Lines smaller than this	
		length will be filtered out.	





12.3.3.6 Thickness (PRO feature)

iess et thickness for non-solid	supports	
Ipper teeth (a)	1,000 mm	a A THUR HUNDER
/all (b)	2,000 mm	
ower Teeth (c)	1,000 mm	
Trim at surface		ь
Trim Z offset	0,000 mm	
		c

Thickness	Set the thickness for non-solid supports.				
	Upper teeth (a)	The thickness of the upper teeth in mm.			
	Wall (b)	The thickness of the wall in mm			
	Lower teeth	The thickness of the lower teeth in mm			
	Trim at surface	The trim Z offset in mm			

12.3.4 Point

12.3.4.1 Current selected profile

For every support type, it is possible to have multiple profiles. Select, create, copy, open rename or delete profiles in the main tab of the support type.





Machine Properties : MachineInfo					
Machine information	Point				
Platform	Current selected profile:				
Z Compensation					
Support parameters	Point				
General					
Common					
Contact length					
Sunken ribs					
Teeth					
Number of Ribs					
Line Line					
Line*					
Block					
Cones*					
Tree Tree					
Tree*					
Save changes in:					
Active platform scene V Al platform scenes alke Machine library OK Cancel Apply Heb					







1	Load an	You can load any profile from the available machines.				
	existing profile.	Load Point Profile Profiles Profil				
A	Rename profile	Enter a new name for the selected profile.				
X	Delete profile Delete the selected profile. Image: Selected profile Image: Selected profile It is not possible to delete all profiles. At least one profile will remain available.					





12.3.4.3 Contact length



Contact length	Minimum Rib Length	Determines the length of the ribs. <i>Note:</i> you need a minimal length in order to have enough stability and to prevent the support from falling through the platform grid.
	Maximum Contact Length	You also can define whether to support the complete surface or only a certain Contact Length.
	Angle	You can choose the angle α , from the support to the part.
	Vertical Distance	You can choose the distance from the support to the part.







Sunken ribs		
Sunken Rib		
Sunken ribs stabilize part surface	the other ribs; it is not connected to the	
Number	0	
The number of s number of ribs -	sunken ribs cannot be greater than total 1	
Distance (a)	2 mm	

Sunken ribs	To minimize the contact area of the support with the parts, some ribs of the point support can be sunken. This means that they will not go till the part. They will stop at a certain distance before the part.				
	Distance	The distance that a sunken rib will stop before the part.			





Height		Lower	Lower Teeth. Lower Teeth are only used if the support is trimming on another part. If the support is trimmed on the platform, there are no lower teeth.
		Height	
Top Length		Top Length	
Base Length		Base Length	





Base Interval	Height Top Length
Lower Teeth Same as Upper Teeth	The Lower Teeth have the same specifications as the Upper Teeth.
Full teeth in ends	You can decide to half a full tooth at the end of a support, instead of half a tooth.
Copy current parameters to all teeth	Copy the teeth parameters from this support type to all types which are using teeth.

12.3.4.6 Number of ribs

Number of Ribs	
Number of Ribs 2 Define the number of ribs that make up the Point support	
	This support has 3 ribs
Number of Ribs Determine the number of the	e ribs.

12.3.5 Line & Line *

12.3.5.1 Current selected profile

For every support type, it is possible to have multiple profiles. Select, create, copy, open rename or delete profiles in the main tab of the support type. See **Error! Reference source not found.** of the Point support type





12.3.5.2 Cross line length

Cross line length							
Minimum Rib Length	(a)	2	mm				
The minimum rib leng cross line. Larger rib harder to remove	gth determines the l os are more stable b	length of t out may be	he				
Maximum Contact	(6	mm				
Maximum contact ler between the suppor	ngth limits the lengt t and the surface	h of the co	ontact			a	
Cross line length	Here, you car	n enter th	ne length o	f the cross	ing lines.		
	Minimum Rib Length	The le	ength of the	e crossing	lines.		
	Maximum Contact Length	The c	ontact lenç	of the c	rossing lin	es with the	e support.





12.3.5.3 Cross line interval

Cross line interval						
Cross Line Interval (a) 6,0			mm			
Defines the distance between cross lines				ЛЛЛ		
Synchronize						
Teeth Alwa	ays Intersect					
Cross line te intersect ea	upport line niddles	teeth				
Teeth Nev	er Intersect					
Cross line te	eeth and central li	ne teeth ne	ever touch			
Cross line interval	Here you ca support.	n set the	e distance	between two consecutive cross lines of a line		
	Synchronize	e The lines An e belo I -I- I Teet Inter	The user can allow the synchronization of the teeth of the cross lines and the teeth of the central line.An example of Line support without synchronization is shown below. $-1 + - + - + - + - + - + - + - + - +$			
		T eet Inter	h Never sect	The teeth of the cross lines avoid to cross the teeth of the central line.		
	Upper and lower teeth synchroniza on	Uppe	Upper and lower teeth will be synchronized			

12.3.5.4 Sunken cross lines





Sunken Cross Lines



12.3.5.5 Perforations

Perforations				
Perforations	Diamond	Þ		
Perforations	If this option is perforations po Diamond	checked, the support will be perforated. There are two kind of ssible: The shape and the size of the perforations are user defined by setting four parameters:		
		Beam	The beam thickness (1) defines the thickness of the beams.	
		Angle	The perforation angle (2) determines the angle of the perforations	
		Height	The height (3) of the vertical part is set with this parameter.	





	Solid Height	The separate parameter Solid Height (4) guarantees a good connection to the platform and the teeth.
Rectangular The shape a setting four p		d the size of the perforations are user defined by rameters:
	Width	The width parameter (1) defines the width of the rectangular holes.
	Height	The Height parameter (2) defines the height of the rectangular holes
	Solid Height	The Solid Height (3) parameter guarantees a good connection to the platform and the part.
	Interval	The interval parameter (4) defines the interval between the holes.
	Only Perforate rows	The support will only be perforated for the given rows, starting from the bottom. This enables the drainage of resin and ensures stable supports.





12.3.5.6 Teeth

Teeth				
	V Upper	Lower		. h
Height (a)	1,5	1,5	mm	
Top Length (b)	0,1	0,1	mm	
Base Length (c)	1,5	1,5	mm	
Base Interval (d)	0,2	0,2	mm	
✓ Lower Teeth Same as Upper Teeth C				
Full Teeth in Ends				
Copy current parameters to all teeth				
Lower teeth are created if support leans on an upfacing surface. If support leans on a platform, no teeth are created				

Teeth	In order to remove the supports easily from the part, the line supports are equipped with teeth profiles on the top and on the bottom.						
	Upper	You can specify whether you want Upper Teeth and/or Lower					
	Lower	Teeth. Those Lower Teeth are only used if the support is trimming on another part. If the support is trimmed on the platform, there are no lower teeth.					
	Height	, Height Top Length					
	Top Length						
	Base Length						
	Base Interval	Base Interval Base Length					
	Lower Teeth	The Lower Teeth have the same specifications as the Upper					
	Same as	Teeth.					
	Upper Teeth						
	Full teeth in ends	You can decide to have a full tooth at the end of a support, instead of half a tooth.					
	Copy current parameters to all teeth	Copy the teeth parameters from this support type to all types which are using teeth.					

12.3.5.7 Cross line teeth





Cross line teeth

	Upper	Lower		
Height (a)	1,5	1,5	mm	
Top Length (b)	0,1	0,1	mm	
Base Length (c)	1,5	1,5	mm	
Base Interval (d)	0,2	0,2	mm	
V Lower Teeth Same as Lipper Teeth				



Copy current parameters to all teeth

Lower teeth are created if support leans on an upfacing surface. If support leans on a platform, no teeth are created

Cross Line Teeth	These parameters are exactly the same as the teeth but they will be applied only for the cross lines used in line supports.				
	Upper	You can specify whether you want Upper Teeth and/or Lower			
	Lower	Teeth. Lower Teeth are only used if the support is trimming on another part. If the support is trimmed on the platform, there are no lower teeth.			
	Height	/Height Top Length			
	Top Length				
	Base Length				
	Base Interval	Base Interval Base Length			
	Lower Teeth	The Lower Teeth have the same specifications as the Upper			
	Same as	Teeth.			
	Upper Teeth				
	Full teeth in ends	You can decide to have a full tooth at the end of a support, instead of half a tooth.			

12.3.6 Block

12.3.6.1 Current selected profile

For every support type, it is possible to have multiple profiles. Select, create, copy, open rename or delete profiles in the main tab of the support type. See **Error! Reference source not found.** of the Point support type.

12.3.6.2 Hatching





Hatchi	Hatching						
Set t	Set the parameters for the hatching strategy of block supports depending on Surface area						
			Dimension		X Hatching (a)	Y Hatching (b)	
	Surface <	-	0,000	mm²	6,000	6,000	mm
	Surface <	-	0,000	mm²	6,000	6,000	mm
	Surface <	-	0,000	mm²	6,000	6,000	mm
	Surface <	•	0,000	mm²	6,000	6,000	mm
	Other: default 6,000 6,000 mm				mm		
Rotation Angle (c) 0,000 °							
To create only a border and remove all batching, select a large batching size (100mm)							

Hatching	Block Supports are generated for larger surfaces, they are made with a and Y lines which are separated at a certain distance (X Hatching and Y Hatching). Hatching can be chosen depending on the surface area.			
	X Hatching	The distance between two X or Y hatchings. You can add 4		
	Y Hatching	constraints to adjust the hatching distance depending on the surface dimensions.		
Ro Ar	Rotation Angle	The hatchings on the first picture have no angle and they are parallel to the X- and Y-axes. On the second picture, they have an angle of 45°.		





12.3.6.3 Hatching teeth



Hatching teeth	In order to remove the supports easily from the part, the hatchings are equipped with teeth profiles on the top and on the bottom.			
	Upper	You can specify whether you want Upper Teeth and/or		
	Lower	Lower Teeth. Lower Teeth are only used if the support is trimming on another part. If the support is trimmed on the platform, there are no lower teeth.		
	Height	/Height Top Length		
	Top Length			
	Base Length			
	Base Interval	Base Interval Base Length		
	Lower Teeth	The Lower Teeth have the same specifications as the		
	Same as	Upper Teeth.		
	Upper Teeth			
	Full teeth in ends	You can decide to have a full tooth at the end of a support, instead of half a tooth.		

12.3.6.4 Teeth synchronization





Teeth Synchronization

No Synchronization

Full Teeth in Ends

Teeth Intersections

Cross line teeth and central support line teeth intersect each other in their middles

No Teeth Intersections

Cross line teeth and central line teeth never touch



The user can allow the synchro teeth of the central line.	onization of the teeth of the cross lines and the
No Synchronization	
Teeth Intersections	
No Teeth Intersections	

1.3.4.1. Fragmentation







Fragmentation	Fragmentation the block suppo of block suppo	will leave a small gap in the hatching of ort each chosen distance, so the removal rts will become a lot easier.
	X Interval	The interval of the gaps according the X direction.
	Y Interval	The interval of the gaps according the X direction.
	Separation Width	The width of the gaps in the hatching.
	Fragmentate Borders	Check this option if you want the borders to be fragmentized too.

12.3.6.5 Hatch removal



Hatch Removal	In case a hatch would be placed too close to the border, problems during the removal of the support can arise.		
	Closer Than	Closer Than defines the minimum distance hatching stays away from the border.	
	With an Angle Smaller Than	Angle defines the minimum angle a rib has to make with the border in order not to be withdrawn with the clearance distance.	







1.3.4.2. Borders



Borders	The borders of the sup contour wall.	port will be reinforced with an additional
Fragmen tate Borders	Gaps in the border support will be generated	
	Separation Width (a)	Gaps width
	Interval (b)	Distance between the end of a gap and the starting of the next





Fragmen tation at Crossing	Gaps in the border support will be generated just where a crossing point (between hatching and support borders) is located	
----------------------------------	---	--

12.3.6.6 Border teeth

Border Teeth					
	Upper	Lower			, b
Height (a)	1,5	1,5	mm		
Top Length (b)	0,1	0,1	mm		
Base Length (c)	1,5	1,5	mm		
Base Interval (d)	0,2	0,2	mm		
☑ Lower Teeth Same as Upper Teeth					c d
Full Teeth in Ends					
Copy current parameters to all teeth					
Lower teeth are created if support leans on an unfacing					

Lower teeth are created if support leans on a	an upracing
surface. If support leans on a platform, no te	eeth are created

Border teeth	In order to remove the supports easily from the part, the hatchings are equipped with teeth profiles on the top and on the bottom.					
	Upper	You can specify whether you want Upper Teeth and/or Lower				
	Lower	Teeth. Those Lower Teeth are only used if the support is trimming on another part. If the support is trimmed on the platform, there are no lower teeth.				
	Height	, Height Top Length				
	Top Length					
	Base Length					
	Base Interval	Base Interval Base Length				
	Lower Teeth	The Lower Teeth have the same specifications as the Upper				
	Same as	Teeth.				
	Upper Teeth					
	Full teeth in ends	You can decide to have a full tooth at the end of a support, instead of half a tooth.				





12.3.6.7 Perforations

Perforations Diamond	Perforations		
b d	Perforations	Diamond	d d d d

Perforations	If this parameter There only one	eter is set, the support will be perforated. In Magics Print Metal one possible kind of perforations:			
	Diamond	The shape a setting four p	nd the size of the perforations are user defined by parameters:		
		Beam	The beam thickness (1) defines the thickness of the beams.		
		Angle	The perforation angle (2) determines the angle of the perforations		
		Height	The height (3) of the vertical part is set with this parameter.		
		Solid Height	The separate parameter Solid Height (4) guarantees a good connection to the platform and the part.		
		Width	The width parameter (1) defines the width of the rectangular holes.		
		Height	The Height parameter (2) defines the height of the rectangular holes		

12.3.7 Cones

12.3.7.1 Current selected profile





For every support type, it is possible to have multiple profiles. Select, create, copy, open rename or delete profiles in the main tab of the support type. See **Error! Reference source not found.** of the Point support type.



Size						
Contact part (R	1) fr	om 0,1	to	0,5	mm	2
	-			-		Δ_{α}
Contact platform	n (R2) fr	om 0,1	to	0,8	mm	
						R2
*Cones can be	merged when ove	rlapping				
Spacing						
(1) Min distance	between cones		1,5	mm		-0.0
					A *	1 🗧 🗧 💼 👘
(2) Min distance	between rows		1,5	mm	· • · ·	1(2)
						A 6'-' P
Max distance be	tween cones		3	mm		· · A
						• • •
					- -	5
*Cones will be p	placed based on su	Irfaces shape	1			•
2:						
	Here you ca	n define th	e cones din	nensions		
SIZE	Here you ca Contact par	n define th	e cones din ter of cone	nensions when cor	tacting the	part
5IZE	Here you ca Contact par Contact	n define th t Diame Diame	e cones din ter of cone ter of cone	nensions when cor when cor	tacting the	part
512e	Here you ca Contact par Contact Platform	n define th t Diame Diame	ter of cones ter of cone ter of cone	nensions when cor when cor	tacting the tacting the	part platform
Spacing	Here you ca Contact par Contact Platform Here you ca	n define th t Diame Diame n define th	e cones din ter of cone ter of cone e spacing c	nensions when cor when cor f the con	itacting the itacting the	part platform
Size	Here you ca Contact par Contact Platform Here you ca Min distance	n define th t Diame Diame n define th e Min dis	e cones din ter of cone ter of cone e spacing c stance betw	nensions when cor when cor f the con een cone	itacting the itacting the es s in the spa	part platform acing setup
Spacing	Here you ca Contact par Contact Platform Here you ca Min distance between	n define th Diame Diame n define th Min dis	e cones din ter of cone ter of cone e spacing o stance betw	nensions when cor when cor f the con- een cone	itacting the itacting the es s in the spa	part platform acing setup
Spacing	Here you ca Contact par Contact Platform Here you ca Min distance between cones	n define th Diame Diame n define th Min dis	e cones din ter of cone ter of cone e spacing o stance betw	nensions when cor when cor f the con- een cone	itacting the itacting the es s in the spa	part platform acing setup
Spacing	Here you ca Contact par Contact Platform Here you ca Min distance between cones Min distance	in define th t Diame Diame in define th e Min dis e Min dis	ter of cone ter of cone ter of cone e spacing o stance betw	nensions when cor when cor f the con- een cone een 2 rov	itacting the itacting the es is in the spa vs of the sp	part platform acing setup acing setup
Spacing	Here you ca Contact par Contact Platform Here you ca Min distance between cones Min distance between rows	an define th t Diame Diame an define th e Min dis e Min dis	e cones din ter of cone ter of cone e spacing o stance betw	nensions when cor when cor f the con een cone een 2 rov	itacting the itacting the es is in the spa vs of the sp	part platform acing setup acing setup
Spacing	Here you ca Contact par Contact Platform Here you ca Min distance between cones Min distance between rows Max distance	an define th t Diame Diame an define th e Min dis e Min dis	ter of cone ter of cone te spacing o stance betw stance betw	nensions when cor when cor f the con- een cone een 2 rov	itacting the itacting the es is in the spa vs of the sp es in the sp	part platform acing setup acing setup
Spacing	Here you ca Contact par Contact Platform Here you ca Min distance between cones Min distance between rows Max distance between	in define th Diame Diame In define th Min dis Min dis	e cones din ter of cone ter of cone e spacing o stance betw stance betw	nensions when cor when cor f the con een cone een 2 rov	itacting the itacting the es is in the spa vs of the sp es in the sp	part platform acing setup acing setup acing setup





12.3.7.3 Lowest Line

Lowest line			
Draw Lowest Line			
When lowest line is che created so that this low the lowest points of the	cked, an extra line o est line (the imagina surface) is supporte	f supports is ry line connecting ed	
Minimal Spacing (a)	2,500	mm	
Minimum Length	0,500	mm	
Note: the effects of this common parameters ->	s parameter are also lowest line	found in the	0000

Draw lowest	Will draw support at the lowest points of your parts		
line	Minimal spacing	Space between cones	
	Min length	Defines what the minimum length of the cones needs to be when drawing a lowest line. Cones smaller than this will not be drawn.	

12.3.7.4 Preview

Preview You can choose to generate a preview of the cones before the actual cones are generated.

This is recommended since the cones generation is time consuming

Generate preview

Generate actual cones

Generate preview	Cones will be visualized by wire frames
Generate actual cones	Cones will be generated as solids

12.3.7.1 Z Offset Direction






12.3.8 Cones*

12.3.8.1 Size & Spacing

Size	Size				
	5120				
	Contact pa	rt (R1)	0,1	mm	ł.
					<u>D</u> _e a
	Contact pla	atform (R2)	0,1	mm	RI
					R2
	Here you can	define the con	es dimensi	ons	
	Contact part	Diameter of	cone when	contacting	the part
	Contact Platform	Diameter of	cone when	contacting	the platform
Spacing	Spacing				
	Max distance	between cones	0,1	mm	(1)
	Here you can	define the spa	cing of the	cones	
	Max distance between cones	Max distanc	e between	cones in th	e spacing setup

12.3.9 Tree & Tree *

12.3.9.1 Current selected profile

For every support type, it is possible to have multiple profiles. Select, create, copy, open rename or delete profiles in the main tab of the support type. See **Error! Reference source not found.** of the Point support type.





12.3.9.2 Trunk

Trunk		
Defines tree support trur	nk parameters	d1
Diameter top (d1)	0,500 mm	
Diameter bottom (d2)	0,800 mm	
Height <mark>(</mark> h)	10,000 mm	h
Note: height will only be	used in manual trees	
		d2
Diameter top	Diameter top trunk cone	

Diameter top	Diameter top trunk cone
Diameter bottom	Diameter bottom trunk cone
Height	Height trunk cone

12.3.9.3 Branch



Diameter top	Diameter top branch cone		
Diameter bottom	Diameter bottom branch cone		
Add break off point	Narrow the branch at a certain position		
	Diameter	Diameter narrowing	
	Distance from top	Distance from contact point where the	
		narrowing needs to be	
Break-off point location			





On branch line	d1 d2 d2
Triangle normal	d1 d2 d2
vertical	d1 d2 d2

12.3.9.4 Branches per trunk

Branches per trunk		
Max branches per trunk	5	
Note: only used in automatic tree		
Max branches per trunk	Max n	umber of branches on trunk





12.3.9.5 Spacing

Spacing					
(1) Min distance between connection points	1,500	mm			
(2) Min distance between rows	1,500	mm			
Max distance between connection points	3,000	mm			
Note: only for autotree					
Draw Lowest Line When lowest line is checked, an extra line created so that this lowest line (the imagin the lowest points of the surface) is support	of supports is nary line conn rted	s ecting			
Minimal Spacing (a) 2,500	mm				
Minimum Length 0,500	mm				

Note: the effects of this parameter are also found in the common parameters -> lowest line $% \left({{{\rm{Not}}} \right) = {{\rm{Not}}} \right)$

Min distance between connection points	Space between connection points		
Min distance between rows	Space between rows of connection points		
Max distance between connection points	The maximum space between connection points		
Draw lowest line	When placing a support under a curved surface, it can happen that the lowest line (= the imaginary line connecting the lowest points of the surface) is not supported correctly. This can cause problems when building the part with some RP techniques. When lowest line is checked, an extra line of support will be placed so that this lowest line is correctly supported.		
	Minimal spacing	Defines the minimal spacing between the connection points along the lowest line.	
	Minimum length	Lowest lines smaller than this value (length) will be filtered out.	

12.3.9.6 Max height of trunk

Max height of trunk	
Max height of trunks	5,000 mm
Max height of trunk	If checked, the maximum height of trunks will be limited by the entered value.



112



12.4 Support module

The support module allows you to interactively and manually manage your supports. You will enter the support module when clicking 'generate support' in the main dialog.



12.4.1 Main

12.4.1.1 Exit

This will allow you to leave the support module. You will be prompted if you want to save your support when exiting.

	J.	🔳 Mag	jics	×
\bigcirc		?	You try to exit SG mode but Support was not saved to disk. Save before Exit?	
Exit			□ Never ask this again	
SG			Yes No Cancel	





12.4.1.2 Import Support



Will allow to import support structure from external sources in a STL format

Import Support

12.4.1.3 Regenerate support



Will allow you to regenerate the supports with the settings available in the machine properties

Regenerate Support

12.4.1.4 Add Cone



This will allow you to add a cone support to your part(s). You will be prompted to enter your cone settings and position before cone generation

Add Cone

Place Cone Support		×	
Cone Properties			
Contact to Part (r1)	0,500	mm	
Contact to Platform (r2)	0,800	mm	
OAngle	2,000	•	
Z Offset			
Upper Z Offset	0,250	mm	
Lower Z Offset	0,250	mm	
Indicating			
No Angle towards platform			
O Angle by Indicating			
Indicate OK	Cancel	Help	





12.4.2 Tree Support

The tree support section will allow the manual creation / deletion of tree supports

12.4.2.1 Start tree support



Start tree support allows to start create a tree support interactively with the mouse. The tree is represented by wires

Start Tree Support

12.4.2.2 Create Trunk



Allows you to create the trunk of the tree support manually. The trunk is represented by a wire diagram.

Create Trunk

12.4.2.3 Create branches



Allows you to create the branches of your tree support manually. The branch is represented by a wire diagram.

Create Branches

12.4.2.4 Edit nodes



Allows you to modify the position of the nodes in the tree structure

Edit Nodes

12.4.2.5 Select tree elements



Allows you to select trunks or branches of your tree structures in order to change or delete them.

Select Tree Element

12.4.2.6 Delete tree element



Allows you to delete selected parts of your tree structure.

Delete Tree Element





12.4.2.7 Tree preview

While creating trees manually, a preview of the tree will be displayed. The preview makes it easier to define the correct placement of the parts of the tree and shows how the support will look. The principle of WYSIWYG (What you see is what you get) is applied here. Depending on the element added you must reload your preview via the button "Create preview" from the support toolbox.

Trunk creation				
Preview of trunk	Created trunk			
Processo and				
Branches created				
Preview of branches	Created branches			
Movement of node				
Preview of node movement	Creation of moved node			



116





12.4.3 Select & Delete

12.4.3.1 Go to surface



Allows you to select support surfaces

Go To Surface

12.4.3.2 Select Item



Allows you to select a support item

Select Item





12.4.3.3 Select Polyline



Allows you to select a polyline support item

Select Polyline

12.4.3.4 Select support



Allows you to select a support item

Select Support

12.4.3.5 Deselect All



Allows to undo all selections

Deselect All





Delete the selected support items

Delete Selected

12.4.4 Surfaces

12.4.4.1 Create new surface



Allows you to transform the marked triangles into a support surface

Create New Surface



2 Add to current surface

Allows you to add the marked triangles to the selected support surface

Add To Current Surface

12.4.4.3 Remove from current surface



Allows you to remove the marked triangles from the selected support surface

Remove From Current Surface





12.4.4.4 Merge surface



Allows you to combine the selected surface with another surface indentified by the surface number.

Merge Surfaces

12.4.4.5 Change surface angle



Allows you to change surface angle that was used to calculate the support surfaces. This will result in new surfaces

Change Surface Angle

12.4.4.6 Examples of surface operations

Add To Current Surface	The marked triangles will be added to the current surface. When you press Regenerate 2D & 3D, Magics will also generate support for these triangles.				
	Begin situation	Triangles to be added are marked	Triangles are added to support		
Remove From Current Surface	The marked triangles will be removed from the current surface. When you click Regenerate 2D & 3D, Magics won't generate supports anymore for the marked triangles				
	Begin situation	Triangles to be removed are marked	Triangles are removed from surface		
Create New Surface	The marked triangle you can support.	es will become a new	v surface, which		
	Begin situation	Triangles to be added as new surface are marked	Triangles are added as new surface		
Merge Surfaces	Magics will merge the current surface with a given support.				





	egin situation	The middle surface will be merged with surface nr 1	The surfaces are merged
Change surface angle	When a surface makes an angle smaller than the entered surface angle it is considered not self – supporting, so support is generated for the respective surface.		

12.4.5 Imported supports

12.4.5.1 Translate support	Translate Part(s)
Allows you to translate imported STL supports with the translate dialog	Relative Absolute dx 0,000 mm dY 0,000 mm dZ 0,000 mm
12.4.5.2 Rotate support	OK Apply Cancel Help
	Rotate Support X
Allows you to rotate imported STL supports with the rotate dialog Rotate Support	Rotation Angle X 0,0000 ° Y 0,0000 ° Z 0,0000 ° Rotation Center
	OK Apply Cancel Help
12.4.5.3 Rescale supports	Rescale Support X Factor Resulting size Difference Original size [1,00000 t] 16,176 t] mm [0,000 t] mm [1,0176 t] mm 1,00000 t] 22,057 t] mm [0,000 t] mm [22,057 t] mm
Allows you to rescale the imported STL supports with the rescale dialog	1.00000 1.00000 mm 30,736 mm 9 Uniform Rescale mm 30,736 mm mm 1 Show Preview Rescale Factor Library mm Nescale Center
12.4.5.4 <i>Pick and place support</i>	Apply Close



Allows you to move / rotate your imported STL supports interactively with the mouse.

12.4.6 View





12.4.6.1 *View All Support* Show all generated supports present on the platform

1

View All Support



12.4.6.2 Supported Area Preview

Show with a heat map the support surfaces

Supported Area Preview



Part Projection

12.4.7 Support pages

12.4.7.1 Support list

The surface list gives you an overview of all surfaces with their support type created.

🔻 Si	 Support Pages 							
Support List Su		urface Info	F	Part Info				
ID	Туре	Т	X Min	Y Min	On Part	Surface Profile	1	
1	None	761	62.088	33.160	No	Default		
1	None	768	62.026	30.825	No	Default		
1	None	647	69.206	31.994	No	Default		
1	Line	512	69.384	34.254	Yes	Default		
1	None	10/	72 117	33 830	No	Default	~	
			15					
	<	<<	13	>>	>			

The red items in the list indicate that the support touches a lower surface of the part itself.







The columns of the Surface List can be set by clicking on the icon in the upper right corner of the list; the following dialog will pop up:

> > >	ID Iype T <u>r</u> iangles	
> >	<u>X</u> Min Y Min Z Min	
	X Max Y Max Z Max	
	<u>S</u> urface Area <u>B</u> order Length	
~	On <u>P</u> art On P <u>l</u> atform	
•	Surface Profile	
ID		The unique number of the surface
Тур	е	The support type given to this surface.
Tria	ngles	Amount of triangles of the surface.
ХM	in	The starting dimensions of the surface.
ΥM	in	
ΖM	in	
ХM	ax	The ending dimensions of the surface.
YM	ax	
ZM	ax	
Surf	ace Area	The surface area of the surface.
Border Length		I he border length of the surface.
On	Part	The support surface is attached to the part.
On	Platform	I he support surface is attached to the platform.
Surf	ace Profile	A support profile, created by the user, is used.

A right mouse click in the surface list will pop up the following:

<u>I</u> nvert Selection Select <u>A</u> ll Select <u>N</u> one
<u>D</u> elete Surfaces Du <u>p</u> licate Surfaces
<u>C</u> opy Parameters From <u>M</u> erge Selected Surfaces
S <u>o</u> rt Reverse <u>O</u> rder
<u>R</u> estore Order <u>S</u> ave Order



122



Invert Selection	The unselected surfaces will become selected and the selected surfaces			
	will not be selected anymore.			
Select All	All surfaces will be selected.			
Select None	All surfaces will be deselected.			
Delete Surface	All selected surfaces will be removed from the surface list.			
Duplicate Surfaces	The selected surface will be duplicated. This gives the possibility to use different support types for one surface. (e.g. Volume support in combination with block support for the metal market)			
Copy Parameters				
From	Copy Parameters			
	From 1 To 1 OK Cancel			
	Copy the support type and all parameters from the given support number to			
	the selected support numbers.			
Merge Selected	The selected surfaces will be merged into one surface.			
Surfaces				
Sort	You can sort the Surface List according to the columns. You can also sort			
	by clicking on the title of the column.			
Reverse Order	The sorted order is reversed.			
Restore Order	The order is restored.			
Save Order	The order is saved.			

12.4.7.2 Browsing through the supports

The complete down facing surface will be split into multiple surfaces, which each have their support structure. You can browse through these surfaces by using these buttons:

<	~~	1	>>	>	Skip Empty
					Comp comp c)

<	Return to surface one.
<<	Return to the previous surface.
1	Window showing surface number.
>>	Go to the next surface.
>	Go to the last selected surface.
Skip Empty Supports	All surfaces which are selected by the surface angle but do not need supports following the selection parameters (no support offset, surface filter), are skipped.





12.4.7.3 Surface Info

▼ Support Pages					
Support List	port List Surfa		Part	Info	
	Min	Max	Delta		
х	69.384	72.3702	2.9862	mm	
Y	34.2535	35.4462	1.1927	mm	
Z	33.4263	34.5701	1.1438	mm	
Contour Length	8.7096	mm			
Surface	1.14861	mm²			
Thinness	66.0431	(= Contour ² / Surface)			
<					
Skip Empty Su	pports				

Dimensions	Min X Y Z	The dimensions of the surface.	
	Max X Y Z		
	Delta X Y Z		
Contour Length	The contour length of the surface.		
Surface	The surface area of the surface.		
Thinness	This parameter represents the thinness (slenderness) of		
	the surface.		
Browsing buttons	Browsing buttons are used to browse through the different		
	surfaces. The buttons are explained above.		

12.4.7.4 Part Info

 Support 	i Pages 🔅	Surface I	nfo Par	t Info	
Part name	ha sultar	ariffes x3 oh		Rename	Next
Dimension	is	grines xo oo		rtename	Here
Min		Max	Delta		
X 55,001	L	79,639	24,638	mm	
Y 30,001	L	36,279	6,278	mm	
Z 10,000)	40,736	30,736	mm	
Mesh info # Triangle # Marked	es 13482 135	0		# Points # Invisible	67332 0
Properties	5				
Volume	299,489		mm ³		Update
Surface	1007,436		mm²	\checkmark	Automatic
Status Cha	inged		Z Comper	nsated No	





Part Name	In this window the	e name of the selected part is displayed.
	Rename	For renaming the selected part.
	Next	For switching to the next part.
Dimensions	Min X Y Z	The dimensions of the part.
	Max X Y Z	
	Delta X Y Z	
Mesh info	# Triangles	The number of triangles the part exists off.
	# Points	The number of points.
	# Marked	The number of marked triangles.
	# Invisible	The number of invisible triangles.
Properties	Volume	The volume of the part.
	Surface	The surface area of the part.
	Automatic	For updating the volume and surface number automatically.
Status	The status of the	STL-part. If no modifications are made to the loaded part, the
	status is Not Cha	nged. In the other case, the status is Changed.
Z-compensated	Indicates the part is z-compensated or not.	

12.4.8 Support parameter pages

12.4.8.1 General

The support parameter pages will allow you to select and define the supports that you want to use for the selected support surface(s) in the support list of the support pages. It consists of 5 main control elements:



- Type tab sheet
- Common tab sheet
- Support specific tab sheet
- Creation control
- Parameter manager





12.4.8.2 Type Tab Sheet

Will allow to select which type of support you want to use for the selected surface in the support list, to 2D Preview the support surface in 2D Plan and to manage the 2D view.

 Support Parar 	neters Pages
Туре	
Туре	Current type: Cones
None	current type. Cones
Block	2D Plan
Line	Тор
Point	
Cones	
Tree	
	Zoom Unzoom Flip View

12.4.8.3 Common Tab Sheet

Will allow you to set the parameters that are common for all support types

 Support Parameters F 	Common		
XY Offset	Upper 7 Offset	0.250 r	nm
Z Offset	opper 2 onset	0,200	
No Support Offset	Lower Z Offset	0,250 r	nm
	Use -Z value *Note: -Z go through	s can cause suppor	t to

- XY offset How much clearance the support position needs to have from an edge
- Z offset Clearance between support and part in the Z direction
- No Support offset How much overhang is allowed without supports

For more detailed information about the parameters check Support parameters – Machine properties





12.4.8.4 Block Tab Sheet

Will allow you to set the specific parameters for the block support type.

 Support Parameters F 	ages		
		Block	
Hetekin -	Hatching		
Hatching Hatching Tooth	X Hatching	6,000	mm
Teeth Synchronization			
Hatch Removal	Y Hatching	6,000	mm
Border Teeth	Detetion Angle	0	
Perforations	Rotation Angle	U	•

Hatching	Defines the dimensions and angle of the cross hatch pattern
Hatching Teeth	Defines the dimensions of the connection teeth of the hatch pattern
Teeth Synchronization	Defines how teeth will intersect and how they will behave at the edges
Hatch removal	Defines where/when hatches will be removed
Border teeth	Defines the dimensions of the connection teeth of the border
Perforations	Defines if the block support will be perforated or not

For more detailed information about the parameters check Support parameters – Machine properties

12.4.8.5 Line Tab Sheet

Will allow you to set the specific parameters for the line support type.

▼ Support Parameters Pages			
		Line	
Cross Line Longth	Cross Line Lengt	h	
Cross Line Interval	Minimum Rib Len	gth 10,0000	mm
Sunken Cross Lines Perforations	Maximum Contac Length	t 6,0000	mm
Cross Line Teeth			
L			





Cross line length	Here you can enter the length of the crossing lines.
Cross line interval	Here you can set the distance between two consecutive cross lines of a line support
Sunken Cross lines	To minimize the contact area of the support with the parts, the cross lines can be sunken, this means that they will not go till the part. They will stop at a certain distance before the part.
Perforations	If this option is checked, the support will be perforated. There are two kind of perforations possible
Teeth	In order to remove the supports easily from the part, the line supports are equipped with teeth profiles on the top and on the bottom.
Cross line teeth	These parameters are exactly the same as the teeth but they will be applied only for the cross lines used in line supports

For more detailed information about the parameters check Support parameters – Machine properties

12.4.8.6 Point Tab Sheet

Will allow you to set the specific parameters for the point support type.

▼ Support Parameters Pages 🐜			
		Point	
Contact Longth	Contact Length		
Sunken Ribs	Minimum Rib	6,0000	mm
Number of Ribs	Maximum Contact Length	2,0000	mm
	Minimal Contact Surface	0,0000	mm²
	Angle	30	•
	O Vertical Distance	0,0000	mm

Contact Length	Determines the length of the ribs
Sunken Ribs	To minimize the contact area of the support with the parts, some ribs of the point support can be sunken. This means that they will not go till the part. They will stop at a certain distance before the part
Teeth	In order to remove the supports easily from the part, the line supports are equipped with teeth profiles on the top and on the bottom.
Number of Ribs	Determine the number of the ribs

For more detailed information about the parameters check Support parameters – Machine properties





12.4.8.7 Cones Tab Sheet

Will allow you to set the specific parameters for the cone support type.

Pages 👐
Cones
Cones Size Contact part (R1) from 0,100 to 0,500 mm Contact platform (R2) from 0,100 to 0,800 mm

Size	Defines the geometry of the cone
Spacing	Defines which spacing the cones need to have when filling the surface
Z offset direction	Clearance between part and support
Lowest line	Define if and how the cones need to be placed at the lowest line

For more detailed information about the parameters check Support parameters – Machine properties

12.4.8.8 Tree Tab Sheet

Will allow you to set the specific parameters for the tree support type.

▼ Support Parameters Pages			
		Tree	
Trunk	Trunk		
Branch Branches per trunk	Diameter top	0,500	
Spacing Max height of trunks	Diameter bottom	0,800	





Trunk	Defines the trunk of your tree structure
Branch	Defines the branch of your tree structure
Branches per trunk	Defines how many branches will be placed on a trunk
Spacing	Defines how the branches will be spread over the support surface
Max Height of trunks	Defines the height if the trunks

For more detailed information about the parameters check Support parameters – Machine properties

13 View & Analyze



13.1 Views

13.1.1 Shade

Shade

The shade modes are the ways to visualize a part.

1	Shade
Ø	Triangle
	Shade&Wire
₿	Wireframe
8	Bounding Box
	Transparency

Shade	This visualization mode will display the part with shades according to the direction of the triangles.
Triangle	In Triangle mode the triangles will be displayed upon the shaded part.
Shade&Wire	This mode will show a combination of the Shade mode and the Wireframe mode.
Wireframe	\$ This visualization mode shows the edges of the object. This representation is deduced from the STL file. It has been tried to approach the normal wireframe representation as good as possible. But due to the limited information, STL errors and noise in the STL file, abnormalities in this representation may show up. A line of wireframe is drawn when the angle between 2 triangles exceeds a certain value. You can change this





		value and so adapt the wireframe view (Settings > Visualization > Wireframe).
Bounding Box	8	This mode will only show the bounding box of the part. This mode is quick in visualization.
Transparency		All parts are shown in a transparent mode.

13.1.2 Top



Top

"Top" allows you select one of the following default views: Top, Bottom, Front, Back, Left, and Right. These views are also easy accessible in the View Pages Toolpage by clicking on the cube in the View tab.

🔊 To	р	н	•	View Pages	;		
😵 Bo	ttom	в		View	Multi-Section	Slices	Grid
😭 🛛 Fro	ont	F	Vis	ualization –			
民 Ba	ck	v		р 🔹 Shade	e&Wire		
🚷 Rig	ht	G		🔊 🔹 Bad E	dges Visible		
🚯 Le	ť	D		🔪 🔹 Flippe	ed Triangles Visible		
🐔 Ho	me View	Q					

13.1.3 Top Front Right



"Top Front Right" allows you select one of the following ISO views: Top Front Right, Top Front Left, Top Back Right, Top Back Left, Bottom Front Right, Bottom Front Left, Bottom Back Right, Bottom Back Left.



13.1.4 Zoom / Unzoom



To zoom in on a region, this region has to be defined by means of a box (drag from the left upper corner to the right bottom corner). When the mouse button was pressed, but no rectangle was drawn, the Zoom In 25% function will be applied. Zooming in and out can also be done using the mouse scroll. For unzooming the zoom factor will be set so that all the active parts are displayed.





13.2 Elements

13.2.1 Rulers

Toggle the visibility of the Rulers. When toggled, the icon gets a blue background. Rulers have been introduced into Magics to give the user the possibility to estimate the dimensions in which he is working. The rulers can be placed at the bottom of the working area and/or in the left side of the working area. These settings can be defined in the Rulers visualization parameter window (Settings > Visualization > Rulers).

13.2.2 Coordinate System



The Coordinate System is called WCS (World Coordinate System) and it is the default coordinate system in which you work. The origin is set in (0,0,0). Sometimes, for example when the part is zoomed in, or when the part is positioned far from the origin, this coordinate system is not visible on the screen. Therefore, you can switch

on the Orientation Indicator. When toggled, the icon gets a blue background.

13.2.3 Orientation Indicator

The Orientation Indicator is a coordinate system that is only there to indicate the direction of the X-axis, the Y-axis and the Z-axis of the WCS. It remains always in the bottom right of your screen, no matter how far you zoomed in on the part. This orientation indicator is drawn in fine lines to avoid confusion.

13.2.4 Visualization



No-build Zones	\$	Toggle to show the No-build zones, if present.
Field Overlaps		Toggle to show Field overlaps, if present.
Platform Visibility	1	Toggle the Patform Visiblity. (F11)





13.3 Measure

13.3.1 Part Dimensions



Activating the part dimensions gives a view on the bounding box with the dimension of each rib indicated.

13.4 Build checks

13.4.1 Wall Thickness Analysis



Visualize the wall thickness of your part with a color heat map.

13.4.2 Out of Bounds



The out of bounds function will color parts which are placed outside of the platform bounds. Any placement tool can be used without losing the color indications

13.4.3 Collision Detection



13.4.4 Supported Area Preview



13.5 Dialogs

13.5.1 Show Log







From the moment Magics Print Metal runs, all the performed actions are written down in a log file. This file is automatically saved as a *.log file. Its name * is composed in the following way: 'Magics Print Metal +_year_month_date_time of first operation (hour, minutes, and seconds)'.In the Settings (Settings > File I/O > Working Folder > Logging) you can define where you would like the files to be saved.

🖲 Log Window 💼 🖬 💌
16:30:55] Operation time: undo and autorecovery 47ms
16:30:55] Selected Part via Mouse Click
16:30:55 S 34 203 Succeeded
16:31:05 D 10002 204 Change Active Scene
16:31:05 I 10002 204 Operation time: Total (without pre operation)
16:31:05 S 10002 204 Succeeded
16:31:06 D 34 205 Part Selection
16:31:06 Operation time: undo and autorecovery 31ms
16:31:06 Selected Part via Mouse Click
16:31:06 S 34 205 Succeeded
16:31:07 Operation time: undo and autorecovery 0ms
16:31:07 Selected Part via Mouse Click
16:31:09 Operation time: undo and autorecovery 0ms

14 Options & Help

FILE	BASIC FLOW	FIXING EDIT	SCENES & N	MACHINES	SUPPORT GENERATION	STANDARDDLP MACHINE	VIEW & ANALYZE	OPTIONS & HELP	۵
0,	~	2?	1	-					
Settings	Licenses	Support Manual Request	About S Magics	Show Log					
Settings	Licenses	Help	About	Logging					

14.1 Settings

Settings In the Settings dialog you can alter all parameters of your Magics Print Metal Software.

14.1.1 Customize Mouse Input

The mouse buttons are fully customizable by the user.



134



 Mouse Input 	Mouse Input		
Mouse Input	Commands	Shortcuts	
 General Modules File I/O 	Common Rotate View Hanning Zoom	New Shortcuts:	Add
	Options		
	Show rotation circle 66 🗘 %		
	Flip Mouse Wheel Input for Zooming		
Reset current page			

Command	This list contains the available functions for the mouse.
Shortcuts	This list represents the current shortcuts for the selected function in the Function List.
Delete	Deletes the selected shortcut.
Reset	The shortcuts for the selected function will be reset.
New Shortcut	By clicking in this textbox and clicking on the desired combination of (mouse) buttons,
	the shortcut will appear in this box.
Add	Adds the shortcut to the Shortcuts List.
Conflicts	This message alerts whether a shortcut for the selected function is in conflict with another shortcut of another function.
Apply	Designates the shortcut to the selected Command, the user is able to define more shortcuts without leaving the dialog.

14.1.1.1 Advised Way of Working



135



Select a command from the Command list. E.g. Panning. Panning already has a shortcut: SHIFT+Right Button and the middle mouse button. We'll create a new one.

Mouse Input	Mouse Input		
Mouse Input	Commande	Charteute	
General	Commands	Shortcats	
> Modules	🞧 Rotate View		Delete
> File I/O	💠 Panning		
The ye	Com Zoom		Reset
		Now Shortsute:	1
		New Shortcuts.	
			Add
		Conflicts:	
	Ontions		
	Snow rotation circle 66 📮 %		
	Flip Mouse Wheel Input for Zooming		
Reset current page			

Activate the New Shortcut textbox by clicking in it and push your desired shortcut. Click on the *Add* button, the shortcut is added to the Shortcut List. Click *OK*. You can now use your newly created shortcut.

14.1.1.2 "Flip Mouse Wheel Input for Zooming" checkbox

Allows the user to change the direction of the zooming behavior by the use of the mouse wheel.

14.1.1.3 "Show rotation circle" checkbox

Allows the user to decide whether or not to show the rotation circle on screen during rotation of the view. The size of the rotation circle can be adjusted to fit the user needs.

14.1.2 General

14.1.2.1 Unit Size

14.1.2.1.1 Units

Units
● mm ○ Inch
☑ Use machine units for the platform scenes





You can choose between mm and inches. You will have to select the units before you load the STL file. If the STL file was originally in millimeters, you have to choose mm. If the file is in inches, you will have to choose Inch. If several parts are loaded, some in millimeters and some in inches, the Unit Conversion has to be used otherwise parts are out of proportion. The program always remembers the last used unit and takes this as default the next time you start up the program.

14.1.2.1.2 Automatic Unit Conversion

Automatic Unit Conversion		
\boxdot inch -> mm if maximum size <	10 ‡ mm	
\bigtriangledown mm -> inch if maximum size >	40 ‡ inch	

The automatic unit conversion is used to avoid mistakes due to the units you work in. It may be that you are working in millimeters, and that you load a part whose dimensions are expressed in inches. A part of 2inch*2inch*2inch, will then become a part of 2mm*2mm*2mm. The size of the part is not correct anymore.

Because 1inch is 25.4mm, the dimensions of the part expressed in millimeters are bigger than those when the part is expressed in inches. A part of 2inch*2inch*2inch, is as big as a part of 50.8mm*50.8mm* 50.8mm.

When you are working in millimeters and you load a part and the dimensions are very small (you can define 'very small' in the options –see the figure above), it may be that the part you loaded was originally expressed in inches. Magics will then multiply the dimensions with 25.4 (inch to mm conversion), so the part will now be expressed in millimeters. When you are working in inches and you load a part and the dimensions are very big (you can define 'very big' in the settings – see figure above), it may be that the part you loaded was originally expressed in millimeters. Magics will then divide the dimensions with 25.4, so the part will now be expressed in millimeters.

14.1.2.2 User process flow improvement



Magics Print Metal will collect user experience feedback to ensure future improvements and best software quality.

14.1.2.3 Languages







You can change the language of you Magics Print Metal installation. The language change is only applied after restarting Magics Print Metal.

14.1.2.4 Warnings

Show the 'Never ask again' message for	
Change memory state of parts	
Cut on bad edges	\checkmark
Delete bounding box measurements	\checkmark
Delete Build Risk Analysis profile	\checkmark
Delete SG profile	\checkmark
Refine and smooth texture shift	\checkmark
Exit SG mode	\checkmark
Switch part in SG	\checkmark

Turn warning messages on/ off for particular functions/ actions to complete.

14.1.3 Modules

14.1.3.1 Support Generation

Will allow you to set the support mode (Manual – Automatic) when switching to the support module (SG)

Switch part in SG mode ○ Generate support O Manual support Always give the option in a dialog (where user can choose which mode to use)

14.1.3.2 3MF convertor

Will allow you to define the location folder of the 3MF convertor.



14.1.4 File I/O

14.1.4.1 Working folders





14.1.4.1.1 Logging

Application logging will allow you to specify where you will store the log file and if log file size will be limited and with how much

Application Logging		
C:\ProgramData\Materialise\Mag	gics\Logs	1
Advanced Options		
✓ Limit Log Folder Size	Max Size: 1	Ĵ МВ

14.1.4.1.2 Support library folder

Allows you to specify the supports library folder

Supports Library Folder	
C:\ProgramData\Materialise\Magics\SupportsLibrary	1

14.1.4.2 Import





Within this window you can define which placement option you want to use as the default one, and whether you want to automatically fix your part upon importing.

As Is	The part will be placed on the same position it was saved in.
Default Position	The part will be placed on the default (platform) position.
Aside of others	The part will be placed next to already loaded parts.
Automatic Placement	The part will be placed according to the Automatic Placement method defined in the machine file.
Autofix during import (in Standard mode)	The imported part will be fixed automatically if it is loaded in Standard Memory mode.
Never ask again while drag & drop	If disabled, a dialog will pop up when dropping a file into Magics, so the user can still define placement and fixing settings.





	If enabled, no dialog will be shown, and the defined settings will be used.
Unzoom at import	After importing the file, the view will change to focus on the part.

When using the dialog to import a file, these options can still be overruled here:



When dropping one or multiple files into Magics, the following dialog will appear:

Import Part	Import Part
Placement As Is Default Position Aside Of Others Automatic Placement Autofix During Import Never Ask Again	Placement As Is Default Position Aside Of Others Automatic Placement Autofix During Import Apply To All Never Ask Again
Ok Close	Ok Close





When "Apply to all" is enabled, Magics will use the same settings for all parts that were dropped into Magics together. When disabled, a new window will appear for each imported part.

14.1.4.2.2 STL

Identical Triang	les
O Don't Ren	nove
Remove C	Copies, Leave One
O Remove C	Copies and Original
Opposite Triang	les
Oon't Ren	nove
O Remove O	Copies, Leave One
O Remove (Copies and Original
Sti Memory State Project Loading	Standard +
Stl Importing	Standard -
Always load St	tl's on disk with more than
·	10000 ‡ triangles
Importing .magics	& .MatAMX files

14.1.4.2.2.1 Identical Triangles

Identical	Identical triangles have their normals in the same direction. You can choose to
Triangles	leave these triangles, leave one of the two triangles or remove them both.
Opposite	Opposite Triangles have their normals in opposite directions. You can choose to
Triangles	leave these triangles, leave one of the two triangles or remove them both.

14.1.4.2.2.2 STL Memory State

	1	
.magics Project Loading	You can define state becomes	e in which memory state you want to load a project. This memory the default when importing a project.
	Standard	This is the standard memory state of a STL file. Magics knows the placement of the triangles and their mutual dependencies. The user is able to perform actions on STL level (E.g. deleting triangles).
	Compact	The STL resides in the memory as read-only, therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor their mutual dependencies. The user is not able to perform actions on STL level.





	On Disk	The STL is saved on disk and unloaded from the memory. The STL will stay in the project but the user cannot perform any actions on it.
	As Saved	The Project will be loaded as previously saved.
STL Importing	You can define	in which memory state you want to load a project. This memory
	state becomes	the default when importing a project.
	Standard	This is the standard memory state of an STL file. Magics knows the placement of the triangles and their mutual dependencies. The user is able to perform actions on STL level (E.g. deleting triangles).
	Compact	The STL resides in the memory as read-only, therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor their mutual dependencies. The user is not able to perform actions on STL level.
	On Disk	The STL is saved on disk and unloaded from the memory. The STL will stay in the project but the user cannot perform any actions on it.
Always load STL's on disk	An STL with m disk.	ore triangles than defined by the user, will always be loaded on

14.1.4.2.2.3 STL Memory State

Show STL list	Check this option when you want to see a list of the parts saved in the imported
when importing	.magics file. In that list you can check the parts you want to be loaded.
.magics file	

14.1.4.2.3 Slices

Will allow you to define how you want to import SLC files - As a slice stack or as a STL

SLC
Convert to STL
\bigcirc Import as stack of slices
☑ Always ask

14.2 Licenses

14.2.1.1 Licenses





-

Licences In the Registration dialog you can display your current license situation and contact information, request key files and register new modules.

System ID:	ABC6CF08-D30E-	A8C6CF08-D3XE-0008-2C678CF827DAF446				
COKey:	9558-5ECA-9FD2	-D749				
Register	Register					
Key file:					Browse	
S.	Register					
Overview lice	Overview licenses					
Module Nodule		Version	License	Days Left	*	
Magics RP Magics Bas	with all extra modules e with all extra module	17.0 ± 17.0	No license No license	n/a n/a		
Magics RP Magics Bas	e	17.0 17.0	Local	4		
Magics Inte	aractive Fix	17.0	Local	4		
Magics Aut	oFix	17.0	Local	4		
Magics Ligh	it	17.0	Local	4		
Magics RP	Demo	17.0	No license	n/a	٣	
Refre	sh 🦳 🍘 Se	rver conf		About		
			• . L			





14.3 Help

14.3.1 Support Request

Magics Print Metal allows you to send a support request by email to the customer support team of your machine manufacturer. This can be done by filling out the request form and by selecting the type of additional information you want to add to the request. To make sure that our customer support team has enough information regarding the problem some additional information can be included. You can select to add additional information to your support request which will give the customer support team more information about your Magics Print Metal configuration. By sharing this information it is more likely that your support case will be solved more swiftly.

Support Request							
Select Office *							
First Name *							
Last Name *							
Company *							
E-mail Address *							
Phone number							
Details: *			*				
			-				
* required fields							
Additional informati	on						
License overview							
Installation history							
Preferences							
GUI profile							
Screen picture							
		Submit	Close				

14.3.2 Manual

Magics Print Metal does not have a build in manual but instead links to your manufacturer's website to a webpage were all support documents including this user guide are placed for download.

FILE	TOOLS FIXE	NG EDIT	SCENES & MACH	INES SUPPORT GENERATION	YLM-120	VIEW & ANALYZE	OPTIONS & HELP
Settings	Licenses	Support M	? Ianual About	Show			
Settings	Licenses	Help	About	Logging			

14.4 About

Gives the version details of the Magics Print software, and the performance parameters of the computer the software is running on.

About Magics

Show Log

14.5 Logging

Shows the log of the last performed actions by the Magics Print Metal software.




 \mathcal{A}

9

15 Toolbars

15.1 Mark Toolbar

In order to fix a corrupted STL file, the user can mark triangles of a selected part. The part must first be selected before triangles can be marked! To indicate that a triangle is marked the triangle turns (default) green. The marked triangles and edges color can be defined in the Settings. When applying one of the options below, keep CTRL pressed to mark through your part, equally marking the triangles at the other side of your part.

15.1.1 Mark Triangle

🛤 Triangles can be marked one by one. Marked triangles can be unmarked by indicating them with the Mark Triangle cursor again.

15.1.2 Mark Plane

By clicking one triangle, a whole plane can be selected or unselected. The plane is not necessary perfectly flat. It can also have a complex shape depending on the plane selection parameters. These you can define in the Settings (Settings > General > Marking, see Error! Reference source not found., page Error! Bookmark not defined.). The indicated triangle will be the reference to mark the plane. Triangles that differ too much from the reference, will not be marked anymore.

15.1.3 Mark Surface

K You have the possibility to mark a surface at once. A surface is surrounded by a wireframe (Settings > Visualization > Wireframe, see Error! Reference source not found., page Error! Bookmark not defined.). The wireframe can be seen as the black lines on the parts, when the shade and wire or wire view is activated. These black lines indicate the zones where two adjacent triangle have an angle more than the active value. Using the Mark Surface option, you will thus mark a smooth surface which ends at the sharp edges.



145



15.1.4 Mark Shell

A shell is defined as a limited collection of triangles correctly connected to each other. A triangle is part of a shell when the direction of rotation of the vectors of two adjacent triangles is opposite:



Direction of rotation of triangles in a shell

To unmark a marked shell, the mark shell cursor is used again.

15.1.5 Mark Window

With this tool, you can mark all triangles within a rectangular area. The conditions for a triangle to be in the selection are:

The triangles should be visualized with at least one pixel on the screen At least a portion of the triangle should be situated in the rectangular area

Remark:

To <u>unselect</u> a portion use the <u>Shift key</u> in combination with a rectangular area. To mark triangles from their backside too, use the Ctrl key in combination with a rectangular area.

15.1.6 Mark Freeform

Freeform marking allows marking of triangles by drawing a freeform shape. As long as the left mouse button is pressed, you can draw the freeform shape. The shape is closed by connecting the begin and end point if there is no intersection. The triangles within the freefrom shape and the triangles intersecting with the freeform shape are marked.

15.1.7 Mark Brush

Brush Marking allows marking triangles on an active part with a brush. Keep the left mouse button down and draw a polyline on a selected part. Every triangle that intersects with this polyline is marked. The left picture shows the polyline, the second the marking result.







The size of the brush can be defined in the options window Settings > Marking > Polyline Marking, or by pressing CTRL while using the mouse scroll button.

See

Brush Marking

Size of Brush	Brush Marking allows marking triangles on an active part
	by a brush. The user can define the size of the brush.

Vertical Marking

Angle deviation	Vertical Marking allows marking triangles on an active part
	vertically. The user can define the deviation.

Horizontal Marking, page Error! Bookmark not defined.

15.1.8 Unmark All

All triangles will be unmarked.

15.1.9 Delete marked triangles







16 The Toolpages

Via the View menu it is possible to access different pages that each group a particular kind of functions: visualization of the STL files, fixing of the files, creating annotation scenes, measuring...

The pages are displayed on the right of the working space. The user has the ability to enlarge the working space by hiding the Toolpages. Toolpages can be hidden by using the arrow displayed on the left side of the Toolpages.



By default the pushpin is enabled, which means that the Toolpages are visible. Disabling the pushpin will hide the Toolpages.

The customer can still make the Toolpages visible by hovering over the Toolpages. Moving the mouse pointer over the Toolpages will open them. As long as the mouse pointer stays above the opened Toolpage, it will be visible. Using the arrow will either open or close the Toolpage.

Notifications

The hover over possibility will not work when using the arrows if the pushpin is enabled.





16.1 General

The Toolpages are grouped in toolboxes. These Toolboxes act as a container to group different sheets. A toolbox is docked at the right side of the workspace. One is able to minimize or maximize the docked toolbox.

		Maximized	Toolbox	
View	Multi-Section	Slices	Grid	
Visualization				
Shad	e Edges Visible ed Triangles Visible	:),
		Minimized	Toolbox	
View Pages	s	•••••••		×
View	Multi-Section	Slices	Grid	

A Maximized Toolbox can become minimized when:

- It's minimized with the minimize button
- When there's not enough vertical space
- This can happen when adding another toolbox or maximizing a minimized Toolbox
- The pushpin will prevent the minimizing of the Toolbox.

 View Page 	s		····· + +
View	Multi-Section	Slices	Grid
Visualization			
🕅 - Trian			

A minimized Toolbox will become maximized when:

- Clicking on the Minimized Toolbox
- When clicking on a Toolpage of a minimized Toolbox, the Toolbox maximizes showing the clicked Toolpage.
- On minimizing or closing another Toolbox so that there's enough space to maximize.

For some Toolboxes, Magics Print Metal determines the height automatically (E.g. Part list or surface list in the Support Generation module). This is dependent of:

- The space left over.
- The space needed.

The height is depending on:

- Minimum height: the height of the Toolpage in the Toolbox
- How many parts loaded in the Part List. The height of the Toolbox that contains the Part List will be adapted in a way that as much as possible parts are visualized.
 - Auto sizing of the Toolbox will never automatically minimize other Toolboxes.





• When a user minimizes a Toolbox, the height will be recalculated.

Upon a right mouse click on the Toolpage tabs, a dialog pops up. This dialog enables the user to select the Toolpages that he/she wants to visualize in the current toolbox.

16.2 View Pages

16.2.1 The View Toolpage

The View Toolpage split up into two parts:

- The Visualization modes
- The Cube

View	Multi-Section	Slices	Grid	
Visualization				
👘 👻 Shad	e		\square	\geq
🔌 👻 Bad E	Edges Visible			
A - Flippe	ed Triangles Visible			\geq

The functions of the View Toolpage are applied on all the parts in the workspace.

*	Shade Triangle	Shade	Shade will display the part with shades according to the direction of the triangles.				
	 Shade&Wire Wireframe Bounding Box Transparency Smooth Shading No-build Zones 	Wireframe	Wireframe shows the edges of the object. This representation is deduced from the STL file. This mode approaches the normal wireframe representation as good as possible, but due to the limited information, STL errors and noise in the				
\$			STL file, abnormalities in this representation may show up. A line of wireframe is drawn when the angle between 2 triangles exceeds a certain value. You can change this value and so adapt the wireframe view.				
		Shade & Wire	The parts are showed in a combination of the shade mode and the wireframe mode.				
		Triangle	The triangles of the parts will be displayed upon the shaded part.				
		Bounding Box	This mode will only show the bounding box of the part. This mode is quick in visualization.				
		Transparency	The parts are shown transparent.				
		Smooth Shading	The parts are shaded as in nature.				
		No-Build zones	The No Build zones are shown on the platform scene.				





Bad Edges Bad Edges Visible Bad Edges Invisible Bad Edges Hidden Line Highlight Bad Edges	Bad Edges Visible Bad Edges Invisible	Defects in the STL file can be detected graphically. All edges that are not shared by exactly 2 triangles will be displayed in yellow on the screen. Makes the bad edges invisible.
	Bad Edges Hidden Line Highlight Bad	The user can hide the indication of the bad edges that are situated behind or inside the part. Bad edges are sometimes difficult to spot. The bad edges are
	Edges	drawn with thick lines so you can see them easily.
Flipped Triangles	Flipped Triangles Invisible	Makes the flipped triangles invisible.
The provide the second seco	Flipped Triangles Visible	Defects in the STL file can be detected graphically. All triangles with a normal pointing into the screen are displayed in the Flipped Triangles color, which is by default red. Remaining red triangles in the shading indicate defects in the STL file (triangles with wrong-oriented normal, missing or overlapping triangles)
	Flipped Triangles As Normal	Shows the flipped triangles as normal triangles.
The Cube	Top H Bottom B Front Back Home View Q ISO ISO Top Front Right Top Front Right Top Back Right Top Back Right Top Back Left E Stotom Front Right Stotom Front Right	Click on the cube to get the requested view. The view where you clicked will be highlighted till you change view: Select another view Rotate manually Clicking on one of the possibilities (it will highlight when the cursor passes over it) accesses these views. The dropdown shows all the possible views. The ISO views.
	Bottom Front Left Bottom Back Right Bottom Back Left	

16.2.2 The Multi-Section Toolpage

The Multi-Section Toolpage allows the user to display 5 multiple sections. Magics Print Metal will always toggle between the Section and Multi-Section Toolpage, when one of them is active and the other is activated via the View menu. In other words, the Section and Multi-Section cannot be displayed at the same time.





View	Mult	ti-Section	Slices		
Active	Туре	Clip	Color	Position	Step
	Xv	٣v	•	0.000	1.000
	Y٧	٣v	•	0.000	1.000
	Zv	Ô٧	•	10.000	1.000
	Xv	٣v	•	0.000	1.000
	Y٧	٣v	0	0.000	1.000
Indicate	A	lign	I I		I.

Active (A)	By checking a row of this column you can make the section visible.				
Туре	The user can define how	Х			
	he/she defines the section.	Y			
	Click on the icon to change	Z			
	the section type in the drop	3 Points			
	down dialog.	Perpendicular on indicated line			
		Coincident with indicated triangle			
		Parallel with screen			
Clip	Here you can select if you wan to look inside the solid part. The	t to hide a side of the part. In this way, it is possible e inside is colored in the Flipped Triangles color			
	(default red).				
		Clicking this icon will switch the section view			
		between Section on Part, Hide side towards origin			
	The drep down many payt to	Soction on Part			
	the icon contains some extra	Hido sido towarda origin			
	ontions	Hide side away from origin			
		Solid section			
		Sections only			
Color	You can assign a different colo	r to each section			
Position	This number indicates the positi	tion of the section along the axis perpendicular to it			
	The units used are the units yo and the section will move to thi	u work in (inch or mm). You can also fill in a number s position.			
Step	Under the window you find a sl slider on the slider bar, the sec	ider bar. If you click to the left or to the right from the tion will move a distance indicated by the Step value.			
	The same happens if you use t	he left and right arrow buttons on your keyboard.			
Indicate	With the Indicate-button, the population will be displayed in the	osition of the section can be pointed on the part. This Position box.			
Align	When you push the align button rotated until the section is align	n, the view point of the part (and the section) will be ed with the screen.			
Slider	You can move the section over calculated and displayed in rea the section is displayed in the F the arrow buttons on your keyb	the parts by sliding the slide. The section will be I-time while you change the position. The position of Position box. The slider will also slide when you use oard.			



152



16.3 Part Pages

16.3.1 Working area

The *Rotate* function allows rotation of your part around all three axes of your screen. Click the Rotate button and use your left mouse button (press it in the workspace) to rotate your part.



Quadruple arrow

The movement of the cursor is translated in a rotation around the three axes in the screen (3D movement).



Circular arrow

The movement of the cursor is translated in a rotation around the axis that is perpendicular to the screen (2D movement).



A circle in the center of your workspace is visualized to show which behavior to expect. When the cursor is inside the circle, it will have a quadruple arrow shape (3D movement). When it is outside the circle, it will have a circular arrow shape (2D movement).

The mouse also has a rotate option:

You can also access this function via your right mouse button shortcut (without clicking on the Rotate button). Press your RM and keep it down while moving your mouse, the part will rotate in accordance with your mouse movements.

16.3.2 Workspace context menu





The context menu in the workspace can be accessed through right-clicking and is as such a quick access point to frequently used function. The usage of the context menu can speed up the general workflow. Depending from where the menu is called, the functions can be different.



16.3.3 The Part List Toolpage

The Part List Toolpage keeps track of the parts in the Part Scene and of the virtual copies in the Platform Scenes.

	•	Part	Pages	200000						×	
	Pa	rt Lis	t	Part	Info	Part Fixir	ng Info Sc	enes			
	1		1					Numb	er of parts	: 17	
	#	3	î	s	2	Memory	Part Name	FixInfo			
	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 **						Horn_outer_1 Horn_1_1 Poussoir_1_Re Engineering_p Engineering_p Clip_1_1 Wheel_Rescal Plug_1_1 Drill_1_1 Frame_1_1 Bishop_1_1 King_1_1 Queen_1_1 Rook_1_1 Knight_1_1 Pawn_1_1	n/a n/a n/a n/a n/a n/a n/a n/a n/a n/a			
	v ~	<u>×</u>	יוכ	()			१। 🛸 💙				
ID				Uniqu	ie id	entifier for	the part				
Selected				Wher selec	the ted.	checkbo>	of a part is	check	ed, then	the	part is
Visible (\	/)		-	The p	art i	s visible if	the glasses	s are pi	resent.		
Shading	(S)		-	The u every on a l virtua	iser par Platf I cop	is able to t. (Changi orm Scen pies of the	define a sep ng the visua e will chang same moth	parate alization le the v her part	visualiza n of a vii risualiza :).	atior rtua tion	n for I copy of all
				Impol	rt of	parts					



	Hide	Hide the respective part.				
	Shade	Shade will display the respective part				
		with shades according to the				
		direction of the triangles.				
	Wireframe	Wireframe shows the edges of the				
		respective part.				
	Shade&Wire	The respective part is showed in a				
		combination of the shade mode and				
		the wireframe mode.				
	Triangle	The triangles of the respective parts				
		will be displayed upon the shaded				
		part.				
	Bounding Box	This mode will only show the				
		bounding box of the respective part.				
	Transparent	This mode will show the respective				
		part as transparent.				
	Import of slices					
	Slices					
	Bounding Box	This mode will only show the				
		bounding box of the respective part.				
Color (C)	The color in the cir	cle represents the color of the				
	matching part. Clic	king this circle leads you to the				
	material editor dial	og or to the color palette.				
	(Changing the cold	or of a virtual copy on a Platform Scene				
	will change the col	or of all virtual copies of the same				
	mother part).					
Memory State	The user is able to define a separate memory state for					
(M)	every part. (Chang	ing the memory state of a virtual copy				
	on a Platform Scer	he will change the memory state of all				
	Virtual conies of the					
		e same mother part).				
	Compact	e same mother part). The STL resides in the memory as				
	Compact	e same mother part). The STL resides in the memory as read-only; therefore it uses far less				
	Compact	e same mother part). The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory				
	Compact	e same mother part). The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the				
	Compact	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the				
	Compact	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to				
	Compact	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level				
	Compact	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level.				
	Normal	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file Magics knows the				
	Normal	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the				
	Normal	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the				
	Normal	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform				
	Normal	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E g deleting				
	Normal	e same mother part). The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles)				
	On Disk	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles) The STL is saved on disk and				
	Normal On Disk	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles) The STL is saved on disk and unloaded from the memory. The STL				
	Normal On Disk	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles) The STL is saved on disk and unloaded from the memory. The STL will stay in the project but the user				
	Normal On Disk	The STL resides in the memory as read-only; therefore it uses far less memory than the Standard memory state. Magics does not know the placement of the triangles nor the mutual dependencies of the triangles. The user is not able to perform actions on STL level. This is the standard memory state of a STL file. Magics knows the placement of the triangles and the mutual dependencies of the triangles. The user is able to perform actions on STL level (E.g. deleting triangles) The STL is saved on disk and unloaded from the memory. The STL will stay in the project but the user can't perform any actions on it.				

155



Part Name /Copy of	This column contains the names or the path of the loaded parts. In case of a Platform Scene, this column will show the name of the virtual copies. The name of a virtual copy is the same as the name of the mother part. If the name doesn't fit in the column a pop up, containing the full part name, will be shown when hovering over the name.
FixInfo	This colums contains the fix status of the part. Double click on part show if there are errors or not. A Second double click performs an autofix on the part
Extend with columns	Here you have the possibility to add or remove additional columns to the part list overview

Select All	Selects every part in the list.
Invert Selection	All selected parts are unselected and the unselected
	parts are selected. The Invert Selected functionality
	works on the Selected (S) column. Invisible parts will thus
	become visible.
Show All	All invisible parts are made visible.
Hide Unselected	Hides all unselected parts.
Unload Selected Parts	Unloads all selected parts.
Add Part to	This function is only available when a scene is present. A
Scene	dialog pops up, showing the parts loaded in the Modeler
	Scene. Check the parts, from which you want to create a
	virtual copy on the active scene.
New Scene	The Select Machine dialog will pop up, where you can
	select the machine of the newly created Platform.



Recommended System Requirements



Select All	Selects every part in the list.			
Invert Selection	All selected parts are unselected and the unselected parts are selected. The Invert Selected functionality works on the Selected (S) column. Invisible parts will thus become visible.			
Show All	Visualize all parts			
Hide Unselected	Hides all unselected p	arts.		
Cut Part(s)	Selected virtual copies clipboard.	s of a platform can be cut to the		
Copy Part(s)	The selected parts or virtual copies are copied to the clipboard.			
Paste Part(s)	Parts are pasted from	the clipboard in the active scene.		
Shells to Parts	This function will split the selected parts, if they consist of more shells, into different parts. Now, each shell will represent one part.			
Merge Selected Parts	The selected parts are merged into one STL.			
Diagnostics	Runs Diagnostics			
Combined Fix	Excutes the Combine	d Fix		
Unload Selected Parts	Deletes all the selected parts from the workspace.			
Set Columns	Pops up a sub menu	where the user can define the		
	visualized columns.			
	Show Part Name	Shows the part name of the parts.		
	Show Path	Shows the path of the part in the Part Name column.		
	# Triangles	Shows the amount of triangles used in the Part List.		
	# Points	Shows the amount of points in the Part List.		





Surface	Shows the Surface of the parts in the Part List.
Volume	Shows the Volume of the part in the Part List.
# Invisible Triangles	Shows the amount of invisible triangles in the Part List.
Preprocessed	Shows the Memory State of the part in the Part List.
Shading	Shows the visualization of the part.
Wireframe angle	Shows the wireframe angle.

16.3.4 The Part Info Toolpage

The properties of the parts in the Part List are displayed. All dimensions are displayed in the selected units.

Part List	t	Part Info	Pa	art Fixing Info	
Part name	Core		*	Rename	Next
Dimension	ns				
Min		Max		Delta	
X -146,3	387	195,898		342,285	mm
Y -296,6	646	335,155		631,801	mm
Z -145,2	757	14,524		160,281	mm
# Marked	d 0	500		# Points # Invisible	0
Propertie	s		7		
Volume	56305	26,358	mm ³		Update
Surface	31952	3,675	mm ²		✓ Automatic
Status No	t chang	jed i	Z Comp	ensated No	



in

the Part List.

Rename	Renames the selected part, a dialog pops up to enter a
	(The part can also be renamed by double clicking the
	part name in the part list.)
Next	The next button allows the user to see the part
	information of the next part in the workspace.
Dimensions	The dimensions of the part. The minimum and maximum
	coordinates (X, Y, Z) of the part. The delta value is the
	difference between the minimum and maximum.
# Triangles	The amount of triangles of the part.
# Points	The amount of points of the part.
# Marked	The amount of marked triangles of the part.
# Invisible	The amount of invisible triangles of the part.
Update	Updates all the information, by default the Volume and
	Surface information has to be updated.
Automatic	If checked, the Volume and Surface will be updated
	automatically.
Volume	The volume of the part.
Surface	The surface of the part.
Status	The status of the STL-part. If no modifications are made
	to the loaded part, the status is Not Changed. In the other
	case, the status is Changed.
Z compensate	Indicates if the part is z-compensated or not.

16.3.5 The Part Fixing Info Toolpage

The Part Fixing Information Toolpage is a guideline through the manual fixing process. By updating this Toolpage you can always determine what is wrong with the STL file.



 Part Pages 				x 🕂 0.000000
Part List	Part Info	Part Fixing Info	Scenes	
Part name Ho	orn_outer_1_1	-		Next
✓ Inverted n	ormals			Fix
Bad edges				
Ba	d contours			
\checkmark	Near bad edge	es		Fix
\checkmark	Planar holes			Fix
Shells				
No	ise shells			Fix
Advanced —				
	Overlapping tr	iangles		Fix
	Intersecting tr	iangles		Fix
	Automatic			Update

Part Name	This is a drop down list containing all the loaded parts. The parts are sorted as in the Part List.
Next	The next button allows the user to see the part information of the next part in the workspace.
Inverted Normals	Shows the amount of Inverted Normals. In the STL format, a normal is indicating the outside of a triangle. When the normal is pointing at the wrong direction (the inside) we call the triangle a flipped triangle.
Bad Edges	Shows the amount of Bad Edges. To have a correct STL file, all edges of each triangle should be connected properly to a neighbor. If an edge is not connected properly, the edge is called a bad edge and is indicated with a yellow line.
Bad Contours	Shows the amount of Bad Contours. A group of bad edges that are connected to each other is a bad contour
Near Bad Edges	Shows the amount of Near Bad Edges. Near bad edges are bad edges that are near other bad edges. These are mainly caused by 2 surfaces that are not well connected. You can recognize them as long yellow lines on the part. You can solve them very easy with stitching.
Planar Holes	Shows the amount of Planar Holes. A hole is where triangles are missing. Use fill hole to fill it up with triangles.
Shells	Shows the amount of shells. A shell is a collection of triangles that are connected to each other. Normally a part has only one shell because every triangle of the part is (indirectly) connected to every other triangle.



Noise Shells	Shows the amount of Noise Shells. Some shells have no geometrical meaning and are considered as noise (waste) that we can throw away. It is however recommended to first have a look at these shells before removing them. Even a shell of a few triangles can be important.
Overlapping	Shows the amount of Overlapping Triangles. Two
Triangles	triangles are considered as overlapping when:
	The distance between 2 triangles is smaller than the
	given tolerance.
	The angle between the normals of the triangles is smaller
	than the given angle.
Intersecting	Shows the amount of Intersecting Triangles. Intersecting
Triangles	triangles are triangles cutting each other.
Undate	Updates all the information, by default the Volume and
opute	Surface information is updated.
Automatic	Check this option if you want the Part Fixing Information
	to be updated automatically. This is not recommended for
	big files.
Fix	The user can click fix to automatically fix the specified
	problem.

16.4 Measurements pages

Magics Print Metal recognizes different features: a point, a line, a plane, a circle, a cylinder and a sphere. You select a feature by moving the pointer of the mouse. Magics will snap (the feature will be marked when you move over it) to all features of the type you selected. For example points - see figure - are marked with a round. In the Settings you can choose which features Magics should recognize. You may for example determine that you only want to snap to points that are in a section, or on a wireframe...



By clicking the left mouse button, you will select the marked feature. When all features of the measurement are selected, they will be marked if the draw feature in the measurement part of the settings is checked.

For example a point is indicated with a cross (see figure), a line with a line (see figure), and a sphere with 3 circumpolar circles. When the draw feature in the measurement part of the settings window is not on, the feature may be selected but is not indicated in a special way.







To select a measurement, you click on the icon 'select parts' in the main toolbar (\mathbb{N}) or in the measurement Toolpage. The mouse pointer gets a green round to show you are in the selection mode. Click on the measurement value to select the measurement. When the measurement is selected some grips will appear. In the figure, the measurement with value 10 is selected. There is a grip in the middle of the measurement line and on one of the intersections of the extension line with the measurement line.



It is possible to adapt a measurement by dragging one of the feature indicators to a same feature positioned elsewhere on the part. This way you get a new measurement. To do so you first have to select a measurement.

In the Settings window, you can indicate how you would like to display the measurement (with or without arrows and extension lines, the size of the grips....).

If you are not satisfied with the position of the measurement value on the screen, you can change this position. First, select a measurement with the mouse. If you select the grips at the cross points of the extension lines, you can turn the measurement indication line around the axis that connects the selected features. When you select the grip in the middle of the measurement line, you can make the extension lines longer or shorter.

Selected measurements can be deleted with the Delete button on the keyboard. To delete one or more measurements (but not all), one has to follow these two steps:

- Select the dimensions you want to delete (keep the shift button down to select several dimensions)
- Hit the Delete button on the keyboard.



All measurements can be deleted at once by clicking the Clear Measurements button in the respective Toolpage.

16.4.1 The Distance Toolpage

The Distance Toolpage allows you to measure the distance between several features.

 Measurement Pages 								
Distance Ra	dius	Angle	Info					
• • •	-	<u>*</u>		Center	٣			
Measurement Info	Measurement Information							
Invisible								
Select	Clear M	easurements	Snap	Settings				

	D : .				
•	Point				
	Line				
0	Circle				
	Plane				
	Cylinder				
	Sphere				
>	Thickness				
8	Bounding Bo	x			
Featu	ire	Measurement Description			
Point The		elength from the second feature to the point.			
Line		The length of the perpendicular through the second feature on the line.			
Circle		The length of the perpendicular through the second feature on the line.			
Plane The I selec		The length of the perpendicular through the second feature on the plane. If you select a plane, Magics will snap to a triangle in that plane.			
Cylinder The leng the cylind		The length of the perpendicular through the second feature on the middle line of the cylinder.			
Sphere The le		length from the second feature to the center of the sphere.			
Thickness		Measuring thickness is a special way of measuring: you do not have to select a			
		second endry. When clicking on the part, wagtes will measure the distance			
		triangle (-the other side of the part) When measuring thickness the spanning			
		on the STI -surface is switched on automatically			
Bound	ding box	Measures the bounding box of the indicated part			
Dound		measures the bounding box of the indicated part.			



Recommended System Requirements

Snapping restrictions						
🙏 3D View						
📥 2D XY						
A 2D XZ						
🤼 2D YZ						
🚓 X - axis						
🙏 Y - axis						
📩 Z - axis						
3D View The measurement is allowed in 3D						
2D XY	The measurement is restricted to the 2D XY plane.					
2D XZ	The measurement is restricted to the 2D XZ plane.					
2D YZ	The measure	ement is restricted to the 2D YZ plane.				
X-axis	The measure	ement is restricted to the 1D X axis.				
Y-axis	The measurement is restricted to the 1D Y axis.					
Z-axis The measurement is restricted to the 1D Z axis.						
Circle options	Center	The center of the circle is used as a starting/ ending point of the measurement.				
	Inside	The inside of the circle is used as a starting/ ending point of the measurement				
	Outside	The outside of the circle is used as a starting/ ending point of the measurement.				

Invisible					
Select	Select Clear Measurements Snap Settings				
Invisible	When checked, the made measurements.	dden. Uncheck to see the			
Select	Measurements can be selected now. A measurement is selected when on the label green dots are visible. When active the measurement or label position can be changed.				
Clear Measurements	Deletes all measurements.				
Snap Settings	Brings you to the Settings window. You can indicate how you would like to display the measurement.				

Notifications

The measurement is dynamic: When you have selected the first feature, Magics will look for the second feature as you move your mouse over the part. The measurement value will change as you snap to features at different positions.

16.4.1.1 Advised Way of Working





Choose the first feature in the menu (by clicking on it), snap the feature on the part and click on it to select it.

 Measure 	ment Pages 🌣			
Distance	Radius	Angle	Info	
• • •	• •			Center -
Measureme	nt Information			
🗌 Invisible				
Select	t Cle	ar Measuremei	nts S	Snap Settings

Choose the restriction of the measurement. This is possible in 1, 2 or 3 dimensions.

 Measurement Page 	jes	00000000000000000000000000000000000000
Distance Radiu	is Angle	Info
• • • •		Center 👻
Measurement Inform	ation	
Invisible		
Select	Clear Measurements	Snap Settings

Choose the second feature in the second menu (by clicking on it) and snap to the feature on the part and then click on it to select it.

 Measure 	ment Pages			00000000000000000000000000000000000000
Distance	Radius	Angle	Info	
• • •	• •	🙏 ·		Center 🝷
Measureme	nt Informatio	n		
Invisible				
Select	t C	lear Measurements	Sn	ap Settings







Choose where you want to display the measurement on the screen, by dragging the extension lines of the measurement.



When you click a last time, the measurement will be fixed.

16.4.2 The Circle Toolpage



166



 Measurement Pag 	es ·····	00000000000000000000000000000000000000
Distance Radiu	s Angle	Info
🔿 🤟 Radius 🚽]	
-Measurement Informa	ation	
Invisible		
Select	Clear Measurement	s Snap Settings

Circle 3 Points Sphere	
Feature	Measurement description
Circle	Select an arc. The radius (or diameter) of the arc will be displayed.
3-Points	Select three points. The radius (or diameters) of the circle defined by these three points will be displayed. Be aware that it is possible to indicate three random points. This can result in a non-existing arc! It is advised to use the radius of an arc measure function when possible. Use this function only when the arc is not recognized by Magics as a feature.
Sphere	Select a sphere. The radius (or diameter) of the sphere will be displayed.
Radius or Diameter	You can choose whether you want to measure the radius or the diameter.

		Snapping restrictions
🙏 3D View	XYZ	The measurement is allowed in 3D
2D XV	XY	The measurement is restricted to the 2D XY plane.
1 2D YZ	XZ	The measurement is restricted to the 2D XZ plane.
	YZ	The measurement is restricted to the 2D YZ plane.
ν ₂ 2D YZ	Х	The measurement is restricted to the 1D X axis.
🐴 X - axis	Y	The measurement is restricted to the 1D Y axis.
🖧 Y-axis	Z	The measurement is restricted to the 1D Z axis.
📩 Z - axis		
Invisible	When checked, the	e made measurements are hidden. Uncheck to see the
	measurements.	
Select	Measurements car	n be selected now. A measurement is selected when on the label
	green dots are visi	ble. When active the measurement or label position can be changed.
Clear	Deletes all measur	ements.
Measurements		
Snap Settings	Brings you to the s measurement.	ettings window. You can indicate how you would like to display the

16.4.3 The Angle Toolpage





 Measurer 	ment Pages 🌣			
Distance	Radius	Angle	Info	
•••		🙏 -		
Measuremen	t Information			
🗌 Invisible				
Select	Cle	ar Measureme	ents	Snap Settings

3 Point Line Plane	S
Feature	Measurement Description
3 points	Select three points. Two imaginary lines will be drawn between those points: between points 1 and 2, and between points 2 and 3. The resulting angle is the angle between those two lines defined by the three points. (You only have to use the 'from side'). Remark: It is advised to measure the angle between two line features when possible. Only use this function when the lines can't be recognized by Magics as features.
Line	Select the two intersecting lines. Both lines will be highlighted, and the intersection point will be drawn. The resulting angle is the angle between those two lines.
Plane	Select two planes.
Defaults	You can also measure the angle between a line or plane and an axis or plane of the coordinate center.

Invisible	When checked, the made measurements are hidden. Uncheck to see the measurements.
Select	Measurements can be selected now. A measurement is selected when on the label green dots are visible. When active the measurement or label position can be changed.
Clear Measurements	Deletes all measurements.
Snap Settings	Brings you to the settings window. You can indicate how you would like to display the measurement.

16.4.4 The Info Toolpage





 Measure 	ment Pages 🎂		······
Distance	Radius	Angle	Info
– Measureme	nt Information		
🗌 Invisible			
Selec	t Clea	ar Measureme	ents Snap Settings

When you snap to a feature, or you select it, some coordinate information of the features is given. This information allows you to draw exactly the same feature on the same point in space.

Point	The X, Y and Z coordinate of the point will be displayed.
Line	The X, Y and Z coordinate of the beginning and end points will be displayed, together with the length of the line.
Circle	The X, Y and Z coordinate of the center of the circle is given, together with its radius.
Triangle	The X, Y, Z coordinates of the corner points and the direction coefficient of the normal will be displayed.
Cylinder	The X, Y and Z coordinate of the middle point of the bounding discs is given, together with the radius.
Sphere	The X, Y and Z coordinate of the middle point of the sphere is given, together with its radius.

Invisible	When checked, the made measurements are hidden. Uncheck to see the measurements.
Select	Measurements can be selected now. A measurement is selected when on the label green dots are visible. When active the measurement or label position can be changed.
Clear Measurements	Deletes all measurements.
Snap Settings	Brings you to the settings window. You can indicate how you would like to display the measurement.

16.5 Fixing Pages

16.5.1 The AutoFix Toolpage





▼ Autofix			
Automatic Combined Fixing			
Manual Combined Fixing			
☑ Normal Fixing	Unify		
Stitching	Filter Sharp Triangles		
Remove Noise Shells			
✓ Hole Filling	Conditional		
Planar			
Freeform Grid:	1,000 ‡mm Perform		

Automatic Combined Fixing	A predefined list of actions is performed. Some actions are conditional, this means that the action will only be performed when the Magics is sure that the result will be ok.			
Manual Combined Fixing	Normal Fixing	Magics will reorient the normal of the triangles automatically.		
	Filter Sharp triangles	Sharp triangles will be removed to improve surface quality.		
	Stitching	Magics will do a stitching to solve the near bad edges.		
	Remove	The automatic removal of detected noise shells, these noise		
	Noise Shells	shells make no geometrical sense.		
	Hole Filling	Magics will only fill a contour when he recognizes it as a hole.		
		Some contours are not holes.		
		Conditional	Magics will only fill a contour when he	
			recognizes it as a hole. Some contours are not	
			holes.	
		Planar	The hole will be filled as a planar hole	
		Freeform	Complex shaped contours are better filled using the freeform algorithm.	
			Grid: The triangle size of the surface that is used to fill the contour	
	Unify	This will remove all internal geometry and intersecting triangles. This operation will only be done if the geometry allows it.		





17 Recommended System Requirements

17.1 Hardware

CPU

Intel® Core i7/AMD Athlon™ (Phenom II X4 / X6) multi-core processors 3.0 GHz or higher with SSE2 technology

Memory

16 GB RAM or higher

Free Disk Space

Win 64-bit system 2GB of free disk space for Windows 64-bit (.NET Framework 4.5)

Display

1920 x 1080 resolution or higher 32-bit color depth (True color)

Video Card

GPU chip: NVIDIA GeForce GTX 1060, AMD Radeon RX 480 or better DirectX 11 compatible video card 1 GB of memory (more is recommended) Memory interface width of 192-bit (256-bit is recommended)

17.2 Operating Systems

Magics 21 runs only on:

Windows Vista SP2 (64 bit) Windows 7 (64bit) Windows 8 / 8.1 (64bit) Windows 10 (64bit)

Magics 21 is not supported on following systems:

Windows 98 Windows 2000 Windows XP Home Windows XP Pro SP3 (32bit/ 64bit) Windows Server Editions



171



Magics does not run natively on Mac OS X. Magics does not run natively on Linux, or any other operating system not listed above.

Virtualization systems such as VMWare are not recommended.





18 Contact Info

Europe (Headquarters)

Technologielaan 15 3001 Leuven Belgium Phone +32 16 39 66 11

software.support@materialise.be

United Kingdom AMP Technology Centre Advanced Manufacturing Park Brunel Way, Catcliffe Sheffield, S60 5WG

Phone +44 1143 997 845 software.support@materialise.be

China

Baoshan District Hutai Road 2999 1F Building no 1 Shanghai 200444 P.R.China

Phone +86 21 583 124 06 software.support@materialise.be

Asia – Pacific Unit 5-01, Menara OBYU No. 4, Jalan PJU 8/8A, Damansara Perdana 47820 Petaling Jaya Selangor Darul Ehsan - Malaysia

Phone: +603 7724 1415 software.support@materialise.be

Website: http://software.materialise.com/ USA & Canada 44650 Helm Court Plymouth, MI 48170 USA

Phone: +1 734 259 6445 Phone (toll-free): +1 888 662 5057 software.support@materialise.be

Germany Friedrichshafener Str. 3 82205 Gilching Germany

Phone: + 49 8105 77 859 20 software.support@materialise.be

Japan

Yokohama Portside Bldg. 2F Sakae-cho 8-1 Kanagawa-ku, Yokohama

Phone +81 45 440 4591 software.support@materialise.be

